2-Colour Display Digital Flow Switch

Flow rate range: 10, 25, 50,100 /min.

Minimum unit setting: 0.01 4/min. (0.1 ℓ /min when the flow rate range is 25, 50, 100 ℓ /min.)

Fluid Air, N₂, Ar, CO₂

Repeatability: ±1%F.S. or less

Grease-free

Flow adjustment valve is integrated. (Reduced piping and space saving)

Response time: Either 50 msec., 0.5 sec., 1 sec. or 2 sec. can be chosen.

2-colour display

Irregular value at a glance









c**Al**°us (E









2-Colour Display Digital Flow Switch





Indicator function


Flashing speed varies according to flow rate. Colour changes from green to red when rated flow rate is exceeded. Can be used as a simple monitor.



Flashing speed	Flow rate
Fast	High
Slow	Low

Connectors


Connection and removal of wiring is easy.



Support for vertical and horizontal secure mounting (panel mount)

A single panel opening is sufficient.


Reduces panel fitting work and enables space-savings.



	Integrated type	Remote type		
	E WATE	Q5		
Measurement flow range	Model	Мо	lel	
(∉min)	Wodel	Sensor unit	Display unit	
0.2 to 10 (0.2 to 5)	PFM710	PFM510		
0.5 to 25 (0.5 to 12.5)	PFM725	PFM525	DEMOCIO	
1 to 50 (1 to 25)	PFM750	PFM550	PFM3□□	
2 to 100 (2 to 50)	PFM711	PFM511		

compact


Same size even when the model with different flow rate range (10, 25, 50, 100 ℓ min) is chosen.



Light weights 55 g (FM710)

(With one-touch fitting, without flow adjustment valve)

Conventional model PF2A711: 290 g



Comparison with the conventional model PF2A711 (10 to 100 l/min)

Piping space can be reduced

Mountable in a narrow location since straight piping length* is not required.


* A straight piping length of 8 times the piping diameter is required for the conventional model.



Comparison with the conventional model PF2A711 (10 to 100 ℓ/min) when ø6 one-touch fittings are attached.

Piping Variations

// Fing remaine						
	One-touch fitting: Ø4, Ø6, Ø8, Ø1/4		Female thread: Rc 1/8, 1/4 • NPT 1/8, 1/4 • G 1/8, 1/4			
	Straight	Bottom	Straight Bottom			
Without flow adjustment						
With flow adjustment						



Main Functions

Selection of fluid

Air, Nitrogen (N₂), Argon (Ar) or Carbon dioxide (CO₂) can be selected using the buttons.

Secret code setting function

The user must input a secret code to cancel the keylock mode. This ensures that only authorised persons can operate the switch.

For details and other functions, refer to page 33.

Power-saving mode

Turning off the display can save power consumption.






The decimal point indicators flash in power-saving mode.

Selection of indication unit	User can select between ANR and Nt/min for each fluid. [ANR] Indicates the flow rate converted to a volume under standard conditions: 20°C, 1 atm (atmosphere), 65%RH [Nt/min] Indicates the flow rate converted to a volume under normal conditions: 0°C, 1 atm (atmosphere).
■ External input Can be selected from accumulated value external reset, auto-shift and auto-shift zero. ■ Indication Minimum unit setting can be selected from 1 t/min, 0.1 t/min and 0.01 t/min. Depends on the Refer to the specifications (P. 33) for details.	


Several Combinations

Depending on the installation conditions, it is possible to add or remove the **flow adjustment valve**, change the **fitting type** and the **piping direction** as desired.





The accuracy may fluctuate by 2 to 3% just after replacement. (Repeatability does not change.)

Recommended Air Circuits





Vacuum line








-■Comparison with Float Type Flow Meter ■--















For Air



For Water



For Deionised Water and Chemicals



For details, refer to the individual catalogue (CAT.ES100-54).

Measurement		Model	
flow range ℓ/min	Sensor unit	Monitor	4-channel flow monitor
0.4 to 4	PF2D504		
1.8 to 20	PF2D520	PF2D30□	PF2D20□
4.0 to 40	PF2D540		

Remote type



2-Color Display Digital Flow Switch

Series PFM7 Integrated Display



Series PFM5 Remote Sensor Unit



Series PFM7, PFM5 Common Specifications

Series PFM3 Flow Sensor Monitor



Made to Order

Features	Features 1 to 5
How to Order	P. 1
Specifications	P. 3
Piping Specifications / Weight	P. 4
Analogue Output	P. 4
Internal Circuits and Wiring Example	esP. 4
Dimensions	P. 5
How to Order	
Specifications	
Piping Specifications / Weight	
Analogue Output	P. 16
Internal Circuits and Wiring Example	
Dimensions	P. 17
Pressure Loss / Flow Characteristic	
Parts Description	
Construction	
Detection Principle	
Component Parts	P. 27
How to Order	
Specifications	
Analogue Output	
Internal Circuits	
Descriptions	
Dimensions	
Function Details	P. 34
Changing the piping entry direction combination for IN and OUT side	P. 35
Compatible with argon (Ar) and carb dioxide (CO ₂) mixed gas	oon P. 37

Safety Instructions Back page 1
Specific Product Precautions Back page 2 to 5



2-Colour Display **Digital Flow Switch**

Integrated display





How to Order

Integrated PFM7 10 display

7 Integrated display

10	0.2 to 10 (5) e/min
25	0.5 to 25 (12.5) d/min
50	1 to 50 (25) ℓ/min
11	2 to 100 (50) ℓ/min

* (): Fluid: CO2

Flow adjustment valve

Nil	None
S	Yes

Port size

Symbol	Description		w rat	e rar	ige
Symbol	Description	10	25	50	11
01	Rc1/8	•	•	•	
02	Rc1/4				•
N01	NPT1/8	•	•	•	
N02	NPT1/4				•
F01	G1/8	•	•	•	
F02	G1/4				•
C4	ø4 (5/32") one-touch fitting	•			
C6	ø6 one-touch fitting	•	•	•	
C8	ø8 (5/16") one-touch fitting		•	•	
N7	ø1/4 one-touch fitting		•	•	

Piping entry direction

Straight
Bottom

* Different combinations of piping entry directions for IN and OUT side are available as made-to-order. (Refer to page 35.)

Made to Order (Refer to page 2 and 35.) Option 2 (Refer to page 2.) Option 1 (Refer to page 2.)

Calibration certificate

Nil	None
Α	With calibration certificate

* The certificate is written in English and Japanese. Other languages are available as specials.

Instruction manual

Nil	With instruction manual (Leaflet: Japanese and English)
N	None

Unit specification

M	Fixed SI unit Note 1)
Nil	With unit switching function Note 2)

Note 1) Fixed unit: Real-time flow rate: \(\ell \)min Accumulated flow: ℓ

Note 2) This product is for overseas use only according to the new Measurement Law. (The SI unit is provided for use in Japan.)

Output specification

	• •
Α	2 NPN outputs
В	2 PNP outputs
С	1 NPN output + Analogue (1 to 5 V)
D	1 NPN output + Analogue (4 to 20 mA)
E	1 PNP output + Analogue (1 to 5 V)
F	1 PNP output + Analogue (4 to 20 mA)
G	1 NPN output + External input Note 3)
Н	1 PNP output + External input Note 3)


Note 3) User can select from accumulated value external reset, auto-shift and auto-shift zero.

Piping Variations


	With one-touch fitti	ngs (C4, C6, C8, N7)	Female thread (01, 02	2, N01, N02, F01, F02)
	Straight (Nil)	Bottom (L)	Straight (Nil)	Bottom (L)
Without flow adjustment valve (Nil)				
With flow adjustment valve (S)				


2-Colour Display Digital Flow Switch Series PFM7

Option 1



Option 2






Each option is not assembled with the product, but shipped together.


Made to Order

	-
Symbol	Specification/Description
X693	Change of piping entry direction
X694	combination
X731	Compatible with argon (Ar) and carbon dioxide (CO ₂) mixed gas

For details, refer to page 35 through to 37.

DIN Rail Mounting Bracket (Order Separately)





- DIN rail (supplied by customers)
- Port size F02: G1/4 cannot be mounted on the DIN rail.

Specifications

Model			PFM710	PFM725	PFM750	PFM711		
Applicable fluid		Dry air, N ₂ , Ar, CO ₂						
Detect flow some Day oir N. A.			0.04.40.4.5	(Air quality grade is ISC		0.1.100.11.1		
Rated flow rate (Flow rate ran		Dry air, N ₂ , Ar	0.2 to 10 <i>t</i> /min	0.5 to 25 t/min	1 to 50 t/min	2 to 100 t/min		
(Flow rate rail	ge)	CO ₂	0	0.5 to 12.5 t/min	1 to 25 t/min	2 to 50 t/min		
Displayed flow	V Note 1)	Dry air, N ₂ , Ar	0.2 to 10.5 t/min	0.5 to 26.3 t/min	1 to 52.5 <i>t</i> /min	2 to 105 t/min		
		CO ₂	0.2 to 5.2 d/min	0.5 to 13.1 <i>t</i> /min	1 to 26.2 <i>t</i> /min	2 to 52 d/min		
Set flow Note 1) Dry air, N ₂ , Ar		0 to 10.5 t/min	0 to 26.3 t/min	0 to 52.5 t/min	0 to 105 t/min			
Minimum unit setting Note 2)			0 to 5.2 e/min 0.01 e/min	0 to 13.1 <i>d</i> /min	0 to 26.2 d/min 0.1 d/min	0 to 52 t/min 0.1 t/min		
		ate exchange value	0.1 d/pulse	0.1 <i>d</i> /pulse	0.1 d/pulse	1 t/pulse		
			'	Real-time flow rate	e/min, CFM x 10⁻²			
Indication uni	[Note 3)			Accumulated f				
Linearity				Display accuracy: ±3%F. Analogue output accu				
Repeatability				±1%F.S. or less	(Fluid: Dry air)			
	ooto-!-!!			Analogue output accu	-			
Pressure char	acteristic	:5		±5%F.S. or less (b. ±2%F.S. (1				
Temperature of	character	istics		±2%F.S. (±5%F.S. (
Operating pre	ssure rar	nge		-100 kPa	to 750 kPa			
Rated pressure range				-70 kPa to	o 750 kPa			
Proof pressure				1 N	IPa			
Accumulated flow range			Max. 999999 ℓ Note 4)					
Switch output			NPN or PNP open collector output					
Maximum load current		80 mA						
	Maximun	n applied voltage	28 VDC (at NPN output)					
	Internal voltage drop		NPN output: 1 V or less (at 80 mA) PNP output: 1.5 V or less (at 80 mA)					
	Respons	e time		1 s (50 ms, 0.5 s, 2				
		rotection	Short-circuit protection, Overcurrent protection					
Accumulated	pulse out	i	NPN or PNP open collector output (Same as switch output)					
		Response time	1.5 s or less (90% response)					
Analogue out	out Note 5)	Voltage output	Voltage output: 1 to 5 V Output impedance: 1 kΩ					
		Current output	Current output: 4 to 20 mA					
	Hve	teresis mode	Max. load impedance: 600 Ω , Min. load impedance: 50 Ω					
Hysteresis Note	e 6)	ow comparator mode						
External input		on comparator mode	Variable No-voltage input (Reed or Solid state) Input 30 ms or more					
Display metho				ent LED 2-colour display (, ,			
Status LED's			0 . 0	output is turned ON (Green)	<u> </u>			
Power supply	voltage				C ±10%	, , ,		
Current consumption		55 mA or less						
Enclosure		IP40						
	Operating	fluid temperature	0 to 50°C (with no freezing and condensation)					
	Operating	temperature range						
Environ-	Operatin	g humidity range	Operating, Stored: 35 to 85%R.H. (with no condensation)					
mental	Withstan	d voltage	1000 VAC for 1 min. between external terminal and case					
resistance	Insulatio	n resistance	,	500 VDC measured via Meg				
	Vibration	resistance	Without orifice: 10 to 500 Hz with a 1.5 mm amplitude or 98 m/s ² acceleration, in each X, Y, Z direction for 2 hrs, whichever is smaller. With orifice: 10 to 150 Hz with a 1.5 mm amplitude or 19.6 m/s ² acceleration, in each X, Y, Z direction for 2 hrs, whichever is smaller.					
	Impact re	esistance	490 m/s² in X, Y, Z directions 3 times each					
	-			ndication upper limit will be [9.99				

Note 1) When the minimum unit setting 0.01 t/min is selected for 10 t/min type, the indication upper limit will be [9.99 t/min]. When the minimum unit setting 0.1 t/min is selected for 100 t/min type, the indication upper limit will be [99.9 t/min]

"ANR" is used for standard conditions: 20°C, 1 atm and 65%R.H.

"Nd/min" is used for normal conditions: 0°C and 1 atm.

When equipped with a unit switching function. (The SI unit (t/min or t) is fixed for types with no unit switching function.)

Note 4) Cleared when the power supply is turned off. Hold function can be selected. (Interval of 2 min or 5 min can be selected).

If the 5 min interval is selected, the life of the memory element (electronic part) is limited to 1 million cycles. (If energised for 24 hours, life is calculated as 5 min x 1 million = 5 million min = 9.5 years). Therefore, if using the hold function, calculate the memory life for your operating conditions, and use within this life.

Note 5) Set to 1.5 s (90%), can be changed to 100 ms.

Note 6) Set to hystresis mode at the time of shipment from the factory. Can be changed to window comparator mode using push-buttons.



Note 2) User can select between 0.01 d/min and 0.1 d/min for the PFM710, and between 0.1 d/min and 1 d/min for the PFM711 respectively.

If the indication unit is selected to "CFM", the minimum unit setting cannot be changed.


At the time of shipment from the factory, the minimum unit setting is set to 0.1 //min for the PFM710 and 1 //min for the PFM711 respectively.

Note 3) Set to "ANR" at the time of shipment from the factory.

Piping Specifications / Weight


Part no.	01	02	N01	N02	F01		F02	C4	C6	C8	N7
Port size	Rc 1/8	Rc 1/4	NPT 1/8	NPT 1/4	G1/8		G1/4	ø4 (5/32") one-touch fitting	ø6 one-touch fitting	ø8 (5/16") one-touch fitting	1/4 one-touch fitting
Weight	Strai Botto Strai Botto	om \ ight \	Nithout on the Without of With Orifi With Orifi With Orifi	orifice: 1 ce: 135	05 g g	Straight Bottom Straight Bottom	Without orifice: 125 g Without orifice: 135 g With orifice: 165 g With orifice: 175 g	Bot Stra	tom With aight With	nout orifice: 5 nout orifice: 6 n orifice: 95 g n orifice: 105	5 g
Wetted parts material	LCP, PBT, Brass (Electroless nickel plated), HNBR (+ Fluoro coated), FKM (+ Fluoro coated), Silicon, Au, Stainless steel 304										

Analogue Output Note: Analogue output at maximum rated flow rate when CO2 is selected is 3 [V] for the voltage output type and 12 [mA] for the current output type.



Analogue Voltage Output (1 to 5 V) Max. rated flow value Model [e/min] PFM710-□-C/E 10 PFM725-□-C/E 25 PFM750-□-C/E 50


PFM711-□-C/E




Analogue Current Output (4 to 20 mA) Max. rated Model flow value [e/min] PFM710-□-D/F 10 (5) PFM725-□-D/F 25 (12.5) PFM750-□-D/F 50 (25) PFM711-□-D/F 100 (50)

* (): Fluid: CO₂

Internal Circuits and Wiring Examples






Internal voltage drop 1 V or less

NPN + Analogue output type NPN + Analogue output type


100



Max. 28V, 80 mA Internal voltage drop 1 V or less

- C: Analogue output 1 to 5 V Output impedance 1 $k\Omega$
- D: Analogue output 4 to 20 mA Load impedance 50 to 600Ω


NPN + External input type PFM7



Max. 28 V. 80 mA Internal voltage drop 1 V or less

External input: No-voltage input Reed switch or solid state switch input 30 msec or more


2 PNP outputs type PFM7 B-B-B-



Max. 80 mA Internal voltage drop 1.5 V or less

PNP + Analogue output type


PNP + Analogue output type



Max. 80 mA Internal voltage drop 1.5 V or less

- E: Analogue output 1 to 5 V Output impedance 1 $k\Omega$ F: Analogue output 4 to 20 mA
- Load impedance 50 to 600Ω


PNP + External input type




Max. 80 mA Internal voltage drop 1.5 V or less

External input: No-voltage input Reed switch or solid state switch input 30 msec or more

Accumulated pulse output wiring examples











Dimensions


PFM7 C4/C6/C8/N7



	(mm)
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	64.2
ø6	64.6
ø8 (5/16")	68
ø1/4	64.6


PFM7 - C4L/C6L/C8L/N7L







Dimensions


PFM7□□-(N)01/(N)02/F01






PFM7□□-(N)01L/(N)02L/F01L










Dimensions


PFM7□□-**F**02









PFM7□□-F02L









2-Colour Display Digital Flow Switch Series PFM7


Dimensions


PFM7 S-C4/C6/C8/N7



PFM7 S-C4L/C6L/C8L/N8L










Dimensions


PFM7□S-(N)01/(N)02/F01






PFM7□S-(N)01L/(N)02L/F01L







Dimensions

PFM7□S-F02




PFM7□S-F02L






Dimensions


Panel mount / Without flow adjustment valve / Straight






	(111111)
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	64.2
ø6	64.6
ø8 (5/16")	68
ø1/4	64.6

Panel mount / Without flow adjustment valve




Panel Fitting Dimensions



Panel thickness 1 to 3.2 mm

Note) Piping entry direction: Minimum dimensions for bottom side piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.


Panel mount / With flow adjustment valve / Straight




ø1/4

92.6

Panel mount / With flow adjustment valve



Panel Fitting Dimensions




Panel thickness 1 to 3.2 mm


Note) Piping entry direction: Minimum dimensions for bottom side piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.

Dimensions

With bracket / Without flow adjustment valve




DIN rail mounting




- DIN rail (supplied by customers)
 Port size, F02: G1/4 cannot be mounted on the DIN rail.

With bracket / With flow adjustment valve



Lead wire with connector **ZS-33-D**



Cable Specifications of Lead Wire with Connector

Rated temp	erature	80°C		
Rated volta	ge	30 V		
Number of wires		4		
	Nominal cross section area	AWG26		
0	Material	Soft copper wire		
Conductor	Construction	28 / 0.08 mm		
	External diameter	Approx. 0.50 mm		
	Material	Cross-linked vinyl chloride resin compound		
Insulation	External diameter	Approx. 1.00 mm		
	Colours	Brown, White, Black, Blue		
Sheath	Material	Oil-resistant vinyl chloride resin compound		
Sneath	Colour	Light grey		
Finished external diameter		ø3.5 ^{+0.10} _{-0.25}		


2-Colour Display Digital Flow Switch

Series PFM5



C P US

How to Order



Piping entry direction

Nil	Straight
L	Bottom


^{*} Different combinations of piping entry directions for IN and OUT side are available as made-to-order. (Refer to page 35.)

Piping Variations


	With one-touch fitti	ngs (C4, C6, C8, N7)	Female thread (01, 02	2, N01, N02, F01, F02)
	Straight (Nil)	Bottom (L)	Straight (Nil)	Bottom (L)
Without flow adjustment valve (Nil)				
With flow adjustment valve (S)				


2-Colour Display Digital Flow Switch Series PFM5

Option 1



Option 2






Each option is not assembled with the product, but shipped together.


Made to Order

Symbol	Specification/Description
X693	Change of piping entry direction
X694	combination

For details, refer to page 35 and 36.

DIN Rail Mounting Bracket (Order Separately)





- DIN rail (supplied by customers)
- Port size F02: G1/4 cannot be mounted on the DIN rail.

Specifications

Model		PFM510	PFM525	PFM550	PFM511			
Applicable fluid			Dry air, N ₂ , Ar, CO ₂ (Air quality grade is ISO8573.1-1, 1.1.2 to 1.6.2.)					
Rated flow range Note Dry air, N2, Ar		0.2 to 10 l/min	0.5 to 25 l/min	1 to 50 l/min	2 to 100 l/min			
(Flow rate ra	ange)	CO ₂	0.2 to 5 l/min	0.5 to 12.5 l/min	1 to 25 l/min	2 to 50 l/min		
Accuracy			±3%F.S. or less					
Repeatability			±1%F.S. or less (Fluid: Dry air)					
Pressure ch	aracteristi	cs	±5%F.S. or less (based on 0.35 MPa)					
Temperature characteristics			±2%F.S. (15 to 35°C) ±5%F.S. (0 to 50°C)					
Operating p	ressure ra	nge		-100 kPa t	o 750 kPa			
Rated press	ure range			–70 kPa to	750 kPa			
Proof press	ure		1 MPa					
Response time		50 msec or 1 s (with response time selection function: 1 s at no-voltage input) → Refer to the internal circuits and wiring examples on page 16.						
Analogue or	utput	Voltage output	Voltage output: 1 to 5 V Output impedance: 1 kΩ					
Current output		Current output	Current output: 4 to 20 mA Max. load impedance: 600 Ω , Min. load impedance: 50 Ω					
Status LED'	s		Power ON indicator: Lights when power is turned on (Green). Flow rate indicator: Flashes when flow is applied (Green).					
Power supp	ly voltage		24 VDC ±10%					
Current con	sumption		35 mA or less					
	Enclosur	е	IP40					
	Operating	fluid temperature	0 to 50°C (with no freezing and condensation)					
	Operating	temperature range	Operating: 0 to 50°C Stored: -10 to 60°C (with no freezing and condensation)					
Environ-	Operating	g humidity range	Operating, Stored: 35 to 85%R.H. (with no condensation)					
mental resistance	Withstan	d voltage	1000 VAC for 1 min. between external terminal and case					
resistance	Insulation	n resistance	50 MΩ or more (at 500 VDC measured via Megohmmeter) between external terminal and case					
	Vibration	resistance	Without orifice: 10 to 500 Hz with a 1.5 mm amplitude or 98 m/s ² acceleration, in each X, Y, Z direction for 2 hrs, whichever is smaller. With orifice: 10 to 150 Hz with a 1.5 mm amplitude or 19.6 m/s ² acceleration, in each X, Y, Z direction for 2 hrs, whichever is smaller.					
	Impact re	esistance	490 m/s² in X, Y, Z directions 3 times each					

Note: Flow rate unit is based on standard conditions (20C, 1 atm, 65% RH).




Piping Specifications / Weight

Part no.	01	02	N01	N02	F01		F02	C4	C6	C8	N7
Port size	Rc 1/8	Rc 1/4	NPT 1/8	NPT 1/4	G1/8		G1/4	ø4 (5/32") one-touch fitting	ø6 one-touch fitting	ø8 (5/16") one-touch fitting	1/4 one-touch fitting
Weight	Stra Botte Stra Botte	om \ ight \	Without of Without of With Orifi With Orifi	orifice: 1 ce: 135	05 g g	Straight Bottom Straight Bottom	Without orifice: 125 g Without orifice: 135 g With orifice: 165 g With orifice: 175 g	Bot Str	tom With	nout orifice: 5 nout orifice: 6 n orifice: 95 g n orifice: 105	5 g
Wetted parts material	etted parts material LCP, PBT, Brass (Electroless nickel plated), HNBR (+ Fluoro coated), FKM (+ Fluoro coated), Silicon, Au, Stainless steel 304				s steel 304						

Analogue Output

Note: Analogue output at maximum rated flow rate when CO_2 is selected is 4.57 [V] for the voltage output type and 18.28 [mA] for the current output type.




Analogue Voltage Output (1 to 5 V)

Model	Max. rated flow value [//min]
PFM510-□-1	10 (5)
PFM525-□-1	25 (12.5)
PFM550-□-1	50 (25)
PFM511-□-1	100 (50)

* (): Fluid: CO₂


Internal Circuits and Wiring Examples



Analogue Current Output (4 to 20 mA)


Model	Max. rated flow value [//min]			
PFM510-□-2	10 (5)			
PFM525-□-2	25 (12.5)			
PFM550-□-2	50 (25)			
PFM511-□-2	100 (50)			
() 51 : 1 00				

* (): Fluid: CO2




Dimensions

PFM5□□-C4/C6/C8/N7



48


FLOW SENSOR
POWER C





	(mm)
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	64.2
ø6	64.6
ø8 (5/16")	68
ø1/4	64.6

PFM5 C4L/C6L/C8L/N7L

(34.2)









	(mm
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	10.1
ø6	10.3
ø8 (5/16")	12
ø1/4	10.3


Dimensions


PFM5□□-(N)01/(N)02/F01






PFM5□□-(N)01L/(N)02L/F01L






Dimensions


PFM5□□-**F**02






PFM5□□-F02L

19






2-Colour Display Digital Flow Switch $Series\ PFM5$


Dimensions


PFM5\sc4/C6/C8/N7



	(mm)
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	92.2
ø6	92.6
ø8 (5/16")	96
ø1/4	92.6

PFM5 S-C4L/C6L/C8L/N8L







	(mm)
One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	10.1
ø6	10.3
ø8 (5/16")	12
ø1/4	10.3




Dimensions


PFM5□S-(N)01/(N)02/F01





PFM5□S-(N)01L/(N)02L/F01L







2-Colour Display Digital Flow Switch $Series\ PFM5$

Dimensions


PFM5□S-F02



PFM5□S-F02L





28



Dimensions

Panel mount / Without flow adjustment valve / Straight







One-touch fitting Applicable tube O.D.	Α
ø4 (5/32")	64.2
ø6	64.6
ø8 (5/16")	68
ø1/4	64.6

(mm)

Panel mount / Without flow adjustment valve




Panel Fitting Dimensions




Panel thickness 1 to 3.2 mm


Note) Piping entry direction: Minimum dimensions for bottom side piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.

Panel mount / With flow adjustment valve / Straight






Panel mount / With flow adjustment valve



Panel Fitting Dimensions




Panel thickness 1 to 3.2 mm


Note) Piping entry direction: Minimum dimensions for bottom side piping. If using straight piping, the piping material and tubing need to be taken into consideration when designing the system. If a bend (R) is used, limit it to R3 or less.


Dimensions

With bracket / Without flow adjustment valve




DIN rail mounting






- DIN rail (supplied by customers)
 Port size, F02: G1/4 cannot be mounted on the DIN rail.

With bracket / With flow adjustment valve



Lead wire with connector **ZS-33-D**



Cable Specifications of Lead Wire with Connector

erature	80°C		
ge	30 V		
vires	4		
Nominal cross section area	AWG26		
Material	Soft copper wire		
Construction	28 / 0.08 mm		
External diameter	Approx. 0.50 mm		
Material	Cross-linked vinyl chloride resin compound		
External diameter	Approx. 1.00 mm		
Colors	Brown, White, Black, Blue		
Material	Oil-resistant vinyl chloride resin compound		
Color	Light grey		
ernal diameter	ø3.5 +0.10 -0.25		
	Nominal cross section area Material Construction External diameter Material External diameter Colors Material Color		


^{*} Connects to the PFM3□□ series.




Series PFM7/PFM5 **Common Specifications**

Pressure Loss (Pressure: 350 [kPa])


PFM710, 510 / For 10 (dmin)




PFM725, 525 / For 25 (dmin)



PFM750, 550 / For 50 (d/min)




PFM711, 511 / For 100 (d/min)




Flow Characteristics


PFM710, 510 / For 10 (d/min)




PFM725, 525 / For 25 (d/min)



PFM750, 550 / For 50 (dmin)





PFM711, 511 / For 100 (d/min)



2-Colour Display Digital Flow Switch Series PFM7/PFM5


Parts Description





Description	Item			
Output (OUT1) indicator (Green)	Illuminates when the output (OUT1) is turned on. Flashes when overcurrent error occurs.			
Output (OUT2) indicator (Red)	Illuminates when the output (OUT2) is turned on. Flashes when overcurrent error occurs.			
LED display	Indicates the flow rate, set mode state and error code. The display colour can be selected between red and green according to the output (OUT1) status.			
Button	Selects the operation mode and increases the set value for ON and OFF. Used to transfer to peak indication mode.			
	Selects the operation mode and decreases the set value for ON and OFF. Used to transfer to bottom indication mode.			
S Button	Used to make changes in each mode and to enter the set value.			
Reset	Reset function is activated by pressing \triangle and ∇ buttons simultaneously. Returns the indicated value to zero and clears errors.			
Body	Main body of the flow switch			
Flow adjustment valve	Orifice mechanism to adjust the flow rate			
Piping port	Connection port for piping			
Knurled lock nut	Used to fix the needle.			
Power confirmation indicator (Green)	Illuminates when power is supplied.			
Flow rate confirmation indicator (Green)	Flashing interval changes according to flow rate. Flashes faster when flow rate is increased. Colour changes to red when exceeding the rated flow rate.			

Construction



Component Parts


No.	Description	Material	Note
1	Fitting for piping	Brass	Electroless nickel plated
2	O-ring	FKM	Fluoro coated
3	O-ring	HNBR	Fluoro coated
4	Rectifying module	Stainless steel 304	
5	Body	PBT	
6	Sensor housing	LCP	
7	Sensor chip	Silicon	
8	Orifice	Brass	Electroless nickel plated
9	Seal	FKM	Fluoro coated
10	Mesh	Stainless steel 304	
11	Bottom piping adapter	PBT	
12	O-ring	HNBR	Fluoro coated
13	Flow adjustment valve assembly	PBT	
14	Body B	Brass	Electroless nickel plated
15	Needle	Brass	Electroless nickel plated
16	O-ring	HNBR	Fluoro coated
17	O-ring	HNBR	Fluoro coated

Detection Principle

This MEMS sensor chip consists of upstream temperature measuring sensor (Ru) and downstream temperature measuring sensor (Rd), which are placed symmetrically from the centre of a platinum thin film coated heater (Rh) mounted on a membrane, and an ambient temperature sensor (Ra) for measuring gas temperature.

The principle is as shown in the diagram on the right. (a) When the gas is static, the temperature distribution of heated gas centered around Rh is uniform, and Ru and Rd have the same resistance. (b) When the gas flows from the left side, it upsets the balance of the temperature distribution of heated gas, and the resistance of Rd becomes greater than that of Ru.

The difference in resistance between Ru and Rd is proportional to the gas velocity, so measurement and analysis of the resistance can show the flow direction and velocity of the gas. Ra is used to compensate the gas and/or ambient temperature.




(b) The gas flows from the left side.



Series PFM7/PFM5

Component Parts

No.	Descriptio	Model	
1	Body		
2	Lead wire with connector	r (2 m)	ZS-33-D
_3	IN side Bottom piping a	dapter (with pin)	ZS-33-P1L
4	OUT side Bottom piping	adapter (with pin)	ZS-33-P2L
	For straight piping	For 10 dmin	ZS-33-10N
5	Flow adjustment valve	For 25 dmin	ZS-33-25N
3	assembly	For 50 dmin	ZS-33-50N
	(with pin)	For 100 dmin	ZS-33-11N
	For bottom piping Flow adjustment valve	For 10 dmin	ZS-33-10NL
6		For 25 dmin	ZS-33-25NL
Ū	assembly	For 50 dmin	ZS-33-50NL
	(with pin)	For 100 dmin	ZS-33-11NL
	One-touch fitting	ø4 (5/32")	ZS-33-C4
7		ø6	ZS-33-C6
•		ø8 (5/16")	ZS-33-C8
		ø1/4	ZS-33-N7
		Rc 1/8	ZS-33-01
8	Female thread	NPT 1/8	ZS-33-N01
		G 1/8	ZS-33-F01
		Rc 1/4	ZS-33-02
		NPT 1/4	ZS-33-N02
		G 1/4	ZS-33-F02



Flow Sensor Monitor Series PFM3



How to Order



Output specification O 2 NPN outputs + 1 to 5 V output 1 2 NPN outputs + 4 to 20 mA output 2 2 NPN outputs + External input Note) 3 2 PNP outputs + 1 to 5 V output 4 2 PNP outputs + 4 to 20 mA output 5 2 PNP outputs + External input Note)

Note) User can select from accumulated value external reset, auto-shift and auto-shift zero

♦Instruction manual

Nil	With instruction manual (Leaflet: Japanese and English)
N	None

Calibration certificate

Nil	None	
Α	With calibration certificate	

The certificate is written in English and Japanese.
 Other languages are available as specials.

PFM300-ML

Type •

3 Remote display unit

Input specification

Symbol Content		Applicable remote type sensor unit	
0	Voltage input	PFM5□□(S)-□-1-□	
1	Current input	PFM5□□(S)-□-2-□	

Unit specification •


	<u> </u>		
Nil With unit switching function		With unit switching function Note 1)	
	М	M Fixed SI unit Note 2)	

Note 1) This product is for overseas use only according to the new Measurement Law.

(The SI unit is provided for use in Japan.)

Note 2) Fixed unit: Real-time flow rate: ℓ/min
Accumulated flow: ℓ

Option 3




Note) Connector is not connected, but shipped together.

Option 1

Nil	None
L	Power supply / Output connector Power supply / Output connector ZS-28-A

Note) Cable is not connected, but shipped together.

Option 2



Note) Options are not assembled, but shipped together.

Panel mount adapter

Option / Part No.

Description	Part no.	Note
Power supply / Output connector (2 m)	ZS-28-A	
Bracket	ZS-28-B	With M3 x 5 ℓ (2 pcs.)
Sensor connector	ZS-28-C-1	1 pc.
Panel mount adapter	ZS-27-C	With M3 x 8 ℓ (2 pcs.)
Panel mount adapter + Front protective cover	ZS-27-D	With M3 x 8 ℓ (2 pcs.)

(M3 x 8 e)

Specifications

Model		PFM3□□				
Rated flow range Dry air,	N ₂ , Ar	0.2 to 10 e/min	0.5 to 25 ℓ/min	1 to 50 ℓ/min	2 to 100 d/min	
(Flow rate range) CO ₂		0.2 to 5 ℓ/min	0.5 to 12.5 ℓ/min	1 to 25 ℓ/min	2 to 50 ℓ/min	
Note 1) Dry air,	N ₂ , Ar	0.2 to 10.5 ℓ/min	0.5 to 26.3 ℓ/min	1 to 52.5 ℓ/min	2 to 105 e/min	
Displayed flow range CO ₂		0.2 to 5.2 e/min	0.5 to 13.1 <i>t</i> /min	1 to 26.2 <i>t</i> /min	2 to 52 ∉/min	
Dry air,	N ₂ , Ar	0 to 10.5 ℓ/min	0 to 26.3 ℓ/min	0 to 52.5 ℓ/min	0 to 105 ℓ/min	
Set flow range Note 1) CO ₂		0 to 5.2 ℓ/min	0 to 13.1 <i>t</i> /min	0 to 26.2 <i>e</i> /min	0 to 52 ℓ/min	
Minimum unit setting Note 2)		0.01 ℓ/min	0.1 ℓ/min	0.1 <i>ℓ</i> /min	0.1 ∉ /min	
Accumulated pulse flow rate exchange	ge value	0.1 dpulse	0.1 ℓ/pulse	0.1 <i>d</i> /pulse	1 ℓ/pulse	
Indication unit Note 3)		Real-time flow rate ℓ /min, CFM x 10 ⁻² Accumulated flow ℓ , ft ³ x 10 ⁻¹				
Accumulated flow range Note 4)			19999	999 €		
Power supply voltage			24 VDC (ripple ±10% or les	s) (With polarity protection)		
Current consumption			50 mA	or less		
Sensor input Number of inputs: 1		PFM30□: Voltage input 1 to 5 VDC (input impedance: 1 MΩ) PFM31□: Current input 4 to 20 mADC (input impedance: 250 Ω)				
Hysteresis Note 5)		Hysteresis mode: Variable, Window comparator mode: Variable				
Switch output		NPN or PNP open collector output: 2 outputs Maximum load current: 80 mA, max. load voltage 30 VDC (at NPN output), Residual voltage 1 V or less (at load current 80 mA), With short-circuit protection				
Accumulated pulse output		NPN or PNP open collector output (Same as switch output)				
Response time		1 s (50 ms, 0.5 s, 2 s can be selected.)				
Repeatability		±0.1%F.S. or less, Analogue output accuracy: ±0.3%F.S. or less				
Analogue output		Voltage output: 1 to 5 VDC (0 ℓ/min to max. rated flow rate value) Output impedance: Approx. 1 kΩ, Accuracy: ±1%F.S. or less (relative to display value) Current output: 4 to 20 mADC (0 ℓ/min to max. rated flow rate value) Max. load impedance: 600 Ω (at 24 VDC), Min. load impedance: 50 Ω Accuracy: ±1%F.S. or less (relative to display value)				
Display accuracy		±0.5%F.S. ±1 digit or less				
Display method		3+1/2-digit, 7-segment LED 2-color display (Red/Green) Sampling cycle: 10 times/sec				
Status LED's		OUT1: Illuminates when output is turned ON (Green). OUT2: Illuminates when output is turned ON (Red).				
External input Note 6)		No-voltage input (Reed or Solid state), LOW level input 30 msec or more, LOW level 0.4 V or less				
Enclosure		IP40				
Operating temperature range		Operating: 0 to 50°C Stored: -10 to 60°C (with no freezing and condensation)				
Operating humidity range		Operating, Stored: 35 to 85%R.H. (with no condensation)				
Withstand voltage		1000 VAC for 1 min. between whole charging part and live part				
Insulation resistance		50 MΩ or more (at 500 VDC measured via Megohmmeter) between whole charging part and live part				
Vibration resistance		10 to 500 Hz with a 1.5 mm amplitude or 98 m/s² acceleration, in each X, Y, Z direction for 2 hrs, whichever is smaller. (de-energised)				
Impact resistance		100 m/s² in X, Y, Z directions 3 times each(de-energised)				
Temperature characteristics		±0.5%F.S. or less (based on 25°C)				
Connection		Power supply / Output connection: 5P connector, Sensor connection: 4P connector				
		1 Ower suppry	•	· · · · · · · · · · · · · · · · · · ·		
Material		i ower suppry	Front case, Re	ear case: PBT		

Note 1) Select the sensor to connect in the initial setting. If CO₂ is selected as the operating fluid, the value is 1/2 on the maximum side.

Note 2) When 10 t/min with a minimum unit setting of 0.01 t/min is selected for the connected sensor, the upper limit of the display range is 10.50 t/min. When 100 t/min with a minimum unit setting of 0.1 t/min is selected for the connected sensor, the upper limit of the display range is 105.0 t/min. The setting at the time of shipment is 10 t/min with a minimum unit setting of 0.01 t/min for the connected sensor.

Note 3) When equipped with a unit switching function. (The SI unit (#min or t) is fixed for types with no unit switching function.)


Note 4) The accumulated flow value is cleared to 0 when power is turned off. It is possible to select function that holds the accumulated flow value so it is not cleared. (The accumulated flow


4) The accumulated now value is cleared to owner power is turned on. It is possible to select function that notes the accumulated now value so it is not cleared. (The accumulated now value can be held at 2- or 5-minute intervals.) The service life of the memory element (electronic component) is limited to 1 million overwrite cycles (assuming 24-hour operation, 5 minutes x 1 million cycles = 5 million minutes = 9.5 years) when 5-minute intervals are selected. Therefore, when using the holding function, calculate the service life based on the usage conditions, and use the switch within the service life. Applies to models equipped with a unit switching function. (The SI unit (d/min or d) is fixed for types with no unit switching function.)

Note 5) Set to hystresis mode at the time of shipment from the factory. Can be changed to window comparator mode using push-buttons.

Note 6) Accumulated external reset function at the time of shipment from the factory. Auto-shift or auto-shift zero function can be selected using push-buttons.

Analogue Output Note: Analogue output at maximum rated flow rate when CO2 is selected is 3 [V] for the voltage output type and 12 [mA] for the current output type.





Rated flow range	Max. rated flow value [//min]
0.2 to 10 ℓ/min	10 (5)
0.5 to 25 ℓ/min	25 (12.5)
1 to 50 ℓ/min	50 (25)
2 to 100 e/min	100 (50)


* (): Fluid: CO2

Internal Circuits

PFM3□0

NPN open collector output: 2 outputs Max. 30 V, 80 mA, residual voltage 1 V or less

Analogue output: 1 to 5 V Output impedance: approx. 1 k Ω



PFM3□1


NPN open collector output: 2 outputs

Max. 30 V, 80 mA, residual voltage 1 V or less

Analogue output: 4 to 20 mA


Max. load impedance: 300 Ω (12 VDC) 600 Ω (24 VDC)

Min. load impedance: 50 Ω




PFM3□2

NPN open collector output with external input: 2 outputs Max. 30 V, 80 mA, residual voltage 1 V or less




Accumulated pulse output wiring example



PFM3□3

PNP open collector output: 2 outputs
Max. 80 mA, residual voltage 1 V or less
Analogue output: 1 to 5 V

Analogue output: 1 to 5 V Output impedance: approx. 1 $k\Omega$




PFM3□4

PNP open collector output: 2 outputs Max. 80 mA, residual voltage 1 V or less

Analogue output: 4 to 20 mA


Max. load impedance: 300 Ω (12 VDC) 600 Ω (24 VDC)


Min. load impedance: 50 Ω



PFM3□5

PNP open collector output with external input: 2 outputs Max. 80 mA, residual voltage 1 V or less





Series PFM3

Descriptions

LCD Display

Shows the current flow rate, mode setting, selected display unit, and error code. Four display modes are available, some of which use indications that are fixed either red or green, and others use indications that change from green to red.

Output (OUT1) Indicator (Green)

Lights when the output (OUT1) is turned on.

△ Button

Used for mode selection and increasing the ON/OFF setting value. Also used to switch to peak display mode.



Output (OUT2) Indicator (Red)

Lights when the output (OUT2) is turned on.


SET Button

Used to activate mode changes and new setting values.

▽ Button


Used for mode selection and decreasing the on/off setting value. Also used to switch to bottom display mode.

Dimensions




Sensor connector (ZS-28-C-1)


Pin no.	Terminal name
1	DC (+)
2	N.C.
3	DC (-)
4	IN*




* 1 to 5 V or 4 to 20 mA


With bracket








With panel mount adapter



With panel mount adapter + Front protective cover






Series PFM3


Dimensions

Panel fitting dimensions

Secure mounting of n (2 or more) switches (horizontal)




Secure mounting of n (2 or more) switches (vertical)



Note) If a bend (R) is used, limit it to R2 or less.

Power supply / Output connector (ZS-28-A)



Cable Specifications

Rated temperature		105°C	
Rated voltage		300 V	
Number of wires		5	
	Nominal cross section area	0.2 mm ²	
Con-	Material	Soft copper wire	
ductor	Construction	40 / 0.08 mm	
	External diameter	0.58 mm	
	Material	Cross-linked vinyl chloride resin compound	
Insula-	External diameter	Approx. 1.12 mm	
tion	Standard thickness	0.27 mm	
	Colours	Brown, Black, White, Grey, Blue	
	Material	Oil-resistant vinyl chloride resin compound	
Sheath	Standard thickness	0.5 mm	
	Colour	Light grey (Munsell N7)	
Finished external diameter		ø4.1	



Series PFM Function Details

■ Output operation

The output operation can be selected from the following: Output (hysteresis mode and window comparator mode) corresponding to real-time flow rate,

Output corresponding to accumulated flow,

Accumulated output pulse output

At the time of shipment from the factory, it is set to hysteresis mode and normal output.

■ Indication colour

The indication colour can be selected for each output condition. The selection of the indication colour provides visual identification of abnormal values. (The indication colour depends on OUT1 setting.)

Green for ON, Red for OFF
Red for ON, Green for OFF
Red all the time
Green all the time

■ Selection of operating fluid

The fluid can be selected. If argon (Ar) or carbon dioxide (CO₂) is used, the setting needs to be changed.

Dry air, N ₂
Argon
CO ₂

Note) When CO_2 is selected, the upper limit of the measured flow rate range will be 1/2 of that for other fluids.

■ Selection of indication unit reference

The indication unit reference can be selected between standard conditions and normal conditions.

Standard conditions: Flow rate converted to a volume at 20°C and 1atm (atmosphere)

Normal conditions: Flow rate converted to a volume at 0°C and 1atm (atmosphere)

■ Setting of response time

The flow rate may change momentarily during transition between ON (open) and OFF (closed) of the valve. It can be set so that this momentary change is not detected.

0.05 sec.	
0.5 sec.	
1 sec.	
2 sec.	

<Principle>

When the switch has been in ON area for a set period of time, the output will turn on (or off).

■ Indication mode

The indication mode can be selected between real-time flow rate and accumulated flow.

Real-time flow rate display	
Accumulated flow display	

■ External input function

The external input function can be selected from accumulated value external reset, auto-shift and auto-shift zero.

(Input signal: Connect input line to GND for 30 ms or more.)

External reset: This function resets the accumulated value to "0"

when an input signal is applied.

Auto-shift: This function generates an output corresponding

to the change in relation to real-time flow rate

when an input signal is applied.

Auto-shift zero: This function displays real-time flow rate as "0"

when a positive input signal is applied in the au-

to shift function described above.

Set values and flow rates that are relatively on the negative side are expressed by illumination of the decimal point on the far left.

■ Indication resolution

The indication resolution of the PFM710 and 711 series can be changed to enable values to be indicated in smaller steps.

100 resolution	PFM710 PFM711	by 0.1 e/min by 1 e/min
1000 resolution	PFM710 PFM711	by 0.01 d/min by 0.1 d/min

■ Accumulated value hold

Accumulated value is not cleared even when the power supply is turned off.

The accumulated value is memorised every 2 or 5 min. during measurement, and continues from the last memorised value when the power supply is turned on again.

The life time of the memory element is 1 million access cycles. Take this into consideration before using this function.

■ Selection of analog output filter

This selection is available when using a product with an analogue output.

A signal with fast response speed can be generated by turning off the analog output filter.

■ Selection of power-saving mode

The power-saving mode can be selected.

With this function, if no buttons are pressed for 30 sec., it shifts to power-saving mode.

At the time of shipment from the factory, the product is set to the normal mode (the power-saving mode is turned off).

(When power-saving mode is activated, the decimal point flashes.)

■ Setting of secret code

The user can select whether a secret code must be entered to release key lock.

At the time of shipment from the factory, it is set such that the secret code is not required.

■ Peak/Bottom value indication

The maximum (minimum) flow rate is detected and updated from when the power supply is turned on. In peak (bottom) value indication mode, this maximum (minimum) flow rate is displayed.

■ Keylock function

Prevents operation errors such as accidentally changing setting values.

■ Zero clear function

Allows the user to adjust the measured flow rate indication to zero. The adjustment range is $\pm 7\% F.S.$ of the initial factory setting.

■ Error indication function

When an error or abnormality arises, the location and contents are displayed.


Description Contents		Action	
Flow rate	The flow rate exceeds the upper limit of indicated flow rate range.	Decrease the flow rate.	
enoi	There is a reverse flow equivalent to -5% or more.	Turn the flow to correct direction.	
Overcurrent	Load current of 80 mA or more is applied to the switch output (OUT1).	Eliminate the cause of the overcurrent by turning off the power supply and then turn on it again.	
error	Load current of 80 mA or more is applied to the switch output (OUT2).		
System	Possibility of internal circuit damage before factory adjustment.	Stop operation immediately and contact SMC.	
error	System error. Possibility of data memorising failure or internal circuit damage.	Reset the unit, and carry out all settings again.	
Zero clear error	If zero clear is performed (by holding down a and buttons simultaneously for 1 sec.) while there is some flow, "Er4" will be displayed for 1 sec.	Perform zero clear of ac- cumulated flow rate when there is no flow.	
Flow rate error	The flow rate exceeds the accumulated flow rate range.	Clear the accumulated flow rate. (This error does not matter when the accumulated flow ra- te is not being used.)	

If the error or abnormality cannot be solved by the action above, please contact SMC for further investigation.



Series PFM7/PFM5

Made to Order 1






Symbol

Changing the piping entry direction combination for IN and OUT side


X693, X694




For details of How to Order, refer to page 1 and 13.

Dimensions

PFM₅⁷□□-C4/C6/C8/N7-□-X693




PFM₅⁷ □ □ - C4/C6/C8/N7 - □ - X694




One-touch fitting Applicable tube O.D.		Α	В
C4	ø4 (5/32")	10.1	8.1
C6	ø6	10.3	8.3
C8	ø8 (5/16")	12	10
N7	ø1/4	10.3	8.3

PFM₅⁷□□-□01/02-□-X693



PFM₅⁷ □ □ - □ 01/02 - □ - X694




Port size	A	В	C (Width across flats)
Rc 1/8, 1/4 NPT 1/8, 1/4 G 1/8	13	11	17
G 1/4	17	15	21



Series PFM7/PFM5


Made to Order 2






Dimensions

PFM⁷₅□□S-C4/C6/C8/N7-□-X693




One-touch fitting Applicable tube O.D.	Α	В
ø4 (5/32")	10.1	8.1
ø6	10.3	8.3
ø8 (5/16")	12	10
ø1/4	10.3	8.3

PFM⁷₅□□S-C4/C6/C8/N7-□-X694




One-touch fitting Applicable tube O.D.	Α	В
ø4 (5/32")	10.1	36.1
ø6	10.3	36.3
ø8 (5/16")	12	37
ø1/4	10.3	36.3

PFM₅⁷□□**S**-□**0**1/**0**2-□-**X**6**9**3



Port size	Α	В	C (Width across flats)	
Rc 1/8, 1/4 NPT 1/8, 1/4 G 1/8	13	11	17	
G 1/4	17	15	21	

PFM₅⁷□□S-□01/02-□-X694



Port size	A B		C (Width across flats)	
Rc 1/8, 1/4 NPT 1/8, 1/4 G 1/8	13	39	17	
G 1/4	17	43	21	

Series PFM7/PFM5 Made to Order 3

Please contact SMC for detailed specifications, lead times and prices.




Symbol

Compatibility with argon (Ar) and carbon dioxide (CO₂) mixed gas

X731


The argon–carbon dioxide gas ratio (Ar: CO₂) can be selected using the push-buttons from among the following: 92:8, 90:10, 80:20, 70:30, and 60:40. Dimensions are same as those of standard models.




For details of How to Order, refer to page 1 and 13.

Model	Gas ratio		Date of flavor rows	Dianta vahla vanga	Cattable renee	Max. analog output	
Model	Ar	CO ₂	Rated flow range	Displayable range	Settable range	Voltage (Vmax)	Current (Imax)
	92%	8%	0.2 to 7.0 d/min	0.2 to 7.4 d/min	0 to 7.4 <i>d</i> /min	3.80 V	15.2 mA
	90%	10%					
PFM710	80%	20%					
	70%	30%					
	60%	40%					
	92%	8%	0.5 to 25.0 ∉/min	0.5 to 26.3 ℓ/min	0 to 26.3 t/min	5.00 V	20.0 mA
	90%	10%					
PFM725	80%	20%	0.5 to 20.0 ∉/min	0.5 to 21.0 d/min	0 to 21.0 ∉min	4.20 V	16.8 mA
	70%	30%					
	60%	40%					
	92%	8%	1.0 to 50.0 ℓ/min	1.0 to 52.5 ℓ/min	0 to 52.5 d/min	5.00 V	20.0 mA
	90%	10%					
PFM750	80%	20%	1.0 to 40.0 d/min	1.0 to 42.0 ∉ /min	0 to 42.0 d/min	4.20 V	16.8 mA
	70%	30%					
	60%	40%					
	92%	8%	2 to 100 d/min	2 to 105 d/min	0 to 105 d/min	5.00 V	20.0 mA
	90%	10%					
PFM711	80%	20%	2 to 90 e/min	2 to 95 ℓ/min	0 to 95 ℓ/min	4.60 V	18.4 mA
	70%	30%	- 2 to 80 ℓ/min	2 to 84 d/min	0 to 84 ℓ/min	4.20 V	16.8 mA
	60%	40%					

Output characteristics using mixed gas







These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of **"Caution"**, **"Warning"** or **"Danger"**. To ensure safety, be sure to observe ISO 4414 Note 1), JIS B 8370 Note 2) and other safety practices.

■ Explanation of the Labels

Labels	Explanation of the labels		
⚠ Danger	In extreme conditions, there is a possible result of serious injury or loss of life.		
	Operator error could result in serious injury or loss of life.		
⚠ Caution	Operator error could result in injury Note 3) or equipment damage. Note 4)		

- Note 1) ISO 4414: Pneumatic fluid power General rules relating to systems
- Note 2) JIS B 8370: General Rules for Pneumatic Equipment
- Note 3) Injury indicates light wounds, burns and electrical shocks that do not require hospitalisation or hospital visits for long-term medical treatment.
- Note 4) Equipment damage refers to extensive damage to the equipment and surrounding devices.

■ Selection/Handling/Applications

1. The compatibility of the pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or post analysis and/or tests to meet the specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalog information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

2. Only trained personnel should operate pneumatically operated machinery and equipment.

Compressed air can be dangerous if handled incorrectly. Assembly, handling or repair of pneumatic systems should be performed by trained and experienced operators. (Understanding JIS B 8370 General Rules for Pneumatic Equipment, and other safety rules are included.)

- 3. Do not service machinery/equipment or attempt to remove components until safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When equipment is removed, confirm that safety process as mentioned above. Turn off the supply pressure for this equipment and exhaust all residual compressed air in the system, and release all the energy (liquid pressure, spring, condenser, gravity).
 - 3. Before machinery/equipment is restarted, take measures to prevent quick extension of a cylinder piston rod, etc.
- 4. If the equipment will be used in the following conditions or environment, please contact SMC first and be sure to take all necessary safety precautions.
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - 2. Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverages, recreation equipment, emergency stop circuits, clutch and brake circuits in press applications, or safety equipment.
 - 3. An application which has the possibility of having negative effects on people, property, requiring special safety analysis.
 - 4. If the products are used in an interlock circuit, prepare a double interlock style circuit with a mechanical protection function for the prevention of a breakdown. And, examine the devices periodically if they function normally or not.

■ Exemption from Liability

- 1. SMC, its officers and employees shall be exempted from liability for any loss or damage arising out of earthquakes or fire, action by a third person, accidents, customer error with or without intention, product misuse, and any other damages caused by abnormal operating conditions.
- 2. SMC, its officers and employees shall be exempted from liability for any direct or indirect loss or damage, including consequential loss or damage, loss of profits, or loss of chance, claims, demands, proceedings, costs, expenses, awards, judgments and any other liability whatsoever including legal costs and expenses, which may be suffered or incurred, whether in tort (including negligence), contract, breach of statutory duty, equity or otherwise.
- 3. SMC is exempted from liability for any damages caused by operations not contained in the catalogs and/or instruction manuals, and operations outside of the specification range.
- 4. SMC is exempted from liability for any loss or damage whatsoever caused by malfunctions of its products when combined with other devices or software.





Be sure to read this before handling.

Refer to the back of page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Common Precautions.

Design and Selection

⚠ Warning

1. Operate the switch only within the specified voltage.

Use of the switch outside of the specified voltage range can cause not only a malfunction and damage to the switch, but it can also cause electrocution and fire.

2. Do not exceed the maximum allowable load specification.

A load exceeding the maximum load specification can cause damage to the switch.

3. Do not use a load that generates surge volta-

Although surge protectiion is installed in the circuit at the output side of the switch, damage may still occur if a surge is applied repeatedly. When working directly such an unit as relay, solenoid valve, etc., which generates surge, use a built-in surge absorbing element type.

4. Be sure to verify the applicable fluid.

The switches do not have an explosion proof rating. To prevent possible fire hazard, do not use with flammable gases or fluids.

5. Monitor the internal voltage drop of a switch.

When operating below the specified voltage, it is possible that a load may be ineffective, even though the pressure switch function is normal. Therefore, the formula below should be satisfied after confirming the voltage of the load.

> Supply _ Internal voltage > Minimum operating drop of switch voltage voltage of load

6. Use the switch within the specified flow rate measurement and operating pressure.

Operating beyond the specified flow rate and operating pressure can damage the switch.

7. Never use flammable fluids and/or permeable

They may cause a fire, an explosion or corrosion.

- * Refer to the MSDS (Material Safety Data Sheet) when using
- 8. To prevent damage due to failure and/or malfunction of the product, establish a backup system such as a fail-safe system which enables multiple-stage type operation of the equipment and machinery.
- 9. When the product is for an interlock circuit, the following points should be noted.
 - · Provide double interlocking through another system (mechanical protection function, etc.).
 - Perform checks to ensure the product is operating properly, as there is a risk of injury.

∕!\ Caution

1. Ensure sufficient space for maintenance activities.

Provide space required for maintenance.

- 2. The direct-current power supply to combine should be UL authorized power supply.
 - (1) Limited voltage current circuit in accordance with UL 508. A circuit in which power is supplied by the secondary coil of a transformer that meets the following conditions.
 - Maximum voltage (with no load): 30 Vrms (42.4 V peak) or less
 - Maximum current:
 - (1) 8 A or less (including when short circuited)
 - (2) limited by circuit protector (such as fuse) with the following ratings.

No load voltage (V peak) | Max. current rating 0 to 20 [V]

- 100 Above 20 to 30 [V] Peak voltage
- (2) A circuit using max. 30 Vrms or less (42.4 V peak), which is powered by UL 1310 or UL 1585 compatible Class-2 power supply.
- 3. Data of the switch are stored even after the power supply is turned off.

Input data is stored in an EEPROM so that the data will not be lost after the flow switch is turned off. (The data can be rewritten for up to one million times, and stored for up to 20 years.)

Mounting

⚠ Warning

1. Monitor the flow direction of the fluid.

Install and connect piping so that the fluid flows in the direction of the arrow indicated on the body.

- 2. Remove dirt and dust from the inside of the piping by means of air blow, before attaching to the switch.
- 3. Do not drop or bump.

Do not drop, bump, or apply excessive impacts (490 m/s²) while handling. Although the external body of the switch (switch case) may not be damaged, the inside of the switch could be damaged and cause a malfunction.

4. Hold the body of the switch when handling.

The tensile strength of the cord is 49 N and applying a greater pulling force than this can cause a malfunction. When handling, hold the body of the switch.

5. Do not use until you can verify that equipment can operate properly.

Following mounting, repair, or retrofit, verify correct mounting by conducting suitable function and leakage tests after piping and power connections have been made.

- 6. Never mount the switch in a place that will be used as a scaffold during piping.
- 7. Apply a wrench only to the metal part of the piping when installing the flow switch in the piping system.



There is a risk of breakage of the switch.



Be sure to read this before handling.

Refer to the back of page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Common Precautions.

Mounting

1. Observe the proper tightening torque.


When the switch is tightened beyond the specified tightening torque, the switch may be damaged.

2. Do not mount the switch in a place that will be used as a scaffold.


The switch could break if subjected to excessive load such as being accidentally stepped on.

3. Use a tapping screw (P-tite) with nominal diameter of 3 to mount the product by using the bracket mounting hole(s) at the bottom.

The length of the screw depends on the thickness of the plate to be fixed. Please select a screw whose length is the thickness of the plate + 4.8 mm. (The hole depth is 5 mm.)



4. When fixing the switch with screws using mounting holes, use a tightening torque of 0.3 N⋅m or less. If necessary, tighten the product to prevent it from loosening.



Wiring

⚠ Warning

1. Verify the color and the terminal number when wiring.

Incorrect wiring can cause the switch to be damaged and malfunction. Verify the colour and the terminal number in the instruction manual when wiring.

2. Use caution not to repeatedly apply bending or stretching forces to the lead wire.

Repeated pulling or bending of the lead wire may cause some of the wires to break.

Wiring

⚠ Warning

3. Confirm proper insulation of wiring.

Make sure that there is no faulty wiring insulation (contact with other circuits, ground fault, improper insulation between terminals, etc.). Damage may occur due to excess current flow into a switch.

4. Do not wire in conjunction with power lines or high voltage lines.

Wire separately from power lines and high voltage lines, and avoid wiring in the same conduit with these lines. Control circuits, including switches, may malfunction due to noise from these lines.

5. Do not short-circuit a load.

Although the switch displays an overcurrent error if a load is short-circuited, there is not protection against incorrect wiring (power source polarity, etc.). Use caution to avoid wiring incorrectly.

6. Do not connect wiring while energising the product.

The switch and any equipment connected to it could break and malfunction.

Operating Environment

Marning

1. Never use in the presence of explosive gases.

The switch does not have an explosion proof construction. If it is used in an environment where explosive gases are used, it may cause an explosive disaster. Therefore, never use it in such an environment.

2. Mount the switch in a location where there is no vibration greater than 98 m/s², or no impact greater than 490 m/s².

With a switch with orifice, the adjusted flow rate value could be affected by vibration.

3. Do not use in an area where surges are generated.

When there are units that generate a large amount of surge in the area around a pressure switch, (e.g., solenoid type lifters, high frequency induction furnaces, motors, etc.) this may cause deterioration or damage to the switch's internal circuitry. Avoid sources of surge generation and crossed lines.

4. Switches are not equipped with surge protection against lightning.

The flow switches are CE compliant; however, they are not equipped with surge protection against lightning. Lightning surge protection measures should be applied directly to system components as necessary.

5. Avoid using the switch in an environment where the likelihood of splashing or spraying of liquids exists.

The switch is an open type and should not be used in an environment exposed to splashing of water and oil.

6. Do not use the product in an environment subject to a temperature cycle.

If the product is subject to a temperature cycle other than natural changes in air temperature, the internal components of the switch could be adversely affected.

7. Do not mount the product in locations where it is exposed to radiant heat.

This could result in damage and/or malfunction.





Be sure to read this before handling.

Refer to the back of page 1 for Safety Instruct

Refer to the back of page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Common Precautions.

Maintenance

⚠ Warning

1. Perform periodical inspections to ensure proper operation of the switch.

Unexpected malfunctions may cause possible danger.

2. Take precautions when using the switch for an interlock circuit.

When a pressure switch is used for the interlock circuit, devise a multiple interlock system to prevent trouble or malfunction, and verify the operation of the switch and interlock function on a regular basis.

3. Do not make any modifications (including exchanging the printed circuit boards) to the product.

It may cause human injuries and damage.

- 4. When maintenance work is performed, the following points should be noted.
 - Turn off the power supply.
 - Cut off the fluid supply, drain the fluid from the piping and ensure the fluid is released to atmosphere before carrying out maintenance. Otherwise, it could cause injury.

∧ Caution

1. Do not wipe the product with chemicals such as benzene or thinner.

Such chemicals could damage the product.

2. The accuracy could change by 2 to 3% when the piping is removed or replaced.

The repeatability accuracy is $\pm 1\%$ F.S. when piping is replaced with piping of the same size. However, the accuracy could change by 2 to 3% if the size is different or when changing from straight to elbow or from elbow to straight piping.

3. Do not poke the inside of the piping port with a stick.

The rectifier could break, making the product unable to sustain the desired performance.

4. Do not touch terminals or connectors when energising the product.

It could cause electric shock, malfunction, or damage to the switch. $\,$

Fluid

⚠ Warning

1. Check regulators and flow adjustment valves before introducing the fluid.


If pressure or flow rate beyond the specified range are applied to the switch, the sensor unit may be damaged.


- 2. Install a filter on the inlet side when there is a possibility of foreign matter being mixed with the fluid.
- 3. Use dry air of quality compliant with ISO85731-1 for this product.

If any mist or drainage present in the air attaches to the product, accurate measurement could be prevented. Also, the accuracy of the product could be degraded.

Recommended air circuits

<Compressed air line>





Others

∧ Warning

- After the power is turned on, the switch's output remains off while a message is displayed. Therefore, start the measurement after a value is displayed.
- 2. Perform settings after stopping control systems.

Operation reflects the new values when settings are made. However, if the power is turned OFF in that state, the settings return to the values before the change when the power is turned ON again. Make sure to press the S button to save any setting changes before turning OFF the power.





Be sure to read this before handling. Refer to the back of page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Common Precautions.

Settable Range and Rated Flow Range


⚠ Caution

Set the flow rate within the rated flow range.

The regulating flow rate range is the range of flow rate that can be set in the switch.

The rated flow range is the range that satisfies the switch specifications (accuracy, linearity etc.) of the sensor.

It is possible to set a value outside of the rated flow range if it is within the regulating flow rate range, however, the specification is not be guaranteed.



Rated flow range
Displayable range
Settable range

In the case of the PFM5 series, the displayable and settable ranges are the same as the PFM3 series flow monitor.









EUROPEAN SUBSIDIARIES:



Austria

SMC Pneumatik GmbH (Austria). Girakstrasse 8, A-2100 Korneuburg Phone: +43 2262-62280. Fax: +43 2262-62285 E-mail: office@smc.at http://www.smc.at



Belgium

SMC Pneumatics N.V./S.A Nijverheidsstraat 20, B-2160 Wommelgem Phone: +32 (0)3-355-1464, Fax: +32 (0)3-355-1466 E-mail: post@smcpneumatics.be http://www.smcpneumatics.be



Bulgaria

SMC Industrial Automation Bulgaria EOOD 16 kliment Ohridski Blvd., fl.13 BG-1756 Sofia Phone:+359 2 9744492, Fax:+359 2 9744519 E-mail: office@smc.bg http://www.smc.bg



Croatia

SMC Industrijska automatika d.o.o. Crnomerec 12, 10000 ZAGREB Phone: +385 1 377 66 74, Fax: +385 1 377 66 74 E-mail: office@smc.hr http://www.smc.hi



Czech Republic

SMC Industrial Automation CZ s.r.o Hudcova 78a, CZ-61200 Brno Phone: +420 5 414 24611, Fax: +420 5 412 18034 E-mail: office@smc.cz http://www.smc.cz



Denmark

SMC Pneumatik A/S Knudsminde 4B, DK-8300 Odder Phone: +45 70252900, Fax: +45 70252901 E-mail: smc@smc-pneumatik.dk http://www.smcdk.com



Estonia

SMC Pneumatics Estonia OÜ Laki 12, 106 21 Tallinn Phone: +372 6510370, Fax: +372 65110371 E-mail: smc@smcpneumatics.ee http://www.smcpneumatics.ee



Finland

SMC Pneumatics Finland Oy PL72, Tiistinniityntie 4, SF-02231 ESPOO Phone: +358 207 513513, Fax: +358 207 513595 E-mail: smcfi@smc.fi http://www.smc.fi



France

SMC Pneumatique, S.A. Since rheumandue, 3.x...

1, Boulevard de Strasbourg, Parc Gustave Eiffel
Bussy Saint Georges F-77607 Mame La Vallee Cedex 3
Phone: +33 (0)1-6476 1000, Fax: +33 (0)1-6476 1010
E-mail: contact@smc-france.fr http://www.smc-france.fr



Germany

SMC Pneumatik GmbH Boschring 13-15, D-63329 Egelsbach Phone: +49 (0)6103-4020, Fax: +49 (0)6103-402139 E-mail: info@smc-pneumatik.de http://www.smc-pneumatik.de



Greece

SMC Hellas EPE Anagenniseos 7-9 - P.C. 14342. N. Philadelphia, Athens Phone: +30-210-2717265, Fax: +30-210-2717766 E-mail: sales@smchellas.gr http://www.smchellas.gr



Hungary

SMC Hungary Ipari Automatizálási Kft. Budafoki ut 107-113, H-1117 Budapest Phone: +36 1 371 1343, Fax: +36 1 371 1344 E-mail: office@smc.hu http://www.smc.hu



Ireland

SMC Pneumatics (Ireland) Ltd. 2002 Citywest Business Campus, Naas Road, Saggart, Co. Dublin Phone: +353 (0)1-403 9000. Fax: +353 (0)1-464-0500 E-mail: sales@smcpneumatics.ie http://www.smcpneumatics.ie



Italy

SMC Italia S.p.A Via Garibaldi 62, I-20061Carugate, (Milano) Phone: +39 (0)2-92711, Fax: +39 (0)2-9271365 E-mail: mailbox@smcitalia.it http://www.smcitalia.it



Latvia

SMC Pneumatics Latvia SIA Smerla 1-705, Riga LV-1006 Phone: +371 781-77-00, Fax: +371 781-77-01 E-mail: info@smclv.lv http://www.smclv.lv



Lithuania

SMC Pneumatics Lietuva, UAB Oslo g.1, LT-04123 Vilnius Phone: +370 5 264 81 26 Fax: +370 5 264 81 26



Netherlands

SMC Pneumatics BV De Ruyterkade 120, NL-1011 AB Amsterdam Phone: +31 (0)20-5318888, Fax: +31 (0)20-5318880 E-mail: info@smcpneumatics.nl http://www.smcpneumatics.nl

Spain

E-mail: post@smc.smces.es http://www.smces.es

Sweden

Switzerland

Turkey

E-mail: smc@entek.com.tr

http://www.entek.com.tr

// UK

Sweden AB

SMC Pneumatics Sweden AB

Ekhagsvägen 29-31, S-141 71 Huddinge

Phone: +46 (0)8-603 12 00, Fax: +46 (0)8-603 12 90

E-mail: post@smcpneumatics.se

SMC Pneumatik AG Dorfstrasse 7, CH-8484 Weisslingen Phone: +41 (0)52-396-3131, Fax: +41 (0)52-396-3191 E-mail: info@smc.ch

Entek Pnömatik San. ve Tic. A*. Perpa Ticaret Merkezi B Blok Kat:11 No: 1625, TR:34386, Okmeydani, Islanbul Phone: +90 (0)212-444-0762, Fax: +90 (0)212-221-1519

SMC Pneumatics (UK) Ltd Vincent Avenue, Crownhill, Milton Keynes, MK8 0AN

Phone: +44 (0)800 1382930 Fax: +44 (0)1908-555064 E-mail: sales@smcpneumatics.co.uk

http://www.smcpneumatics.co.uk

Zuazobidea 14, 01015 Vitoria Phone: +34 945-184 100, Fax: +34 945-184 124

SMC España, S.A.

http://www.smc.nu

http://www.smc.ch



Norway

SMC Pneumatics Norway A/S Vollsveien 13 C, Granfos Næringspark N-1366 Lysaker Tel: +47 67 12 90 20, Fax: +47 67 12 90 21 E-mail: post@smc-norge.no http://www.smc-norge.no



Poland

SMC Industrial Automation Polska Sp.z.o.o. ul. Poloneza 89, PL-02-826 Warszawa, Phone: +48 22 211 9600, Fax: +48 22 211 9617 E-mail: office@smc.pl http://www.smc.pl



Portugal SMC Sucursal Portugal, S.A. Rua de Eng^o Ferreira Dias 452, 4100-246 Porto Phone: +351 22-610-89-22, Fax: +351 22-610-89-36 E-mail: postpt@smc.smces.es http://www.smces.es



Romania

SMC Romania srl Str Frunzei 29, Sector 2, Bucharest Phone: +40 213205111, Fax: +40 213261489 E-mail: smcromania@smcromania.ro http://www.smcromania.ro



Russia

SMC Pneumatik LLC. AB Sverdlovskaja nab, St. Petersburg 195009 Phone::+7 812 718 5445, Fax:+7 812 718 5449 E-mail: info@smc-pneumatik.ru http://www.smc-pneumatik.ru



Slovakia

SMC Priemyselná Automatizáciá, s.r.o. Námestie Matina Benku 10, SK-81107 Bratislava Phone: +421 2 444 56725. Fax: +421 2 444 56028 E-mail: office@smc.sk http://www.smc.sk



Slovenia

SMC industrijska Avtomatika d.o.o. Mirnska cestá 7, SLO-8210 Trebnje Phone: +386 7 3885412 Fax: +386 7 3885435 E-mail: office@smc.si http://www.smc.si



OTHER SUBSIDIARIES WORLDWIDE:

ARGENTINA, AUSTRALIA, BOLIVIA, BRASIL, CANADA, CHILE, CHINA, HONG KONG, INDIA, INDONESIA, MALAYSIA, MEXICO, NEW ZEALAND, PHILIPPINES, SINGAPORE, SOUTH KOREA, TAIWAN, THAILAND, USA, VENEZUELA

> http://www.smc.eu http://www.smcworld.com

