

Etra Sport mat installation instructions

Requirements for the base

Sanded and vacuum-cleaned concrete, evened out where necessary. Allowed deviation 2 m / \pm 3 mm. Concrete humidity max. 85 % (RYL 2000). Use regular fillers/cements for evening the floor.

Installation

We recommend installing the Etra Sport mat as fixed installation. In special cases, the mat can be installed with butt joint or by taping the seams.

We recommend using a dispersion adhesive for the installation, e.g. Kiilto M1000, or if the mat is exposed to moisture, either from the base or from use, use a 2-component adhesive, e.g. Kiilto Slim (small areas) or Kiilto PL240 (larger areas). Adhesive consumption 300–700 g/m², depending on the type of the base material. Adhesive stains can be freshly removed with ethanol, xylene, or light sanding.

Etra Sport mat cannot be welded, but it can be joined with butt joints, longitudinal extensions may be used. Please note that the product may shrink slightly after opening from the roll. Lay the roll open directly, do not turn. Please note the small bevel on the edge. If there are gaps between extensions, they can be filled with sealant. Small gaps disappear on their own when the mat settles down. Once the mat is glued down, it must be rolled withing 1-2 hours with a roller. Roll the seams twice.