




Assembly Guide **Axelent X-It Escape**

XIT-L/R14-301
XIT-L/R14-401

X-Guard Sliding door

XIT-L/R14-000



x1



M5x20
x1




M5x20
x4



M8x35
x1

XIT-002-301



x1





M3x14
x1



M3
x1




1




CL0034

x1

2





3




XIT-000-301

x1




XIT-000-401


x1




4



5



6



7

