



FINN HAMMER

Concrete remover

Usage

FINN HAMMER is a biodegradable concrete solvent. The product is a slightly viscous liquid detergent used for removal of concrete residues and for washing of concrete trucks and -mixers. Finn Hammer shows outstanding performance without the need of mechanical scrubbing!

Finn Hammer makes removal of concrete and similar residues fast and easy.

Finn Hammer can also be used on cementitious residues and limescale, oil, grease, and dirt. It can be used on tools, machines, and similar surfaces. The product does not harm aluminum, painted surfaces, glass, or rubber. Finn Hammer is an extremely efficient detergent for washing of concrete floors.

Users

Concrete industry, mining industry, machine rentals, building sites, service workshops, concrete floor layers and -renovators.

Properties

Clear, slightly viscous liquid

Contains

Glycolic acid 10-25% Potassium hydroxide < 2,5%

pH in concentrate 2,5

The product is biodegradable.

User instructions

- 1. Apply with sprayer or brush onto the dry concrete residue.
- 2. Let soak for 20-40 minutes. Smaller objects can be cleaned by immersion.
- 3. The product is active when moist do not allow to dry.
- 4. Rinse thoroughly with pressure washer.
- 5. Recommended operating temperature over +5°C.

When washing vehicles, finish the wash using Finn Cleaner Car Wash. This will make removal of concrete residues easier.

N.B.!

Do not apply Finn Hammer in strong sunlight or when the surface temperature is too high. Under these circumstances the product may cause discolorations. The product must be kept moist until rinsed of. Use a pressure washer. The manufacturer and/or importer can not be held responsible for damages arising from failure to comply with the manufacturer's user instructions. Causes serious eye damage. Wear protective goggles and -gloves.





Product codes	Packages
203911	6 x 1 L
203915	3 x 5 L
2039120	20 L
20391200	200 L
203911000	IBC

Waste handling

Dispose of contents/container in accordance with regulations on hazardous waste. Empty and cleaned containers may be burned or recycled. Cardboard boxes can be burned or returned to cardboard waste recycling.

Storage Keep at room temperature

Best before 2 years from packaging date

Made in Finland





