




# Axelent X-Guard Assembly Guide L20-00-0



20100121

BG Инструкции за монтаж  
 CZ Montážní návod  
 DE Montageanleitung  
 DK Monteringsvejledning  
 EE Paigaldusjuhised  
 ES Instrucciones de montaje  
 FI Kokoamisohje  
 FR Les instructions d'assemblage  
 GB Assembly instructions  
 GR οδηγίες συναρμολόγησης  
 HU Összeszerelési utasítások  
 IE Treoracha cóimeála  
 IT Istruzioni di montaggio  
 LT Surinkimo instrukcija  
 LV Montāžas instrukcijas  
 MT Assemblagg istruzzjonijiet  
 NL Montagehandleiding  
 PL Instrukcja montażu  
 PT Instruções de montagem  
 RO Instrucțiunile de asamblare  
 SE Monteringsanvisning  
 SI Sestavljanje navodila  
 SK Montážny návod



Axelent AB  
 Box 1 · Kävsjövägen 17  
 SE-330 33 Hillerstorp  
 Axelent Direct. 0370-37 37 37  
 Fax. 0370-37 37 47  
 E-mail. sales@axelent.se  
 Internet. www.axelent.se

