






Axelent X-Guard Assembly Guide L20-05-2



20130529



Axelent AB
Box 1 · Kävsjövägen 17
SE-330 33 Hillerstorp
Axelent Direct. 0370-37 37 37
Fax. 0370-37 37 47
E-mail. sales@axelent.se
Internet. www.axelent.se



L20-05-2

x 1



x 1 A

BG	Инструкцията за монтаж	IT	Istruzioni di montaggio
CZ	Montážní návod	LT	Surinkimo instrukcija
DE	Montageanleitung	LV	Montāžas instrukcijas
DK	Monteringsvejledning	MT	Assemblagg istruzjonijiet
EE	Paigaldusjuhised	NL	Montagehandleiding
ES	Instrucciones de montaje	PL	Instrukcja montażu
FI	Kokoamisohje	PT	Instruções de montagem
FR	Les instructions d'assemblage	RO	Instrucţiunile de asamblare
GB	Assembly instructions	SE	Monteringsanvisning
GR	οδηγίες συναρμολόγησης	SI	Sestavljanje navodila
HU	Összeszerelési utasítások	SK	Montážny návod
IE	Teoracha cóimeála		

