
# Modular F.R.L. Units

**AC** Series


RoHS



CAT.EUS40-60B-UK


## Transparent bowl guard

#### **Better environmental resistance:** Transparent bowl guard can protect the inner bowl



#### Better visibility: 360°

Use of transparent bowl guard makes it possible to check the condensate inside the filter bowl and the remaining oil amount in the lubricator from the entire periphery.



#### Light weight: Max. 90 g reduction \* Except AW

AF40

Weight 450 g

AF40-A

#### Metal related corrosion does not occur.

Filter

Regulator

Lubricator

AL

AWଁ□0(K)-B



Resin body does not rust.

#### **New Spacer**

#### **Modular connection**

#### Step (1)

- Mount the product by lining up the mating surface of the new spacer with bracket.
- Insert the retainer into the spacer bolt and tighten the nut. (temporary assembling)

Spacer with bracket Retainer


> Tentative tightening by fingers is possible.

#### Step (2)

• Tighten the nut with the hexagon wrench.

#### Interchangeable with previous model

- New spacer can be connected to the previous AF, AR, AL, AW series. • Previous spacer can be connected to the new AF□-A, AR□(K)-B, AL□-A,
  - AW□(K)-B series.



## Modular F.R.L. Units

# AC Series

## Series Configuration


					P	ort si	ze				
	Product	Model	M5	1/8	1/4	3/8	1/2	3/4	1	INDEX	
	Air Filter 🕂 Regulator 🕂 Lubricator	AC10-A									
	AF AR AL	AC20-B									
		AC25-B									
		AC30-B									
	2 <sup>3</sup> 6	AC40-B								P. 7	
	요구의 道 법 취	AC40-06-B									
	·	AC50-B									
		AC55-B									
		AC60-B									
	Filter Regulator	AC10A-A									
	AW AL	AC20A-B									
		AC30A-B									
	TOTAL TOTAL	AC40A-B								P. 15	
	25 - 9	AC40A-06-B									
	2011 (B 8)	AC50A-B									
		AC60A-B									
с (											
	Air Filter 🛨 Regulator	AC10B-A									
	AF AR	AC20B-B									
Air Combination	P	AC25B-B									
nbir	8-1	AC30B-B									
Con		AC40B-B								P. 21	
Air (		AC40B-06-B									
	1	AC50B-B									
		AC55B-B									
		AC60B-B									
	Air Filter 🕂 Mist Separator 🕂 Regulator	AC20C-B									
	AF AFM AR	AC25C-B									
		AC30C-B								P. 27	
		AC40C-B									
		AC40C-06-B									
	Filter Regulator	AC20D-B									
	AW AFM	AC30D-B								P. 31	
		AC40D-B					0				
		AC40D-06-B									

## Series Configuration

	Dee	Madal			F	Port siz	e				
	Proc	JUCT	Model	M5	1/8	1/4	3/8	1/2	3/4	1	INDEX
	AF	100 million (100	AF10-A								
	100000	225.0	AF20-A								
_	234.5		AF30-A				0				
Air Filter		1 III	AF40-A			•	0				P. 43
Air	ų,	-	AF40-06-A								
		Sal	AF50-A						0		
		495	AF60-A								
	AFM		AFM20-A		0	0					
2	体決測	2014	AFM30-A			0	0				P. 55
arato		1.000	AFM40-A			0	0	0			
Sepa	-	100	AFM40-06-A						0		
Mist Separator	8										
≥		Sand Sand									
		- en									
	AFD		AFD20-A								
o			AFD30-A				0				
arat	220.0	TOLA	AFD40-A			0	0	0			P. 55
Sep		COLUMN 1	AFD40-06-A						0		
Mist	Q.										
Micro Mist Separator		-									
Ξ		1									
		65.2									
	AR		AR10-A								
		1000	AR20-B								
r	1000	100	AR25-B				•				
ulato			AR30-B								P.64
Regulator	(135	10.000	AR40-B			0	0	0			
-	1.009	1.1	AR40-06-B						0		
			AR50-B						•	0	.
			AR60-B								
	AR□K		AR20K-B								
tion			AR25K-B				0				
Regulator with Backflow Function			AR30K-B								
tor ∨ × F		and the second	AR40K-B				0				P.67
gulat skflo		16.8.00	AR40K-06-B								
Rec Bac			AR50K-B								
			AR60K-B								
3	L										



						_						AC
	Produc	ct	Model	M5	1/8	F 1/4	Port siz	e 1/2	3/4	1		A
				l T	1/0	1/4	3/0	1/2	3/4			
	AL	- Gim	AL10-A	•							-	AF + AR + AL
	.13.		AL20-A		•	•					-	+ AR
tor	N I I R	211-	AL30-A			•	0				-	AF
Lubricator	10 TO 2	1111	AL40-A			•	0	•			P. 82	
Luk			AL40-06-A						0			AW+AL
	4	.7	AL50-A						•	0		AM
			AL60-A							0		ĸ
	AW	-	AW10-A									AF+AR
		1 1	AW20-B		0	0					1	▲
	1253	and the second s	AW30-B			0	0				1	AR
ator		17 x 2 x 11	AW40-B			0	0	0			P. 92	<b>≚</b>
gula	1 - 1		AW40-06-B						0		1	AF+AFM+AR
Filter Regulator	and a second sec	1000	AW60-B						0	0	1	AF
Filte	-	in a									·	Σ
	ž											AFI
		A										AW+AFM
		44										
	AW□K	100	AW20K-B									Attachment
		AW30K-B							hr			
hith n	1000	and in	AW40K-B								P. 95	ttac
or w		191	AW40K-06-B						0			Ā
julator with Function			AW60K-B									
Filter Regu Backflow I	Contraction of	3										ЧF
ilter acki	-											
ш	ž	2-										<u>e</u>
		-										AFM / AFD
												AFN
Sim	ple Spe	cials Sys <sup>.</sup>	tem 🗛	syst	em d	esign	ed to	resp	ond	quicl	dy	
	-										needs	AR
	$\cap$	Shor	t lead tim	es								
Sin	nple	This syst	em enables us to I machining, acce	respon								
			ich special produ									AL
	pecials	Dana	ot orders									
		receive a Simple		part nu	mber fr	om you	r previo	us				
	<b>S</b> ystem	will process the o to you.									AV	
1	/	uenverit	to you.									



#### **Repeat orders**

Please contact your local sales representative for more details.

**SMC** 


#### Attachment List


#### Check valve

Applicable ser

A check valve with intermediate branch port can be easily installed to prevent a backflow of lubricant when branching the air flow and releasing the air on the outlet side of the regulator.

Page 34





- · Air Filter + Regulator (AC20B-B to AC60B-B)
- · Air Filter + Mist Separator + Regulator (AC20C-B to AC60C-B)
- · Filter Regulator + Mist Separator (AC20D-B to AC60D-B)

#### Pressure relief 3 port valve Page 36

With the use of a pressure relief 3 port valve, pressure left in the line can be easily exhausted.

Pressure relief 3 port valve




- · Air Filter + Regulator + Lubricator (AC20-B to AC50-B) series
  - · Filter Regulator + Lubricator (AC20A-B to AC50A-B)
  - · Air Filter + Regulator (AC20B-B to AC50B-B)
  - · Air Filter + Mist Separator + Regulator (AC20C-B to AC40C-B)
- pplicable · Filter Regulator + Mist Separator (AC20D-B to AC40D-B)


#### **Piping adapter**




A piping adapter allows installation/removal of the component without removing the piping and thus makes maintenance easier.




\* Needs to be ordered separately.











#### Made-to-Order List



#### **Related Product**



**SMC** 

AR

A


AV

# Air Combination Air Filter + Regulator + Lubricator AC10-A



#### How to Order

#### Refer to page 9 for size 20 to 60.



• Option/Semi-standard: Select one each for a to h. · Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AC10-M5CG-T-12NR-A

				Symbol	Description
		a	Float type auto drain	_	Without auto drain
	c	a	Float type auto drain	<b>C</b> *1	N.C. (Normally closed) Drain port is closed when pressure is not applied.
0	Option			+	
· · · ·	0	b	Pressure gauge	_	Without pressure gauge
		D	Flessule gauge	<b>G</b> *2	Round type pressure gauge (without limit indicator)
				+	
2		٨.+	tachment (T-spacer) *3	—	Without attachment
9		Au	lachiment (1-spacer)	Т	Mounting position: AF+ <b>T</b> +AR+AL
				+	
			Set pressure *4	—	0.05 to 0.7 MPa setting
		С	Set pressure	1	0.02 to 0.2 MPa setting
				+	
				_	Polycarbonate bowl
		d	Bowl *5	2	Metal bowl
				6	Nylon bowl
				+	
	ard	е	Lubricator lubricant		Without drain cock
6	and	e	exhaust port	3	Lubricator with drain cock
9	Semi-standard			+	
	Ser	f	Exhaust mechanism		Relieving type
		<b>'</b>	Exhaust mechanism	Ν	Non-relieving type
				+	
			Flow direction	_	Flow direction: Left to right
		g	Flow direction	R	Flow direction: Right to left
				+	
		h	Drosouro unit	-	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa
		h	Pressure unit	Z	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F
*1 Whe	en pre		s not applied, condensate which doe		Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F

\*1 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended. \*2 A 1.0 MPa pressure gauge will be fitted. It is not assembled and supplied loose at the time of shipment.

\*3 The bracket position varies depending on the T-spacer mounting.

\*4 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

\*5 Refer to chemical data on page 46 for chemical resistance of the bowl.



#### **Standard Specifications**

	Air Filter [AF]	AF10-A
Component	Regulator [AR]	AR10-A
	Lubricator [AL]	AL10-A
Port size		M5 x 0.8
Pressure gauge por	rt size [AR]	1/16
Fluid		Air
Ambient and fluid to	emperature	-5 to 60 °C (with no freezing)
Proof pressure		1.5 MPa
Maximum operating	) pressure	1.0 MPa
Set pressure range	[AR]	0.05 to 0.7 MPa
Nominal filtration ra	ating [AF]	5 μm
Recommended lubr	icant [AL]	Class 1 turbine oil (ISO VG32)
Bowl material [AF/A	\L]	Polycarbonate
Construction [AR]		Relieving type
Weight [kg]		0.27

## ▲ Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### Selection

# 

- 1. When releasing air at the intermediate position using a T-spacer on the inlet side of the lubricator, lubricant may back flow. Therefore, releasing air that does not contain traces of lubricant is not possible.
- **2.** An F.R.L. unit shipped from the plant has its model number labelled. However, components that are combined together during the distribution process do not have a label on them.

AR


A

A₹

# Air Combination Air Filter + Regulator + Lubricator AC20-B to AC60-B

#### How to Order

#### Refer to page 7 for size 10.



 Option/Semi-standard: Select one each for a to m.
 Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AC30-F03DE1-KSTV-136NR-B

$\left[\right]$	<u> </u>	_							0			
				Symbol	Description			В	ody siz	e		
						20	25	30	40	50	55	60
				—	Rc							
2		Pipe	e thread type	<b>N</b> *1	NPT							
				<b>F</b> *2	G							
				+								
				01	1/8		—	—		—	_	—
				02	1/4					—	—	—
8			Port size	03	3/8					—		—
			011 0120	04	1/2		—			—		—
				06	3/4		—	_			_	—
				10	1		—	—				
				+		-	-	-	6	-	6	
			Float type	_	Without auto drain		•	•	•	•	•	
		а	auto drain	<b>C</b> *4	N.C. (Normally closed) Drain port is closed when pressure is not applied.		٠	•		•	•	
				<b>D</b> *5	N.O. (Normally open) Drain port is open when pressure is not applied.							
				+				-			-	
	۳ *				Without pressure gauge		•	•		•		
4	tion		Pressure gauge *6	E	Square embedded type pressure gauge (with limit indicator)		•	•		•	•	•
	Option		gauge	G	Round type pressure gauge (with limit indicator)		•	•		•	•	
		b		M	Round type pressure gauge (with colour zone)		•	•		•		
			Digital	E1	Output: NPN output, Electrical entry: Wiring bottom entry		•	•				
			pressure	E2	Output: NPN output, Electrical entry: Wiring top entry		•	•				
			switch	E3 E4	Output: PNP output, Electrical entry: Wiring bottom entry		•			•		•
				+	Output: PNP output, Electrical entry: Wiring top entry							
				т —	Without attachment							
		С	Check valve	K	Mounting position: AF+AR+K+AL			•	•*7		_	
				+								
			Pressure	·	Without attachment							
	ent	d	switch	<b>S</b> *8	Mounting position: AF+AR+ <b>S</b> +AL							
6	Attachment			+			•		-	•		
	ttac		_	_	Without attachment							
	Ā	е	T-spacer	<b>T</b> *8	Mounting position: AF+ <b>T</b> +AR+AL							
				+	51				I			<u> </u>
			Pressure relief	—	Without attachment							
		f	3 port valve	V	Mounting position: AF+AR+AL+V						_	—
				+								
		~	Set	—	0.05 to 0.85 MPa setting							
		g	pressure *9	1	0.02 to 0.2 MPa setting							
	ard			+								
	Semi-standard				Polycarbonate bowl							
6	-sta			2	Metal bowl							
	-imi	h	Bowl *10	6	Nylon bowl		•			•		
	Š		20.11	8	Metal bowl with level gauge		•					
				C	With bowl guard	•	*11	*11	*11	*11	*11	*11
				6C	With bowl guard (Nylon bowl)		*12	*12	*12	*12	*12	*12

# Air Combination AC20-B to AC60-B Series



AC40-B

AC

AF + AR + AL

AW+AL

AF+AR

AF+AFM+AR

AW + AFM

Attachment

AF

AFD

AFM / .

AR

A

AV

/		<u> </u>	_	Cumb -	Description				0			
				Symbol	Description				ody siz		-	
						20	25	30	40	50	55	60
				—	With drain cock							
			Air filter	<b>J</b> * <sup>14</sup>	Drain guide 1/8		—	—	—	_	—	—
			drain port *13	J	Drain guide 1/4	_						
				<b>W</b> *15	Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)	_						
				+		L						
			Lubricator lubricant	—	Without drain cock							
	g	1	exhaust port	<b>3</b> *16	Lubricator with drain cock							
	Semi-standard			+			•	•				
6	stai	k	Exhaust	—	Relieving type							
-	ц.	ĸ	mechanism	Ν	Non-relieving type							
	Se			+			•	•				
			Flow direction	—	Flow direction: Left to right							
			Flow direction	R	Flow direction: Right to left							
				+			•	•				
				—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa							
		m	Pressure unit	<b>Z</b> *17	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	○*19	O*19	O*19	O*19	O*19	O*19	○*19
				<b>ZA</b> *18	Digital pressure switch: With unit selection function	$\triangle^{*20}$						
*1 [	)rain (	abiur	is NPT 1/8 (applicab	le to the A	C20-B) and pressure gauge will be fitted for standard (0.85 MPa)	*15 T	he com	bination	of met	al bowl.	2 and	8 is not

- \*1 Drain guide is NPT 1/8 (applicable to the AC20-B) and NPT 1/4 (applicable to the AC25-B to AC60-B). The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AC25-B to AC60-B).
- \*2 Drain guide is G 1/8 (applicable to the AC20-B) and G 1/4 (applicable to the AC25-B to AC60-B).
- \*3 Options G, M are not assembled and supplied loose at the time of shipment.
- \*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- \*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- \*6 When the pressure gauge is attached, a 1.0 MPa

pressure gauge will be fitted for standard (0.85 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type. \*7 Not available with piping port size: 06

- \*8 The bracket position varies depending on the T-spacer
- or pressure switch mounting. \*9 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- \*10 Refer to chemical data on page 46 for chemical resistance of the bowl.
- \*11 A bowl guard is provided as standard equipment (polycarbonate).
- \*12 A bowl guard is provided as standard equipment (nylon).
- \*13 The combination of float type auto drain: C and D is not available.
- \*14 Without a valve function

- \*15 The combination of metal bowl: 2 and 8 is not available.
  \*16 When choosing with W: Filter drain port, the drain
- cock of a lubricator will be with barb fittings. \*17 For pipe thread type: NPT.
  - Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially.
- \*18 For options: E1, E2, E3, E4.
- \*19 O: For pipe thread type: NPT only
- \*20  $\triangle$ : Select with options: E1, E2, E3, E4.

#### **Standard Specifications**

1	Nodel	AC20-B	AC25-B	AC30-B	AC40-B	AC40-06-B	AC50-B	AC55-B	AC60-B		
	Air Filter [AF]	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A	AF60-A		
Component	Regulator [AR]	AR20-B	AR25-B	AR30-B	AR40-B	AR40-06-B	AR50-B	AR50-B	AR60-B		
	Lubricator [AL]	AL20-A	AL30-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A	AL60-A		
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1	1		
Pressure gau	ge port size [AR] *1	1/8									
Fluid		Air									
Ambient and	fluid temperature *2				-5 to 60 °C (wi	th no freezing)					
Proof pressu	re				1.5	MPa					
Maximum op	erating pressure	1.0 MPa									
Set pressure	range [AR]	0.05 to 0.85 MPa									
Nominal filtra	ation rating [AF]	5 μm									
Recommende	ed lubricant [AL]			(	Class 1 turbine	oil (ISO VG32	)				
Bowl materia	I [AF/AL]				Polyca	rbonate					
Bowl guard [	AF/AL]	Semi-standard (Steel) Standard (Polycarbonate)									
Construction	[AR]				Relievi	ng type					
Weight [kg]		0.39	0.70	0.78	1.39	1.53	3.43	3.71	3.76		


\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch.


\*2 -5 to 50 °C for the products with the digital pressure switch.




# AC10-A Series AC20-B to AC60-B Series

#### Flow Rate Characteristics (Representative values)












Rc 1/4

Condition: Inlet pressure of 0.7 MPa



00 2000 4000 6000 8000 10000 Flow rate [l/min (ANR)]





4000


Flow rate [l/min (ANR)]


6000


10000

Conditions: Inlet pressure of 0.7 MPa, Outlet pressure of 0.2 MPa, Flow rate 20 l/min (ANR)

8000









11


# Air Combination AC10-A Series Air Combination AC20-B to AC60-B Series

#### Pressure Characteristics (Representative values)

Conditions: Inlet pressure of 0.7 MPa, Outlet pressure of 0.2 MPa, Flow rate 20 l/min (ANR)







## ▲ Specific Product Precautions

I Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### Mounting/Adjustment

# \land Caution

1. A knob cover is available to prevent careless operation of the knob. Refer to page 112 for details.

Piping

# \land Warning

1. When mounting a check valve, make sure the arrow (IN side) points in the correct direction of air flow.

#### Air Supply

## A Caution

1. Use an air filter with 5  $\mu$ m or less filtration rating on the inlet side of the valve to avoid any damage to the seat caused by dust when mounting a pressure relief 3 port valve on the inlet side.

#### Mounting/Adjustment

# \land Caution

1. When the bowl is installed on the air filter, filter regulator, lubricator, mist separator, or micro mist separator (AC25-B to AC60-B), install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



#### Selection

## \land Warning

- 1. Float type auto drain
  - Operate under the following conditions to avoid malfunction. <N.O. type>
  - · Operating compressor: 0.75 kW (100 l/min (ANR)) or more. When using 2 or more auto drains, multiply the value above by the number of auto drains to find the capacity of the compressors you will need.

For example, when using 2 auto drains, 1.5 kW (200 l/min (ANR)) of the compressor capacity is required.

- · Operating pressure: 0.1 MPa or more
- <N.C. type>

· Operating pressure for AD27-A: 0.1 MPa or more

Operating pressure for AD37-A/AD47-A: 0.15 MPa or more

2. Use a regulator or filter regulator with backflow function when mounting a pressure release 3 port valve on the inlet side to ensure the release of the residual pressure. Otherwise, residual pressure will not be fully released.

## A Caution

1. When releasing air at the intermediate position using a T-spacer on the inlet side of the lubricator, lubricant may back flow. Therefore, releasing air that does not contain traces of lubricant is not possible.


To release air that does not contain traces of lubricant, use a check valve (AKM series) on the inlet side of the lubricator to prevent a backflow of the lubricant.


- 2. If a pressure relief 3 port valve is mounted on the inlet side of the lubricator, causing a backflow of air, it can result in a backflow of oil or damage to internal parts. Do not use it in this fashion.
- 3. An F.R.L. unit shipped from the plant has its model number labeled. However, components that are combined together during the distribution process do not have a label on them.

# AC10-A Series AC20-B to AC60-B Series


#### Dimensions


#### AC10-A







#### AC20-B






#### AC25-B to AC60-B





# Air Combination AC10-A Series Air Combination AC20-B to AC60-B Series




**SMC** 

\*1 For the AC20-B only, the position of the pressure gauge is above the centre of the piping.


14

# **Air Combination** Filter Regulator + Lubricator AC10A-A



#### How to Order

#### Refer to page 17 for size 20 to 60.



• Option/Semi-standard: Select one each for a to h. • Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AC10-M5CG-T-12NR-A

		Symbol	Description
	Floot type quite drain		Without auto drain
a	Float type auto drain	<b>C</b> *1	N.C. (Normally closed) Drain port is closed when pressure is not applied.
		+	
h	Pressure dauge	_	Without pressure gauge
	T Tessure gauge	<b>G</b> *2	Round type pressure gauge (without limit indicator)
		+	
Δ	ttachment (T-snacer) *3		Without attachment
		Т	Mounting position: AW+ <b>T</b> +AL
		+	
	Set pressure *4	_	0.05 to 0.7 MPa setting
	Set pressure	1	0.02 to 0.2 MPa setting
		+	
		—	Polycarbonate bowl
d	Bowl *5	2	Metal bowl
		6	Nylon bowl
		+	
	Lubricator lubricant	—	Without drain cock
e	exhaust port	3	Lubricator with drain cock
		+	
4	Expount machanism	—	Relieving type
11 <b>'</b>	Exhaust mechanism	N	Non-relieving type
		+	
	Elow direction	-	Flow direction: Left to right
g		R	Flow direction: Right to left
		+	
h		—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa
n	Pressure unit	Z	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F
	c	b       Pressure gauge         Attachment (T-spacer) *3         c       Set pressure *4         d       Bowl *5         e       Lubricator lubricant exhaust port         f       Exhaust mechanism         g       Flow direction	a Float type auto drain $-$ C *1 C *1 + b Pressure gauge $-$ G *2 + Attachment (T-spacer) *3 $-$ T + Attachment (T-spacer) *3 $-$ T + + C Set pressure *4 $-$ C Set p

\*1 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended. \*2 A 1.0 MPa pressure gauge will be fitted. It is not assembled and supplied loose at the time of shipment.

\*3 The bracket position varies depending on the T-spacer mounting.

\*4 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

\*5 Refer to chemical data on page 46 for chemical resistance of the bowl.



AC

#### AC10A-A

#### **Standard Specifications**

Component	Filter Regulator [AW]	AW10-A				
Component	Lubricator [AL]	AL10-A				
Port size		M5 x 0.8				
Pressure gauge por	t size [AW]	1/16				
Fluid		Air				
Ambient and fluid te	mperature	-5 to 60 °C (with no freezing)				
Proof pressure		1.5 MPa				
Maximum operating	pressure	1.0 MPa				
Set pressure range	[AW]	0.05 to 0.7 MPa				
Nominal filtration ra	ting [AW]	5 µm				
Recommended lubri	cant [AL]	Class 1 turbine oil (ISO VG32)				
Bowl material [AW/A	\L]	Polycarbonate				
Construction [AW]		Relieving type				
Weight [kg]		0.2				

# Air Combination Filter Regulator + Lubricator AC20A-B to AC60A-B

-B


How to Order

#### Refer to page 15 for size 10.

 Option/Semi-standard: Select one each for a to I.
 Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AC30A-F03DE1-KSV-136NR-B

$\left \right $	<u> </u>							0			
				Symbol	Description			Body size			
						20	30	40	50	60	
					Rc						
2		Pipe	thread type	<b>N</b> *1	NPT						
				<b>F</b> *2	G						
				+							
				01	1/8		—	_			
				02	1/4		•	•			
8			Port size	03	3/8		•	•			
				04	1/2	<u> </u>	—	•	_		
				06 10	3/4		—	•	•	•	
				+	1		—	_	•	•	
				· _	Without auto drain				•		
		а	Float type	<b>C</b> *4	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•	•	•	
			auto drain	<b>D</b> *5	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•	•	•	
				+	· · · · · · · · · · · · · · · · · · ·	L					
	es es			_	Without pressure gauge						
	<sup>*</sup> u		Pressure	E	Square embedded type pressure gauge (with limit indicator)						
4	Option		gauge *6	G	Round type pressure gauge (with limit indicator)						
		b		М	Round type pressure gauge (with colour zone)						
			Digital	E1	Output: NPN output, Electrical entry: Wiring bottom entry						
			pressure	E2	Output: NPN output, Electrical entry: Wiring top entry					•	
			switch	E3	Output: PNP output, Electrical entry: Wiring bottom entry			•		•	
				E4	Output: PNP output, Electrical entry: Wiring top entry						
				+				-	-	_	
		с	Check valve	—	Without attachment		•	•	•	•	
				К +	Mounting position: AW+K+AL			●*7	_	_	
	Attachment		Pressure	т —	Without attachment				•		
6	Ichr	d	switch	<b>S</b> *8	Mounting position: AW+S+AL						
	Atta		0	+		•		•	•	•	
			Pressure relief		Without attachment						
		е	3 port valve	V	Mounting position: AW+AL+V					_	
				+		L					
		f	Set	—	0.05 to 0.85 MPa setting						
		1	pressure *9	1	0.02 to 0.2 MPa setting						
				+							
				_	Polycarbonate bowl	•		•	•	•	
	p			2	Metal bowl		•	•	•	•	
	Semi-standard	g	Bowl *10	6	Nylon bowl		•	•	•	•	
6	star			8	Metal bowl with level gauge		• 11	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	• • 11	
	ц.			C 6C	With bowl guard With bowl guard (Nylon bowl)		*11 *12	*11 *12	*11 *12	*11	
	Se			6C +	with bowl guara (Nyion bowl)		*12	*12	*12	*12	
				+	With drain cock						
			Filter regulator		Drain guide 1/8			_			
		h	drain port *13	<b>J</b> *14	Drain guide 1/8	_	•	•	•	•	
				<b>W</b> *15	-		•	•	•	•	
				••		L	-	-	-	-	

# Air Combination AC20A-B to AC60A-B Series



			_	0	Description			0		
				Symbol	Description		E	Body size		
						20	30	40	50	60
		:	Lubricator lubricant	_	Without drain cock					•
			exhaust port	<b>3</b> *16	Lubricator with drain cock					
				+						
	ard	:	Exhaust		Relieving type					
	dar	1	mechanism	Ν	Non-relieving type					
6	emi-standard			+						
0	ii-st	k	Flow direction		Flow direction: Left to right		•	•		
	em	n	Flow direction	R	Flow direction: Right to left					
	S			+						
				—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa					
		1	Pressure unit	<b>Z</b> *17	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O* <sup>19</sup>	O* <sup>19</sup>	○*19	O*19	O*19
				<b>ZA</b> *18	Digital pressure switch: With unit selection function	$\triangle^{*20}$	$\triangle^{*20}$	$\triangle^{*20}$	$\triangle^{*20}$	$\triangle^{*20}$
	) and in	auido	in NDT 1/9 (applied	bla ta tha	AC20A P) pressure gauge will be fitted for standard (0.95 MDa)	#15 Tho	ombinatio	of motol	hawli 2 an	d Q io pot

\*1 Drain guide is NPT 1/8 (applicable to the AC20A-B) and NPT 1/4 (applicable to the AC30A-B to AC60A-B). The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AC30A-B to AC60A-B).

\*2 Drain guide is G 1/8 (applicable to the AC20A-B) and G 1/4 (applicable to the AC30A-B to AC60A-B).

\*3 Options G, M are not assembled and supplied loose at the time of shipment.

- \*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- \*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- \*6 When the pressure gauge is attached, a 1.0 MPa

- pressure gauge will be fitted for standard (0.85 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Not available with piping port size: 06 \*7
- \*8 The bracket position varies depending on the pressure switch mounting.
- \*9 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range
- \*10 Refer to chemical data on page 46 for chemical resistance of the bowl.
- \*11 A bowl guard is provided as standard equipment (polycarbonate) \*12 A bowl guard is provided as standard equipment
- (nylon). \*13 The combination of float type auto drain: C and D is
- not available
- \*14 Without a valve function

\*15 The combination of metal bowl: 2 and 8 is not available

 $\ast 16\,$  When choosing with W: Filter drain port, the drain cock of a lubricator will be with barb fittings.

\*17 For pipe thread type: NPT.

Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially.

\*18 For options: E1, E2, E3, E4.

- \*19 O: For pipe thread type: NPT only
- \*20  $\triangle$ : Select with options: E1, E2, E3, E4.

#### Standard Specifications

1	Vodel	AC20A-B	AC30A-B	AC40A-B	AC40A-06-B	AC50A-B	AC60A-B	AF	
Component	Filter Regulator [AW]	AW20-B	AW30-B	AW40-B	AW40-06-B	AW60-B	AW60-B	4	
Component	Lubricator [AL]	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A		
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1	AFD	
Pressure gauge	ge port size [AW] *1	1/8							
Fluid				A	vir			N N	
Ambient and	fluid temperature *2			-5 to 60 °C (w	ith no freezing)			AFM	
Proof pressure 1.5 MF									
Maximum op	erating pressure	1.0 MPa							
Set pressure	range [AW]	0.05 to 0.85 MPa							
Nominal filtra	ation rating [AW]	5 μm							
Recommende	ed lubricant [AL]			Class 1 turbine	oil (ISO VG32)				
Bowl materia	I [AW/AL]			Polyca	rbonate				
Bowl guard [	AW/AL]	Semi-standard (Steel)		Sta	ndard (Polycarbona	ate)			
Construction	[AW]			Relievi	ng type			<b>A</b>	
Weight [kg]		0.33	0.63	1.15	1.25	3.21	3.36	1	

**SMC** 

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch.

\*2 -5 to 50 °C for the products with the digital pressure switch.

AV

AC


AF+AR+AL

AW+AL


# AC10A-A Series AC20A-B to AC60A-B Series


#### Dimensions


#### AC10A-A





#### AC20A-B















# Air Combination AC10A-A Series Air Combination AC20A-B to AC60A-B Series




AV

# Air Combination Air Filter + Regulator **AC10B-A**



#### How to Order

#### Refer to page 23 for size 20 to 60.



Option/Semi-standard: Select one each for a to g.
Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
Example) AC10B-M5CG-T-12NR-A

				Symbol	Description
		a	Float type auto drain		Without auto drain
	c	a	Float type auto drain	<b>C</b> *1	N.C. (Normally closed) Drain port is closed when pressure is not applied.
0	Option			+	
	0	b	Pressure gauge	_	Without pressure gauge
			T Tessure gauge	<b>G</b> *2	Round type pressure gauge (without limit indicator)
				+	
2		Δı	ttachment (T-spacer) *3	—	Without attachment
2			laciment (1-spacer)	Т	Mounting position: AF+ <b>T</b> +AR
				+	
		с	Set pressure *4	_	0.05 to 0.7 MPa setting
			Set pressure	1	0.02 to 0.2 MPa setting
				+	
				_	Polycarbonate bowl
		d	Bowl *5	2	Metal bowl
	q			6	Nylon bowl
	ndar			+	
3	Semi-standard	е	Exhaust mechanism	—	Relieving type
	emi	C		Ν	Non-relieving type
	۰ f			+	
			Flow direction	_	Flow direction: Left to right
				R	Flow direction: Right to left
				+	
		a	Pressure unit	—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa
	g			Z	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, $^\circ \! F$

\*1 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.

Releasing the residual condensate before ending operations for the day is recommended. \*2 A 1.0 MPa pressure gauge will be fitted. It is not assembled and supplied loose at the time of shipment.

 \*2 A 1.0 MPa pressure gauge will be litted. It is not assembled and supp \*3 The bracket position varies depending on the T-spacer mounting.

\*4 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

\*5 Refer to chemical data on page 46 for chemical resistance of the bowl.



AC10B-A

#### **Standard Specifications**

Component	Air Filter [AF]	AF10-A
Component	Regulator [AR]	AR10-A
Port size		M5 x 0.8
Pressure gauge por	t size [AR]	1/16
Fluid		Air
Ambient and fluid te	emperature	-5 to 60 °C (with no freezing)
Proof pressure		1.5 MPa
Maximum operating	pressure	1.0 MPa
Set pressure range	[AR]	0.05 to 0.7 MPa
Nominal filtration ra	ting [AF]	5 μm
Bowl material [AF]		Polycarbonate
Construction [AR]		Relieving type
Weight [kg]		0.16

AW

# Air Combination Air Filter + Regulator AC20B-B to AC60B-B

How to Order

#### Refer to page 21 for size 10.

AC 30 B - 03 DE - - - B 0 03 DE - - - B 0 05 6

$\left \right $	<u> </u>	_							0			
				Symbol	Description			B	ody siz	ze	_	
						20	25	30	40	50	55	60
				_	Rc							
2		Pipe	e thread type	<b>N</b> *1	NPT		•	•	•	•	•	•
			51	<b>F</b> *2	G							
				+							I	
				01	1/8			_	_	_	_	
				02	1/4					_	_	
				03	3/8	_				_	_	—
8			Port size	04	1/2	_		_		_	_	
				06	3/4	_		_			_	—
				10	1	_	<u> </u>	-	_			
				+				1	1		1	
					Without auto drain							
		а	Float type auto drain	<b>C</b> *4	N.C. (Normally closed) Drain port is closed when pressure is not applied.							
			autouran	<b>D</b> *5	N.O. (Normally open) Drain port is open when pressure is not applied.	-						
				+								
	es *			—	Without pressure gauge							
			Pressure	E	Square embedded type pressure gauge (with limit indicator)							
4	Option		gauge *6	G	Round type pressure gauge (with limit indicator)							
	0	h		М	Round type pressure gauge (with colour zone)							
		b		E1	Output: NPN output, Electrical entry: Wiring bottom entry							
			Digital	E2	Output: NPN output, Electrical entry: Wiring top entry							
			pressure switch	E3	Output: PNP output, Electrical entry: Wiring bottom entry							
			Switch	E4	Output: PNP output, Electrical entry: Wiring top entry							
				+								
			Pressure	—	Without attachment							
	Ħ	С	switch	<b>S</b> *7	Mounting position: AF+ <b>S</b> +AR							
	ner		T-spacer	<b>T</b> *7	Mounting position: AF+ <b>T</b> +AR							
6	Attachment			+								
	Atta		Pressure relief	—	Without attachment							
		d	3 port valve	V	Mounting position: AF+AR+V							
				V1*8	Mounting position: <b>V</b> +AF+AR⊡K							—
				+					1			,
		е	Set		0.05 to 0.85 MPa setting							
		-	pressure *9	1	0.02 to 0.2 MPa setting							
				+				_	-			
				_	Polycarbonate bowl		•	•	•	•		•
	p			2	Metal bowl		•	•				
	Idai	f	Bowl *10	6	Nylon bowl		•	•				
6	Semi-standard			8	Metal bowl with level gauge	-	•	•		•		
				C	With bowl guard		*11	*11	*11	*11	*11	*11
	Ser			6C	With bowl guard (Nylon bowl)		*12	*12	*12	*12	*12	*12
				+	MPH, during a st			6				
					With drain cock		•					
		g	Air filter	<b>J</b> *14	Drain guide 1/8		-	-		-	_	_
			drain port *13	10.0045	Drain guide 1/4	-	•	•		•		•
				<b>W</b> *15	Drain cock with barb fitting: For $\emptyset$ 6 x $\emptyset$ 4 nylon tube							

# Air Combination AC20B-B to AC60B-B Series



AC20B-B

AC40B-B

	<u> </u>	<u> </u>	_	Symbol	Description	Body size							
	, , , , , , , , , , , , , , , , , , ,					20	25	30	40	<u>50</u>	55	60	
		h	Exhaust	—	Relieving type		٠						
		n	mechanism	N	Non-relieving type								
	Ird			+									
	nda		Flow direction	—	Flow direction: Left to right								
6	Semi-standard	'	Flow direction	R	Flow direction: Right to left								
	, B			+									
	Se			—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa								
		j	Pressure unit	<b>Z</b> *16	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	0*18	0*18	0*18	0*18	O*18	0*18	0*18	
				<b>ZA</b> *17	Digital pressure switch: With unit selection function	$\triangle^{*19}$	$\triangle^{*19}$	$\triangle^{*19}$	$\triangle^{*19}$	∆*19	∆*19	$\triangle^{*19}$	
			is NPT 1/8 (application (applicable to the AC				he comb t availabl		f float typ	pe auto	drain: C	and D is	

- The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AC25B-B to AC60B-B).
- \*2 Drain guide is G 1/8 (applicable to the AC20B-B) and G 1/4 (applicable to the AC25B-B to AC60B-B).
- \*3 Options G, M are not assembled and supplied loose at the time of shipment.
- \*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- \*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- type. 0.4 MPa pressure gauge for 0.2 MPa type.
   \*7 The bracket position varies depending on the T-spacer
- or pressure switch mounting.
- \*8 Make sure that the outlet pressure is released to atmospheric pressure using a pressure gauge.
- \*9 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- \*10 Refer to chemical data on page 46 for chemical resistance of the bowl
- \*11 A bowl guard is provided as standard equipment (polycarbonate).
- \*12 A bowl guard is provided as standard equipment (nylon).

\*14 Without a valve function

\*15 The combination of metal bowl: 2 and 8 is not available.

\*16 For pipe thread type: NPT.

- Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially.
- \*17 For options: E1, E2, E3, E4.
- \*18  $\bigcirc$ : For pipe thread type: NPT only \*19  $\triangle$ : Select with options: E1, E2, E3, E4.

#### **Standard Specifications**

Γ	Vodel	AC20B-B	AC25B-B	AC30B-B	AC40B-B	AC40B-06-B	AC50B-B	AC55B-B	AC60B-B		
Component	Air Filter [AF]	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A	AF60-A		
Component	Regulator [AR]	AR20-B	AR25-B	AR30-B	AR40-B	AR40-06-B	AR50-B	AR50-B	AR60-B		
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1	1		
Pressure gau	ge port size [AR] *1				1	/8					
Fluid					A	.ir					
Ambient and	fluid temperature *2	-5 to 60 °C (with no freezing)									
Proof pressu	re		1.5 MPa								
Maximum op	erating pressure	1.0 MPa									
Set pressure	range [AR]	0.05 to 0.85 MPa									
Nominal filtra	ation rating [AF]	5 μm									
Bowl materia	l [AF]	Polycarbonate									
Bowl guard [	AF]	Semi-standard (Steel)			Stand	lard (Polycarbo	onate)				
Construction	[AR]				Relievi	ng type					
Weight [kg]		0.27	0.45	0.53	0.91	0.99	2.27	2.40	2.45		

**SMC** 

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch. \*2 -5 to 50 °C for the products with the digital pressure switch.

AF

**AFM / AFD** 

AR

A


AV

AC

# AC10B-A Series AC20B-B to AC60B-B Series


#### Dimensions

#### AC10B-A




# IN (Pressure gauge port size)


Δ




#### AC20B-B










# Air Combination AC10B-A Series Air Combination AC20B-B to AC60B-B Series



**SMC** 

\*1 For the AC20B-B only, the position of the pressure gauge is above the centre of the piping

26

# Air Combination Air Filter + Mist Separator + Regulator AC20C-B to AC40C-B


#### How to Order

AC 30 C - Otion/Semi-standard: Select one each for a to j. Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AC30C-F03DE1-SV-16NR-B

	<u> </u>	_					0		
				Symbol	Description		Body	size	
						20	25	30	40
				_	Rc			•	•
2		Pipe	e thread type	<b>N</b> *1	NPT	•	•	•	•
9		թ.		<b>F</b> *2	G	•	•	•	•
				+	<u> </u>	•		•	•
				01	1/8			_	_
				02	1/4	•			•
8			Port size	03	3/8	_	•		•
				04	1/2	_		_	•
				06	3/4	_	_	_	
				+			1		
			-	—	Without auto drain				•
		a	Float type	<b>C</b> *4	N.C. (Normally closed) Drain port is closed when pressure is not applied.				•
			auto drain	<b>D</b> *5	N.O. (Normally open) Drain port is open when pressure is not applied.	_			٠
				+					
	° *			—	Without pressure gauge				•
	sul,		Pressure	E	Square embedded type pressure gauge (with limit indicator)				
4	Option <sup>3</sup>		gauge *6	G	Round type pressure gauge (with limit indicator)				
	0	L		М	Round type pressure gauge (with colour zone)			•	
		b		E1	Output: NPN output, Electrical entry: Wiring bottom entry				
			Digital pressure	E2	Output: NPN output, Electrical entry: Wiring top entry			•	٠
			switch	E3	Output: PNP output, Electrical entry: Wiring bottom entry			•	٠
			Switch	E4	Output: PNP output, Electrical entry: Wiring top entry			•	٠
				+					
			Pressure	_	Without attachment			•	٠
	t	С	switch	<b>S</b> *7	Mounting position: AF+AFM+ <b>S</b> +AR				•
	ner		T-spacer	<b>T</b> *7	Mounting position: AF+AFM+ <b>T</b> +AR				
6	Attachment			+					
	Atta		Pressure relief		Without attachment		•		•
		d	3 port valve	V	Mounting position: AF+AFM+AR+V				•
				V1*8	Mounting position: V+AF+AFM+AR□K				•
				+					
		е	Set		0.05 to 0.85 MPa setting	•	•	•	•
			pressure *9	1	0.02 to 0.2 MPa setting				
				+	Delivered exerts haved				-
					Polycarbonate bowl			•	
				2	Metal bowl	•	•	•	•
	-	f	Bowl *10	6	Nylon bowl	•	•	•	•
	larc			8	Metal bowl with level gauge		• *11	• *11	<b>•</b> *11
	and			C 6C	With bowl guard			*12	*12
6	Semi-standard			- 0C +	With bowl guard (Nylon bowl)				
				- T	With drain cock				•
			Air filter		Drain guide 1/8	•		-	
		g	Mist separator	<b>J</b> *14	Drain guide 1/4	_	•	•	•
			drain port *13	<b>W</b> *15	Drain cock with barb fitting: For $\emptyset$ 6 x $\emptyset$ 4 nylon tube		•	•	•
				+			-	-	-
			Exhaust	T	Relieving type				•
		h	mechanism	 N	Non-relieving type			•	
						-		-	-



# Air Combination AC20C-B to AC40C-B Series



AC20C-B

#### AC40C-B

AC

AF+AR+AL

AW+AL

AF+AR

AF+AFM+AR

Attachment || AW+AFM

AF

**AFM / AFD** 

AR

A

AV

/	/	/				0						
	Syml			Symbol	Description	Body size						
						20	25	30	40			
		:	Flow direction		Flow direction: Left to right		•	•				
	standard	1	Flow direction	R	Flow direction: Right to left							
6	an			+								
6				—	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa	•			•			
	Semi	j	Pressure unit	<b>Z</b> *16	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	○*18	○*18	○*18	○*18			
	0			<b>ZA</b> *17	Digital pressure switch: With unit selection function	$\triangle^{*19}$	△*19	$\triangle^{*19}$	$\triangle^{*19}$			

- \*1 Drain guide is NPT 1/8 (applicable to the AC20C-B) and NPT 1/4 (applicable to the AC25C-B to AC40C-B). The auto drain port comes with Ø 3 / 8 " One-touch fitting (applicable to the AC25C-B to AC40C-B).
- \*2 Drain guide is G 1/8 (applicable to the AC20C-B) and G 1/4 (applicable to the AC25C-B to AC40C-B).
- \*3 Options G, M are not assembled and supplied loose at the time of shipment.
- \*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- \*5 If the compressor is small (0.75 kW, discharge flow is less than 1 0 0 l/min (ANR)), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- \*6 When the pressure gauge is attached, a 1 . 0 MPa pressure gauge will be fitted for standard (0.85 MPa) type.
- 0.4 MPa pressure gauge for 0.2 MPa type. \*7 The bracket position varies depending on the
- T-spacer or pressure switch mounting. \*8 Make sure that the outlet pressure is released to atmospheric pressure using a pressure gauge.
- \*9 Pressure can be set higher than the specification pressure in some cases, but use pressure within the
- specification range. \*10 Refer to chemical data on page 4 6 for chemical
- resistance of the bowl. \*11 A bowl guard is provided as standard equipment
- (polycarbonate). \*12 A bowl guard is provided as standard equipment
- (nylon).

- \*13 The combination of float type auto drain: C and D is not available.
- \*14 Without a valve function
- \*15 The combination of metal bowl: 2 and 8 is not available.
- \*16 For pipe thread type: NPT.
- Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially. \*17 For options: E1, E2, E3, E4.
- \*18 O: For pipe thread type: NPT only
- \*19  $\triangle$ : Select with options: E1, E2, E3, E4.

#### Standard Specifications

	specifications					1				
	Model	AC20C-B	AC25C-B	AC30C-B	AC40C-B	AC40C-06-B				
	Air Filter [AF]	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A				
Component	Mist Separator [AFM]	AFM20-A	AFM30-A	AFM30-A	AFM40-A	AFM40-06-A				
	Regulator [AR]	AR20-B	AR25-B	AR30-B	AR40-B	AR40-06-B				
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4				
Pressure gau	uge port size [AR] *1			1/8						
Fluid				Air						
Ambient and	I fluid temperature *2	-5 to 60 °C (with no freezing)								
Proof pressu	re			1.5 MPa						
Maximum op	perating pressure	1.0 MPa								
Set pressure	range [AR]	0.05 to 0.85 MPa								
Nominal filtra	ation rating [AF/AFM]	AF: 5 μm, AFM: 0.3 μm (99.9 % filtered particle size)								
Rated flow [I/	/min(ANR)] [AFM] *3	200	450	450	1100	1100				
Outlet side oil m	hist concentration [AFM] *4 *5		Max.1	.0 mg/m³ (ANR) (≈0.8	3 ppm)					
Bowl materia	I [AF/AFM]			Polycarbonate						
Bowl guard [	AF/AFM]	Semi-standard (Steel)		Standard (Pc	olycarbonate)					
Construction	1 [AR]			Relieving type						
Weight [kg]		0.38	0.69	0.77	1.39	1.53				

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch.

\*2 -5 to 50 °C for the products with the digital pressure switch.

\*3 Conditions: Mist separator inlet pressure: 0.7 MPa; The rated flow varies depending on the inlet pressure.

Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.

\*4 When the compressor oil mist discharge concentration is 30 mg/m<sup>3</sup> (ANR).

\*5 Bowl seal and other O-rings are slightly lubricated.

**SMC** 

# AC20C-B to AC40C-B Series

#### Dimensions AC20C-B AC25C-B to AC40C-06-B Α Α F Ν М F Ν .1 S ≌ S **m** ð C OUT OUT IN IN Ò ő ð m U. U m ŕΠ TT. Ē 2 x **P**1 fo maintenance 1 , (Port size) Clearance Ð 9 Drain Drain 2 x **P**1 P<sub>2</sub> Ċ Е Clearance for maintenance (Port size) (Pressure gauge port size) P<sub>2</sub> G Drain Drain (Pressure gauge port size) Option Square embedded type pressure gauge Digital pressure switch Round type pressure gauge Round type pressure gauge (with colour zone) J J J I т Dimensions Centre of Centre of Centre of piping piping piping Applicable model AC20C-B AC25C-B to AC40C-06-B With auto drain (N.C.) With drain guide With auto drain (N.O./N.C.) Optional/Semi-standard specifications Metal bowl Metal bowl with drain guide N.O.: Black m N.C.: Grey m m ш B Dimensions Width across M5 x 0.8 ЛП Width across Thread type/Rc, G: Ø 10 One-touch fitting flats 14 1/8flats 14 1/8 Thread type/NPT: Ø 3/8" One-touch fitting AC25C-B to AC40C-06-B Applicable model Drain cock with barb fitting Metal bowl Metal bowl with drain guide Metal bowl with level gauge Metal bowl with level gauge, with drain guide With drain guide Optional/Semi-standard specification m ш B ш B B Dimensions Barb fitting m Width across m Width across Width across applicable 1/4 1/4 1/4 flats 17 flats 17 flats 17 tubing: T0604 Standard specifications Model Bracket mount **P**1 F P<sub>2</sub> В С Ε Α G J Κ V М Ν Q1 $Q_2$ S U R AC20C-B 1/8, 1/4 2 \*1 1/8 126 4 87.6 26.5 41.6 40 28.5 30 43.2 24 33 55 12 35 29 AC25C-B 1/4, 3/8 30 55.1 41 1/8 167.4 115.1 28 50 27.5 0 41 57.2 35 7 14 4 1/4, 3/8 AC30C-B 1/8 167.4 115 1 307 30 55.1 50 29.4 35 41 57.2 35 7 14 4 41 1/4, 3/8, 1/2 AC40C-B 1/8 220.4 147.1 35.8 38.4 72.6 75 33.8 3.5 50 75.2 40 9 18 5 48

				Option	al specifio	cations				Semi-standard specifications								
Model	Square embedded type pressure gauge		Digital pressure switch		Round type pressure gauge		Round type pressure gauge (with colour zone)		With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide			
	н	J	н	J	н	J	Н	J	В	В	В	В	В	В	В			
AC20C-B	□28	29.5	□27.8	40	Ø 37.5	65	Ø 37.5	66	104.9	_	91.4	87.4	93.9	_	_			
AC25C-B	□28	28.5	□27.8	39	Ø 37.5	64	Ø 37.5	65	156.8	123.6	121.9	117.6	122.1	137.6	142.1			
AC30C-B	□28	30.4	□27.8	40.9	Ø 37.5	65.9	Ø 37.5	66.9	156.8	123.6	121.9	117.6	122.1	137.6	142.1			
AC40C-B	□28	34.8	□27.8	45.3	Ø 42.5	71.3	Ø 42.5	71.3	186.9	155.6	153.9	149.6	154.1	169.6	174.1			
AC40C-06-B	□28	34.8	□27.8	45.3	Ø 42.5	71.3	Ø 42.5	71.3	188.9	157.6	155.9	151.6	156.1	171.6	176.1			

**SMC** 

75

33.8

3

50

80.2

40

9

18

5

48

\*1 For the AC20C-B only, the position of the pressure gauge is above the centre of the piping.

AC40C-06-B

3/4

1/8

235.4

149.1

35.8

38.4


77.6

AC
AF+AR+AL
AW+AL
AF+AR
AF+AFM+AR
AW+AFM
Attachment
AF
AFM / AFD
AR
AL
AW

**SMC** 

# Air Combination Filter Regulator + Mist Separator AC20D-B to AC40D-B


#### How to Order



							0	
			<u> </u>	Symbol	Description		Body size	
						20	30	40
					Rc			•
2	F	Pipe	thread type	<b>N</b> *1	NPT	•	•	•
			<b>J</b>	<b>F</b> *2	G	•	•	•
				+				
				01	1/8			_
				02	1/4	•	•	•
8		F	Port size	03	3/8		•	•
				04	1/2	_	_	•
				06	3/4		—	•
				+				
			Float type	_	Without auto drain			٠
		a	auto drain	<b>C</b> *4	N.C. (Normally closed) Drain port is closed when pressure is not applied.			•
				<b>D</b> *5	N.O. (Normally open) Drain port is open when pressure is not applied.			٠
				+				
C	ç.				Without pressure gauge	•	•	•
4	Option		Pressure	E	Square embedded type pressure gauge (with limit indicator)	•	•	•
	bti		gauge *6	G	Round type pressure gauge (with limit indicator)	•	•	•
		b		M	Round type pressure gauge (with colour zone)	•	•	•
			Distic	E1	Output: NPN output, Electrical entry: Wiring bottom entry	•	•	•
			Digital pressure	E2	Output: NPN output, Electrical entry: Wiring top entry	•	•	•
			switch	E3	Output: PNP output, Electrical entry: Wiring bottom entry	•	•	•
				E4	Output: PNP output, Electrical entry: Wiring top entry		•	•
				+				
		c	Pressure		Without attachment	•	•	•
	ent		switch	<b>S</b> *7	Mounting position: AW+S+AFM			•
6	Attachment			+				
	tac		Pressure relief		Without attachment			•
	ē	d	3 port valve	V	Mounting position: AW+AFM+V	•	•	•
			•	V1*8	Mounting position: <b>V</b> +AW□K+AFM		•	•
			-	+				
		e	Set pressure *9		0.05 to 0.85 MPa setting	•	•	•
			pressure	1	0.02 to 0.2 MPa setting			•
	1			+	Delveerbenete beud			
					Polycarbonate bowl			•
				2	Metal bowl	•		
		f	Bowl *10	6 8	Nylon bowl Metal bowl with level gauge		•	•
				° C		_	*11	*11
-	פ			6C	With bowl guard With bowl guard (Nylon bowl)	•	*12	*12
-	nda			+	with bowl guard (Nylon bowl)	•		·12
6	Semi-standard			- <b>T</b>	With drain cock			•
	Ē		Filter regulator		Drain guide 1/8		<b>—</b>	
0	နှို	g	Mist separator	<b>J</b> *14	Drain guide 1/4	_	•	•
			drain port *13	<b>W</b> *15	Drain cock with barb fitting: For Ø 6 x Ø 4 nylon tube		•	•
				+		L	-	•
	1		Exhaust	·	Relieving type			
		h	mechanism	 N	Non-relieving type			
			incontanioni	+		•	-	<b>.</b>
	[			-	Flow direction: Left to right			•
		i	Flow direction	R	Flow direction: Right to left		•	•
						<b>—</b>	-	-

**SMC** 

# Air Combination AC20D-B to AC40D-B Series



1

Body size

30

0\*18

△\*19

\*13 The combination of float type auto drain: C and D is



Attachment

A

# A AV

\*14 Without a valve function  $\ast 15$  The combination of metal bowl: 2 and 8 is not \*16 For pipe thread type: NPT. Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially. \*17 For options: E1, E2, E3, E4. \*18 O: For pipe thread type: NPT only

40

0\*18

△\*19

- \*19 △: Select with options: E1, E2, E3, E4.
- \*11 A bowl guard is provided as standard equipment \*12 A bowl guard is provided as standard equipment

20

O\*18

∆\*19

not available.

available.

#### **Standard Specifications**

operations for the day is recommended.

Pressure unit

NPT 1/4 (applicable to the AC30D-B/AC40D-B).

(applicable to the AC30D-B/AC40D-B)

(applicable to the AC30D-B/AC40D-B).

\*1 Drain guide is NPT 1/8 (applicable to the AC20D-B) and

\*2 Drain guide is G 1/8 (applicable to the AC20D-B) and G 1/4

\*3 Options G, M are not assembled and supplied loose at

\*4 When pressure is not applied, condensate which does

\*5 If the compressor is small (0.75 kW, discharge flow is

less than 100 l/min [ANR]), air leakage from the drain

cock may occur during start of operations. N.C. type is

not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending

The auto drain port comes with Ø 3/8" One-touch fitting

-standar

i

the time of shipment.

recommended.

6

Symbol

**Z**\*16

**ZA**\*17

	Model	AC20D-B	AC30D-B	AC40D-B	AC40D-06-B				
Component	Filter Regulator [AW]	AW20-B	AW30-B	AW40-B	AW40-06-B				
Component	Mist Separator [AFM]	AFM20-A	AFM30-A	AFM40-A	AFM40-06-A				
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4				
Pressure gau	uge port size [AW] *1	1/8							
Fluid		Air							
Ambient and	fluid temperature *2		-5 to 60 °C (wi	th no freezing)					
Proof pressu	ire	1.5 MPa							
Maximum op	erating pressure	1.0 MPa							
Set pressure	range [AW]	0.05 to 0.85 MPa							
Nominal filtra	ation rating [AW/AFM]	AW: 5 µm, AFM: 0.3 µm (99.9 % filtered particle size)							
Rated flow [I	/min(ANR)] [AFM] *3	150	330	800	800				
Outlet side oil m	ist concentration [AFM] *4 *5	Max.1.0 mg/m³ (ANR) (≈0.8 ppm)							
Bowl materia	al [AW/AFM]	Polycarbonate							
Bowl guard [	AW/AFM]	Semi-standard (Steel) Standard (Polycarbonate)							
Construction	n [AW]	Relieving type							
Weight [kg]		0.32	0.62	1.15	1.25				

Description

Name plate, caution plate for bowl, and pressure gauge in SI units: MPa

Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F

0.4 MPa pressure gauge for 0.2 MPa type.

atmospheric pressure using a pressure gauge.

\*6 When the pressure gauge is attached, a 1.0 MPa

\*7 The bracket position varies depending on the pressure

\*8 Make sure that the outlet pressure is released to

\*9 Pressure can be set higher than the specification

\*10 Refer to chemical data on page 46 for chemical

pressure in some cases, but use pressure within the

pressure gauge will be fitted for standard (0.85 MPa) type.

Digital pressure switch: With unit selection function

switch mounting.

specification range.

(polycarbonate)

(nylon).

resistance of the bowl.

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch.

\*2 -5 to 50 °C for the products with the digital pressure switch.

\*3 Conditions: Mist separator inlet pressure: 0.5 MPa; The rated flow varies depending on the inlet pressure.

Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.


\*4 When the compressor oil mist discharge concentration is 30 mg/m<sup>3</sup> (ANR).

\*5 Bowl seal and other O-rings are slightly lubricated.



# AC20D-B to AC40D-B Series

#### Dimensions



SMC

\*1 The dimension of C is the length when the filter regulator knob is unlocked.

33

# **Air Combination AC** Series **Options/Attachments**

#### **Options/Attachments/Part No.**

								Deviter						
				E 1010 1		- 1005 -	E 1000 E	Part no.	-	-	-	E 1000 E		
L			Model	For AC10-A	For AC20-B	For AC25-B	For AC30-B		For AC40-06-B		For AC55-B	For AC60-B		
ctic				For AC10A-A		-			For AC40A-06-B			For AC60A-B		
Section		Deseriet								For AC50B-B	For AC55B-B	For AC60B-B		
		Descripti			For AC20C-B	For AC25C-B				_	_	—		
				For AC20D-B		For AC30D-B	For AC40D-B	For AC40D-06-B		—				
		Round	Standard	G27-10-R1	l	G36-10-□01				G46-10-□01				
	bnu		0.02 to 0.2 MPa setting	G27-10-R1	I	G36-4-□01		G46-4-□01						
	g	Round type (with colour	Standard		l	G36-10-□01-L G46-10-□01-L								
	5	zone)	0.02 to 0.2 MPa setting	—	I	G36-4-🗆01-L		1		G46-4-□01-L				
L	ess	Square embedded	Standard	—	I				Pressure gauge					
Option	ā	type *2	0.02 to 0.2 MPa setting	—		-			Pressure gauge of					
do	Di		NPN output, Wiring bottom entry	1		-			25-M (Switch bo					
		accura	NPN output, Wiring top entry	' _ I		-			25-M (Switch bo		-			
		vitch	PNP output, Wiring bottom entry	1		-			65-M (Switch bo					
	-		PNP output, Wiring top entry	·				-MLA [ISE35-R-	65-M (Switch bo		-			
	Float type N.O. — — AD38-A							AD48-A						
		o drain *4	N.C.	AD17-A	AD27-A	AD3		AD47-A						
		acer		Y100-A	Y200-A		00-A	Y400-A Y500-A Y600-A						
	Sp	Spacer with bracket		Y100T-A	Y200T-A	Y300	-	Y400T-A Y500T-A Y600T-A						
	Ch	Check valve *5 *6		' <u> </u>	AKM2000-□01-A			AKM4000-(□02)-A	· _					
	-		-	1	· · · /	(□02)-A □02-A 0M-20-A IS10M-30-A		□03-A	104014 50 1					
	Pr	essure sv	vitCh *º		IS10M-20-A			IS10M-40-A	IS10M-50-A		IS10M-60-A			
	T-spacer *5 *6		*6	Y110-M5-A	Y210-□01-A	( - )		Y410-(□02)-A	Y510-(□02)-A	Y610-□03-A	Y610-(□03)-A			
				1	(□02)-A □02-A		□03-A □02A	□03-A	(□04)-A	ļl	□04-A			
Ħ	Pr	Pressure relief		1	VHS20-□01A	VHS30	VHS30-□02A			VHS50-⊡06A	ļ			
Jen				· -	□02A		□03A	VHS40-□03A	VHS40-□06A	□10A	ı —			
Attachment	_			1				04A	ļ	I	ι			
tac				1	□01-A	□01-A □02-A		□02-A	ļ į	I				
At	Pi	oing adap	ing adapter *6 E100-M5-A E200-□02-A E300-□03-A □03-A		-	E400-□03-A	E500-□06-A	I	E600-□06-A					
		5P						□04-A		I	□10-A			
				1				□06-A	ļ	·				
	-		deale and the	1	□01-A	□01-A □02-A		□02-A	l l		ļ			
	Pressure switch with piping adapter *6		adapter *6 – IS10E-2002-A IS10E-3		-	IS10E-40003-A			l _					
					□03-A □04-A		□04-A	ļ į						
				1			-	□06-A			ļ	<u> </u>		
	Cr	oss space	ər *6	Y14-M5-A	Y24-□01-A	Y34-[	-	Y44-⊡02-A	Y54-□03-A	_ I	_			
Ц					□02-A		02-A	□03-A	□04-A					

\*1 □ in part numbers for a round type pressure gauge indicates a pipe thread type. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for psi unit specifications.


Regarding how to order the digital pressure switch, refer to the **Web Catalogue**. \*4 Minimum operating pressure: N.O. type–0.1 MPa; N.C. type–0.1 MPa (AD27-A) and 0.15 MPa (AD37-A/AD47-A). Please consult with SMC separately for psi and °F unit display specifications.

 \*2 Including one O-ring and 2 mounting screws
 \*3 Lead wire with connector (2 m), adapter, lock pin, O-ring (1 pc.), mounting screw (2 pcs.) are attached. []: Switch body only.

\*5 For F.R.L. units, port sizes without () are standard specifications.
 \*6 Separate spacers are required for modular unit.

#### Check Valve: (K) 1/8, 1/4, 3/8

A check valve with intermediate air release port can be easily installed to prevent a backflow of lubricant when redirecting the air flow and releasing the air on the outlet side of the regulator.



**SMC** 

AC

AF + AR + AL

AW+AL

AF+AR

AF+AFM+AR

AW + AFM

Attachment

AF

**AFM / AFD** 

AR

P

AV

# AC Series

#### Pressure Switch: (S)

A compact integrated pressure switch can be easily installed and facilitates the pressure detection of the line.



#### Semi-standard: Select one each for a to c. Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) IS10M-30-<u>6LP</u>

				Symbol	Description	20	E 30	D Body size	ə 50	60								
			/															
			Set pressure	—	0.1 to 0.4 MPa													
	σ	а	range	<b>6</b> *1	0.1 to 0.6 MPa													
	lar			+														
_	standard	b	Lead wire	—	0.5 m		•	•	•									
2	sta		b	b	b	b	b	b	b	b	length	L	3 m		•		•	
-					lengui	Z	5 m		•		٠							
	Semi-			+														
	S	с	Pressure unit of	_	MPa				•									
			the scale plate	<b>P</b> *2	MPa/psi dual scale		•		•									

\*1 Set pressure range of 6P (L, Z) is 0.2 to 0.6 MPa (30 to 90 psi).

#### Specifications

Fluid	Air					
Ambient and fluid temperature	-5 to 60 °C (with no freezing)					
Proof pressure	1.0 MPa					
Maximum operating pressure	0.7 MPa					
Set pressure range (when OFF)	0.1 to 0.4 MPa					
Hysteresis	0.08 MPa or less					


#### **Switch Characteristics**


Contact point configuration	1a				
Maximum contact point capacity	2 VA (AC), 2 W (DC)				
Operating voltage: AC, DC	100 V or less				
Maximum operating current	12 V to 24 V AC, DC: 50 mA 48 V AC, DC: 40 mA 100 V AC, DC: 20 mA				

\* For detailed specifications on the IS10 series, refer to the IS10 series section of the SMC website: http://www.smc.eu

#### T-Spacer: (T) M5 x 0.8, 1/8, 1/4, 3/8, 1/2

Using a T-spacer facilitates the branching of air flow.





Pressure switch

Model	Α	В	С	D	Applicable model
IS10M-20-A	10.6	74.2	64.4	28	AC20□-B
IS10M-30-A	12.6	84.5	70.5	30	AC25□-B, AC30□-B
IS10M-40-A	14.6	93.3	75.3	36	AC40□-B
IS10M-50-A	16.6	97.3	77.3	44	AC40□-06-B
IS10M-60-A	22	92.5	68.5	53	AC50□-B, AC55□-B, AC60□-B

Symbol

 $\leq$ 

23

\* Separate spacers are required for modular unit.

Model *1	Port size	Α	В	С	D	Е	Applicable model		
Y110-M5-A	M5 x 0.8	11.2	19	12	14	8	AC10-A, AC10B-A		
Y210-□01-A	1/8	14.0	41.8	32	00 40		0 00	19	AC20-B, AC20B-B
Y210-□02-A	1/4	14.6	41.0	32	28	19	AC20C-B		
Y310-□01-A	1/8	14.6	52.7	38.7	30	19	AC25-B, AC25B-B		
Y310-□02-A	1/4	14.0	5 52.7	30.7	30	19	AC25C-B, AC30C-B		
Y410-□02-A	1/4	18.6	62	44	36	24	AC40-B, AC40B-B		
Y410-□03-A	3/8	10.0	62	44	30	24	AC40C-B		
Y510-□02-A	1/4	18.6	66	46	44	24	AC40-06-B, AC40B-06-B		
Y510-□03-A	3/8	10.0	00	40	44	24	AC40C-06-B		
Y610-□03-A	3/8	22	0.1	57	53	30	AC50-B, AC55-B, AC60-B,		
Y610-□04-A	1/2	22	81	57	53	30	AC50B-B, AC55B-B, AC60B-B		

\*1 □ in model numbers indicates a pipe thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.

\* Separate spacers are required for modular unit.

 $\ast\,$  Refer to the attachment table on page 34 for standard port sizes when using with the AC.

#### **Caution on Mounting**

If a T-spacer is used on the inlet side of the lubricator, lubricant may be mixed. Use the AKM series check valve to avoid such possibility.





#### Pressure Relief 3 Port Valve: (V) Pressure relief With the use of a pressure relief 3 port valve, pressure left in the line can be easily exhausted. 3 port valve VHS 30 3 4 Symbol 2 • Semi-standard: Select one each for a to b. · Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) VHS30-03A-RZ 3 1 Symbol Description Body size 20 30 40 50 Rr N\*1 2 Pipe thread type NPT • • • • **F**\*1 G • • • + Ουτ IN 01 1/8 2 x **P**1 02 1/4 m 03 3/8 • (Port size) 0 3 Port size $\odot$ 04 1/2 ۲ 06 3/4 P<sub>2</sub> I EXH 10 (Port size) 2 Flow direction: Left to right Flow • • Key can be mounted when standarc а Ø directio R Flow direction: Right to left • • • • residual pressure is released 4 Name plate in SI units: MPa • Pressure Semi b unit • • • Name plate in imperial units: psi σu т \*1 For pipe thread type: NPT only **Flow Rate Characteristics** Е Flow rate characteristics Port size D Model IN→OUT OUT→EXH C IN. OUT EXH Standard specifications VH

1/8 66.4 22.3 40 37.5 14 46.6 33.6 28 43

3/8 104.9 38.5

1/2 134.3 53

Α

110.4 42

В

80.3 29.4

D Ε F G Н

19 52

22 58

22 58

26 76 61

38

44

44

53 49

70 63

75 63

90 76

С

	IIN, OUT		C(dm3/s·bar)	b	Cv	C(dm <sup>3</sup> /s·bar)	b	Cv					
1/11000	1/8		2.4	0.43	0.65	2.5	0.39	0.69		Model			
VHS20	1/4	1/8	3.3	0.40	0.88	3.1	0.51	0.84	•	Woder	<b>P</b> 1	<b>P</b> 2	
1/11000	1/4	4/4	6.4	0.45	1.7	6.2	0.38	1.7		VHS20	1/8, 1/4	1/8	(
VHS30	3/8	1/4	8.3	0.41	2.3	7.0	0.41	1.9		VHS30	1/4, 3/8	1/4	8
	1/4		7.3	0.49	2.0	8.5	0.35	2.3	•	VHS40	1/4, 3/8, 1/2	3/8	1(
VHS40	3/8	3/8	10.9	0.45	3.0	11.6	0.40	3.1		VHS40-06	3/4	1/2	1
	1/2		14.2	0.39	3.8	13.3	0.43	3.6		VHS50	3/4, 1	1/2	1:
VHS40-06	3/4	1/2	18.3	0.31	5.0	17.7	0.37	4.8					L
VHS50	3/4	1/2	23.8	0.41	6.4	21.8	0.41	5.9	* Use	an air filter	on the inlet	side f	or
100	1	1/2	31.9	0.33	8.6	23.5	0.44	6.4		ating protec			

## Cross Spacer: M5 x 0.8, 1/8, 1/4, 3/8, 1/2

Pipings are possible in all 4 directions.

IN/OUT ports are not machined for threads.

Please contact SMC if threaded (machined) ports are required.





### **Caution on Mounting**

1. When mounting a cross spacer directly on the IN side of the lubricator, be sure to use the AKM series check valve between the lubricator and cross spacer.

2. Factory mounting of a cross spacer on the AC model is available as a special order.

F: Without threa	E E E D		E		) F	Centre of F.R.L. body
Model *1	E (Port size)	Α	В	С	D	Applicable model
Y14-M5-A	M5	23	16	14	25	AC10□-A
Y24-□01-A	1/8	40	40	22	40	AC20□-B
Y24-□02-A	1/4	40	40	22	40	AC20
Y34-□01-A	1/8	49	43	28	48	AC25□-B, AC30□-B
Y34-□02-A	1/4	49	43	20	40	AC2J□-D, AC3U□-D
Y44-□02-A	1/4	60	48	36	54	AC40 <b>□-</b> B
Y44-□03-A	3/8	00	40	30	54	AC400-D
Y54-□03-A	3/8	72	62	40	62	AC40□-06-B
Y54-□04-A	1/2	12	02	40	02	AC400-00-D
∗1 □ in model	numbers indic	ates a	nine th	bread t	vpe N	o indication is necessary

\*1  $\square$  in model numbers indicates a pipe thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.

\* If threaded IN/OUT ports are required, they are available as a special order. Please contact SMC.

\* Two hexagon socket head plugs are included in the package.

F

1

30 49

36 63

44 63

53 81

**AFM / AFD** 

AF


AR

A


AV

### Piping Adapter: M5 x 0.8, 1/8, 1/4, 3/8, 1/2, 3/4, 1

A piping adapter allows installation/removal of the component without removing the piping and thus makes maintenance easier.



### Pressure Switch with Piping Adapter



\*2 For pipe thread type: NPT only.

### Specifications

Fluid	Air
Ambient and fluid temperature	-5 to 60 °C (with no freezing)
Proof pressure	1.0 MPa
Maximum operating pressure	0.7 MPa
Set pressure range (when OFF)	0.1 to 0.4 MPa
Hysteresis	0.08 MPa or less

#### Switch Characteristics


Contact point configuration	1a
Maximum contact point capacity	2 VA (AC), 2 W (DC)
Operating voltage: AC, DC	100 V or less
Maximum operating current	12 V to 24 V AC, DC: 50 mA 48 V AC, DC: 40 mA
. 5	100 V AC, DC: 20 mA

Model *1	Port size	Α	В	D	Applicable model
E100-M5-A	M5 x 0.8	10	14	14	AC10□-A
E200-□01-A	1/8				
E200-□02-A	1/4	29.8	23.5	28	AC20□-B
E200-□03-A	3/8				
E300-□02-A	1/4				
E300-□03-A	3/8	31.8	30	30	АС25□-В, АС30□-В
E300-□04-A	1/2				
E400-□02-A	1/4				
E400-□03-A	3/8	31.8	36	36	AC40□-B
E400-□04-A	1/2	31.0	30	30	AC40∐-D
E400-□06-A	3/4				
E500-□06-A	3/4	31.8	40	44	AC40□-06-B
E600-□06-A	3/4	35	48	53	AC50-B, AC55-B, AC60-B, AC50A-B, AC60A-B, AC50B-B,
E600-□10-A	1	00	-0	55	AC55B-B, AC60B-B

\*1 
in model numbers indicates a pipe thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.

Separate spacers are required for modular unit.

\* Factory mounting of a piping adapter on the AC models is available as a special order.




Model *1	Port size	Α	В	С	D	E	Applicable model
IS10E-20□01-A	1/8						
IS10E-20 02-A	1/4	29.8	66.3	55.3	28	16	AC20□-B
IS10E-20□03-A	3/8						
IS10E-3002-A	1/4						
IS10E-30003-A	3/8	31.8	72.8	58.8	30	13	AC25⊡-B, AC30□-B
IS10E-30004-A	1/2						
IS10E-40□02-A	1/4						
IS10E-40□03-A	3/8	31.8	78.8	60.8	37	12.5	*2
IS10E-40□04-A	1/2	51.0	70.0	00.0	57	12.5	AC40□-B
IS10E-4006-A	3/4						

necessary for Rc; however, indicate N for NPT, and F for G.

\*2 Cannot be mounted on the AC40□-06-B.

Separate spacers are required for modular unit. \* The pressure switch on the AC40□-06-B can be mounted by screwing IS10-01S into the piping adapter E500-D06-A-X501 (with top-face thread Rc 1/8). Products with a premounted switch are available as a special order. Please contact SMC regarding their availability.

# **AC** Series **Accessories** (Spacers/Brackets)




### **Replacement Parts**

Description	Material			Part	t no.		
Description	Ivialeria	Y100-A	Y200-A	Y300-A	Y400-A	Y500-A	Y600-A
Seal	HNBR (NBR) *1	Y120P-050AS *2	Y220P-050S	Y320P-050S	Y420P-050S	Y520P-050S	Y620P-050S
*1 ( ): Size 10							

\*1 ( ): Size 10\*2 Assembly of 2 O-rings

### **Spacer with Bracket**



Model	Α	В	С	D	Е	EE	F	G	Н	J	Κ	Applicable model
Y100T-A	6	56	24.5	43.6	20	27	6.8	4.5	13	3	25	AC10□-A
Y200T-A	3.2	67	29	53.4	24	33	12	5.5	15.5	3.5	30	AC20 B
Y300T-A	4.2	82	41	71.5	35	—	14	7	19	4	41	AC25□-B, AC30□-B
Y400T-A	5.2	96	48	86.1	40	—	18	9	26	5	50	AC40□-B
Y500T-A	5.2	96	48	89.6	40	—	18	9	26	5	50	AC40□-06-B
Y600T-A	6.2	120	60	118	50	_	20	11	31.2	6	70	AC50□-B, AC55□-B, AC60□-B



Y200T-A

### Y400T-A

### **Replacement Parts**

Description	Material	Part no.										
Description	Wateria	Y100T-A	Y200T-A	Y300T-A	Y400T-A	Y500T-A	Y600T-A					
Seal	HNBR (NBR) *1	Y120P-050AS *2	Y220P-050S	Y320P-050S	Y420P-050S	Y520P-050S	Y620P-050S					

\*1 ( ): Size 10

\*2 Assembly of 2 O-rings



Attachment AW+AFM

AF


AFM / AFD

AR

AL

AW

### Mounting Position for Spacer with Bracket



# Attachments **AC** Series

AC

AW+AL AF+AR+AL

AF+AR

Attachment AW+AFM AF+AFM+AR

AF

**AFM / AFD** 

AR

AL

AW

Attachment		К		-	S	٦	-		V			KS			КТ				V			KST	
Model	A1	A2	A3	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	A4	A1	A2	A3
AC10-A	—	—	—	—	—	28	48.2	—	—	—	—	_	_	—	_	—	—	—	—	—	—	—	
AC20-B	41.6	43.2	43.2	41.6	43.2	41.6	61	41.6	43.2	43.2	41.6	43.2	57	41.6	61	43.2	41.6	43.2	43.2	43.2	41.6	61	57
AC25-B	55.1	57.2	57.2	55.1	57.2	55.1	76	55.1	57.2	57.2	55.1	57.2	74	55.1	76	57.2	55.1	57.2	57.2	57.2	55.1	76	74
AC30-B	55.1	57.2	57.2	55.1	57.2	55.1	76	55.1	57.2	57.2	55.1	57.2	74	55.1	76	57.2	55.1	57.2	57.2	57.2	55.1	76	74
AC40-B AC40-06-B	72.6	75.2	75.2	72.6	75.2 80.2	72.6	99 104	72.6	75.2	75.2 80.2	72.6	75.2	95	72.6	99	75.2	72.6	75.2	75.2	75.2	72.6	99	95
AC40-06-B				93.1	96.2	93.1	104	77.6	80.2	80.2		_	_	_		_	_		_				
AC55-B		_	_	98.1	96.2	98.1	124	_			_		_	_	_	_	_					_	
AC60-B	_	_	_	98.1	101.2	98.1	129	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	
												1											·
Attachment Model	A1	A2	SV	Δ.4	Δ.1	A2		Δ.4	Δ.1	A2		Δ.4	-	A2	Δ1	SV A2	12	Δ1	A2	A3	Δ1	<b>TV</b> A2	A3
AC10-A		AZ	A3	A4	A1	A2	A3	A4	A1	AZ	A3	A4	A1	AZ	A1	A2	A3	A1	AZ	A3	A1	AZ	AS
AC10-A AC20-B	41.6	43.2	57	43.2	41.6	61	43.2	43.2	41.6	61	57	43.2	41.6	61	41.6	43.2	57	41.6	61	57	41.6	61	43.2
AC25-B	55.1	57.2	74	57.2	55.1	76	57.2	57.2	55.1	76	74	57.2	55.1	76	55.1	57.2	74	55.1	76	74	55.1	76	57.2
AC30-B	55.1	57.2	74	57.2	55.1	76	57.2	57.2	55.1	76	74	57.2	55.1	76	55.1	57.2	74	55.1	76	74	55.1	76	57.2
AC40-B	72.6	75.2	95	75.2	72.6	99	75.2	75.2	72.6	99	95	75.2	72.6	99	72.6	75.2	95	72.6	99	95	72.6	99	75.2
AC40-06-B	-	_	—	—	_	_	_	—	_	_	—	_	77.6	104	77.6	80.2	102	77.6	104	102	77.6	104	80.2
AC50-B	—	—	—	-	—	—	—	—	—	—	—	-	93.1	124	93.1	189.3	124	93.1	124	124	93.1	124	96.2
AC55-B	—	—	—	_	—	—	—	—	—	—	—	—	98.1	124	—	—	—	—	—	—	—	—	—
AC60-B		_	_	-		_		—	—	—	_	-	98.1	129	-	_	_	-	_			_	
Attachment	ŀ	۲	S	\ \	V	K	S		K۷			KSV		S	V								
Model	A1	A2	A1	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2								
AC20A-B	41.6	43.2	41.6	41.6	43.2	41.6	57	41.6	43.2	43.2	41.6	57	43.2	41.6	57								
AC30A-B	55.1	57.2	55.1	55.1	57.2	55.1	74	55.1	57.2	57.2	55.1	74	57.2	55.1	74								
AC40A-B AC40A-06-B	72.6	75.2	72.6	72.6	75.2 80.2	72.6	95	72.6	75.2	75.2	72.6	95	75.2	72.6	95 102								
AC40A-06-B			77.6 93.1	77.6 93.1	96.2	_			_	_		_	_	77.6 93.1	102								
AC60A-B	_	_	98.1			_	_	_	_	_	_	_	_		-								
	6					14		V		14	-		-	14		L							
Attachment		<b>T</b>		V A2	V	-		V	S'	1		V		V1									
Model	A1	A1 28	A1	A2	A1	A2	A1	A2	A1	A2	A1	A2	A1	A2									
AC10B-A	41.6	41.6	41.6	43.2	41.6	43.2	41.6	57	41.6	43.2	41.6	61	41.6	43.2	I I								
AC25B-B	55.1	55.1	55.1	57.2	55.1	57.2	55.1	74	55.1	57.2	55.1	76	55.1	57.2									
AC30B-B	55.1	55.1	55.1	57.2	55.1	57.2	55.1	74	55.1	57.2	55.1	76	55.1	57.2									
AC40B-B	72.6	72.6	72.6	75.2	72.6	75.2	72.6	95	72.6	75.2	72.6	99	72.6	75.2									
AC40B-06-B	77.6	77.6	77.6	80.2	77.6	80.2	77.6	102	77.6	80.2	77.6	104	77.6	80.2									
AC50B-B	93.1	93.1	93.1	189.3	93.1	96.2	93.1	124	93.1	96.2	93.1	124	93.1	96.2									
AC55B-B	98.1	98.1	—	-	—	—	—	—	-	—	—	-	-	—									
AC60B-B	98.1	98.1		-		-	—	—	-				-										
Attachment			-	Г		V	-		V1			SV			SV1			TV			TV1		
Model	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	
AC20C-B	41.6	43.2	41.6	43.2	41.6	43.2	43.2	41.6	43.2	43.2	41.6	43.2	57	41.6	43.2	43.2	41.6	43.2	61	41.6	43.2	43.2	
AC25C-B AC30C-B	55.1 55.1	57.2 57.2	55.1 55.1	57.2 57.2	55.1 55.1	57.2	57.2	55.1	57.2 57.2	57.2 57.2	55.1 55.1	57.2 57.2	74 74	55.1	57.2 57.2	57.2 57.2	55.1	57.2 57.2	76 76	55.1 55.1	57.2 57.2	57.2 57.2	
AC30C-B	72.6	75.2	72.6	75.2	72.6	57.2 75.2	57.2 75.2	55.1 72.6	75.2	75.2	72.6	75.2	95	55.1 72.6		75.2	55.1 72.6	75.2	99	72.6	75.2	75.2	
AC40C-06-B	77.6	80.2	77.6	80.2	77.6	80.2	80.2	77.6	80.2	80.2	77.6	80.2	102	77.6	80.2		77.6	80.2	104	77.6		80.2	
										-	I									1			
Attachment	-		/	V		S			V1		Jimens rst bra		m the	ena of	ine IN :	side to	ine ce	ntre of	ine mo	ounting	noie to	n the	
	A1	A1	A2	A1	A2	A1	A2	A1	A2	A2: I	Nountir	ng hole						econd b					
AC20D-B AC30D-B	41.6 55.1	41.6 55.1	43.2 57.2	41.6	43.2	41.6 55.1	57 74	41.6 55.1	43.2			0						e third					
ACOUD-D	55.1	55.1	51.2	55.1	51.2	55.1	14	55.1	51.2	A4: I	viountir	ng hole	pitch	petwee	en the t	nırd an	a the f	ourth b	rackets	S.			

 AC30D-B
 55.1
 55.1
 57.2
 55.1
 57.2
 55.1
 74
 55.1
 57.2

 AC40D-B
 72.6
 72.6
 75.2
 72.6
 95
 72.6
 75.2
 72.6
 95
 72.6
 75.2

AC40D-06-B 77.6 77.6 80.2 77.6 80.2 77.6 102 77.6 80.2

# Modular Type Air Filters **AF/AFM/AFD Series**

Air Filter AF Series	Model	Port size	Filtration µm	Options	
	AF10-A	M5 x 0.8			
	AF20-A	1/8, 1/4			
	AF30-A	1/4, 3/8		Bracket (Except AF10-A)	
	AF40-A	1/4, 3/8, 1/2	5		
	AF40-06-A	3/4		Float type auto drain	
	AF50-A	3/4, 1			
Pages 43 to 54	AF60-A	1			
Mist Separator AFM Series	AFM20-A	1/8, 1/4			
	AFM30-A	1/4, 3/8	0.3	Bracket	
	AFM40-A	1/4, 3/8, 1/2	0.0	Float type auto drain	
Pages 55 to 63	AFM40-06-A	3/4			
Micro Mist Separator AFD Series	AFD20-A	1/8, 1/4			
204	AFD30-A	1/4, 3/8	0.01	Bracket	ì
	AFD40-A	1/4, 3/8, 1/2	0.01	Float type auto drain	I
Pages 55 to 63	AFD40-06-A	3/4			ĺ

AC

AL

			Air A		<sup>ter</sup> 10-A to AF	<b>-6</b>	50	)	4		
Sym Air Fil <u>1</u>			Air Filter w	vith Auto I	Drain How to Order		AF10-4		F20-A	AF	40-A
A	F	3		03 Symbol	<ul> <li>BD - A - Option/Semi-s</li> <li>Option/Semi-s</li> <li< th=""><th>standard sy ate in alph</th><th>/mbol: W anumeric</th><th>hen mor</th><th>e than on</th><th>e specific</th><th>cation is</th></li<></ul>	standard sy ate in alph	/mbol: W anumeric	hen mor	e than on	e specific	cation is
2		Pipe	thread type	<b>N</b> *1 <b>F</b> *2 +	Metric thread (M5) Rc NPT G	10 •  	20 — • •	30 — •	40 — • •	50 — ● ●	60 — • •
3		I	Port size	M5 01 02 03 04 06 10	M5 x 0.8 1/8 1/4 3/8 1/2 3/4 1	•    				   •	
4	Option	a	Mounting	+ 	Without mounting option With bracket Without auto drain	• 	•	•	•	•	•
		b c	Bowl *6	B <sup>*3</sup> With bracket     +     Without auto drain     C <sup>*4</sup> N.C. (Normally closed) Drain port is closed when pressure is not a     D <sup>*5</sup> N.O. (Normally open) Drain port is open when pressure is not a     +     Polycarbonate bowl     2 Metal bowl     6 Nuloe bowl		•  • • • • • • •	• • • • •	• • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • •
6	Semi-standard	d	Drain port *9	+ J*10 W*11 +	With drain cock Drain guide 1/8 Drain guide 1/4 Drain cock with barb fitting	•  	•	• 	•  •	• 	•  •
		e f	Flow direction Pressure unit	R + 	Flow direction: Left to right Flow direction: Right to left Name plate and caution plate for bowl in SI units: MPa Name plate and caution plate for bowl in imperial units: psi, °F e AF20-A) and NPT 1/4 (applicable to the AF30-A to AF60-A).	● ● ○*13	• • • • •	• • • •	• • ()*13	• • ()*13	• • ()*1

The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AF30-A to AF60-A).

\*2 Drain guide is G 1/8 (applicable to the AF20-A) and G 1/4 (applicable to the AF30-A to AF60-A).

The auto drain port comes with Ø 10 One-touch fitting (applicable to the AF30-A to AF60-A).

\*3 Option B is not assembled and supplied loose at the time of shipment. Assembly of a bracket and 2 mounting screws. \*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

\*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min [ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.

\*6 Refer to chemical data on page 46 for chemical resistance of the bowl.

\*7 A bowl guard is provided as standard equipment (polycarbonate).

\*8 A bowl guard is provided as standard equipment (nylon).

 $\ast 9~$  The combination of float type auto drain: C and D is not available.

\*10 Without a valve function

 $\ast 11\,$  The combination of metal bowl: 2 and 8 is not available.

\*12 For pipe thread type: M5, NPT.

\*13  $\bigcirc$ : For pipe thread type: M5, NPT only

43



# Air Filter AF10-A to AF60-A Series

### **Standard Specifications**

1/8, 1/4	1/4, 3/8 -5 to	1/4, 3/8, 1/2 Air 60 °C (with no fre 1.5 MPa 1.0 MPa	3/4 eezing)	3/4, 1	
	-5 to	60 °C (with no fre 1.5 MPa 1.0 MPa	ezing)		
	-5 to	1.5 MPa 1.0 MPa	ezing)		
		1.0 MPa			
		5 µm			
8	25		4	5	
		Polycarbonate			
Semi-standard (Steel)		Stan	dard (Polycarbor	nate)	
0.08	0.18	0.36	0.41	0.87	1.00
	Semi-standard (Steel)	Semi-standard (Steel)	Polycarbonate           Semi-standard (Steel)         Stan	Polycarbonate           Semi-standard (Steel)         Standard (Polycarbor	Polycarbonate           Semi-standard (Steel)         Standard (Polycarbonate)

### **Option/Part No.**

Optional specifications				Model			
Optional specifications	AF10-A	AF20-A	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A
Bracket assembly *1	—	AF22P-050AS	AF32P-050AS	AF42P-050AS	AF42P-070AS	AF52P	-050AS

\*1 Assembly of a bracket and 2 mounting screws

### **Bowl Assembly/Part No.**

Bowl	Drain					Mode	el .			
material	discharge mechanism	Drain port	Other	AF10-A	AF20-A	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A
		With drain cock	—	C1SF-A	C2SF-A			-	_	
		WITH UTAILL COCK	With bowl guard		C2SF-C-A	C3SF-A		C4S	SF-A	
	Manual	Drain cock with barb fitting	With bowl guard	—	—	C3SF-W-A	C4SF-W-A			
Polycarbonate		With drain guide	—	—	C2SF□-J-A	—				
FOIYCAIDONALE		(without valve function)	With bowl guard	—	C2SF□-CJ-A	C3SF□-J-A		C4SF⊡-J-A		
	A	Normally closed (N.C.)	—	AD17-A	AD27-A	—	_			
	(Auto drain)		With bowl guard	—	AD27-C-A	AD37🗆-A		AD4	7□-A	
		Normally open (N.O.)	With bowl guard	—	—	AD38🗆-A	AD48□-A			
		With drain cock	—	C1SF-6-A	C2SF-6-A	—		-	_	
		WITH UTAIN COCK	With bowl guard	_	C2SF-6C-A	C3SF-6-A		C4SF-6-A		
	Manual	Drain cock with barb fitting	With bowl guard		—	C3SF-6W-A		C4SF	-6W-A	
Nylon		With drain guide	—	—	C2SF□-6J-A	—				
INVIOIT		(without valve function)	With bowl guard	—	C2SF□-6CJ-A	C3SF□-6J-A	C4SF□-6J-A			
	A	Normally closed (N.C.)	—	AD17-6-A	AD27-6-A	—				
	(Automatic *)		With bowl guard	—	AD27-6C-A	AD37□-6-A		AD47	□-6-A	
		Normally open (N.O.)	With bowl guard	—	—	AD38□-6-A		AD48	□-6-A	
		With drain cock	—	C1SF-2-A	C2SF-2-A	C3SF-2-A	C4SF-2-A			
	Manual		With level gauge		—	C3LF-8-A		C4LF	-8-A	
	Ivialiual	With drain guide	—		C2SF□-2J-A	C3SF□-2J-A		C4SF	-2J-A	
Metal		(without valve function)	With level gauge	—	—	C3LF□-8J-A		C4LF	-8J-A	
weld		Normally closed (N.C.)	_	AD17-2-A	AD27-2-A	AD37□-2-A		AD47	□-2-A	
	Automatic *1	INOTTIALLY CLOSED (IN.C.)	With level gauge		—	AD370-8-A		AD47	□-8-A	
	(Auto drain)	Normally open (N.O.)	—		—	AD380-2-A		AD48	□-2-A	
			With level gauge			AD380-8-A		AD48	□-8-A	

\*1 Minimum operating pressure: N.O. type–0.1 MPa (AD38-A, AD48-A); N.C. type–0.1 MPa (AD17-A, AD27-A) and 0.15 MPa (AD37-A, AD47-A). Bowl assembly for the AF20-A to AF60-A models comes with a bowl seal.

in bowl assembly part numbers indicates a pipe thread type (applicable tubing for auto drain). No indication is necessary for Rc thread; however, indicate N for NPT thread, and F for G thread. (For auto drain, —: Ø 10, N: Ø 3/8") Please consult with SMC separately for psi and °F unit display specifications.

AF+AR

AF + AFM + AR

Attachment AW+AFM

AF

**AFM / AFD** 


AR


AL


AW


# AF10-A to AF60-A Series


### Flow Rate Characteristics (Representative values)

















# Air Filter AF10-A to AF60-A Series

## Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### **Design/Selection**

## **Warning**

1. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

			Material		
Туре	Chemical name	Application examples	Polycar- bonate	Nylon	
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×	
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0	
Inorganic salts	Sodium sulfide Potassium nitrate Sulfate of soda	_	×	Δ	
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ	
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ	
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×	
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×	
Oil	Gasoline Kerosene	_	×	0	
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0	
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0	
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×	
Others	Thread-lock fluid Seawater	_	×	Δ	

When the above factors are present, or there is some doubt, use a metal bowl for safety.

### Maintenance

- \land Warning
- 1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

### **Mounting/Adjustment**

## **A** Caution

 When the bowl is installed on the air filter (AF30-A to AF60-A), install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



SMC


A


AV

# AF10-A to AF60-A Series


### Working Principle: Float Type Auto Drain

### N.O. type: AD38-A, AD48-A





### Compact auto drain N.C. type: AD17-A, AD27-A



## • When pressure inside the bowl is released:

When pressure is released from the bowl (1), the piston (7) is lowered by the spring (6).

The sealing action of the seal 0 is interrupted, and the outside air flows inside the bowl 1 through the housing hole 9 and the drain cock 1.

Therefore, if there is an accumulation of condensate in the bowl (1), it will drain out through the drain cock.

## • When pressure is applied inside the bowl:

When pressure is 0.1 MPa or more, the force of the piston  $\bigcirc$  surpasses the force of the spring (6), and the piston goes up.

This pushes seal  $(\widehat{0})$  up so that it creates a seal, and the inside of the bowl  $(\widehat{1})$ , is shut off from the outside air.

If there is no accumulation of condensate in the bowl (1) at this time, the float (2) will be pulled down by its own weight, causing the valve (4), which is connected to the lever (3), to seal the valve seat (5).

#### When there is an accumulation of condensate in the bowl:

The float (2) rises due to its own buoyancy and the seal at the valve seat (5) is interrupted. This allows the pressure inside the bowl (1) to

enter the chamber (a). The result is that the combined pressure inside the chamber (b) and the force of the spring (b) lowers the piston (c).

This causes the sealing action of the seal 1 to be interrupted, and the accumulated condensate in the bowl 1 drains out through the drain cock 1.

Turning the drain cock 1 manually counterclockwise lowers the piston 7, and causes the seal created by the seal 1 to be interrupted, thus allowing the condensate to drain out. **47** 

## • When pressure inside the bowl is released:

Even when pressure inside the bowl 1 is released, spring 6 keeps the piston 7 in its upward position.

This keeps the seal created by the seal 1 in place; thus, the inside of the bowl 1 is shut off from the outside air.

Therefore, even if there is an accumulation of condensate in the bowl  $(\ensuremath{\underline{0}}),$  it will not drain out.

#### When pressure is applied inside the bowl:

Even when pressure is applied inside the bowl (1), the combined force of the spring (6) and the pressure inside the bowl (1) keeps the piston (7) in its upward position.

This maintains the seal created by the seal 0 in place; thus, the inside of the bowl 1 is shut off from the outside air.

If there is no accumulation of condensate in the bowl ① at this time, the float ② will be pulled down by its own weight, causing the valve ④, which is connected to the lever ③, to seal the valve seat ⑤.

## • When there is an accumulation of condensate in the bowl:

The float (2) rises due to its own buoyancy and the seal at the valve seat (5) is interrupted. This allows the pressure inside the bowl (1) to enter the chamber (8).

The result is that the pressure inside the chamber (§) surpasses the force of the spring (§) and pushes the piston downward.

This causes the sealing action of the seal 1 to be interrupted and the accumulated condensate in the bowl 1 drains out through the drain cock 1.

Turning the drain cock (1) manually counterclockwise lowers the piston (2), and causes the seal created by the seal (1) to be interrupted, thus allowing the condensate to drain out.

## • When pressure inside the bowl is released:

Even when pressure inside the bowl ① is released, the weight of the float ② causes the valve ④, which is connected to the lever ③, to seal the valve seat ⑤. As a result, the inside of the bowl ① is shut off from the outside air. Therefore, even if there is an accumulation of

condensate in the bowl (1), it will not drain out.

## • When pressure is applied inside the bowl:

Even when pressure is applied inside the bowl (1), the weight of the float (2) and the differential pressure that is applied to the valve (4) cause the valve (4) to seal the valve seat (5), and the outside air is shut off from the inside of the bowl (1).

## • When there is an accumulation of condensate in the bowl:


The float 2 rises due to its own buoyancy and the seal at the valve seat 5 is interrupted.

The condensate inside the bowl 1 drains out through the knob 6.

Turning the knob <sup>(6)</sup> manually counterclockwise lowers it and causes the sealing action of the valve seat <sup>(5)</sup> to be interrupted, which allows the condensate to drain out.



# Air Filter AF10-A to AF60-A Series




Operating State and Proper Use of Float Type Auto Drain

Note) For N.O. (Normally open) type, the drain discharge passage is open when pressure is not applied. For this reason, the drain exhaust port is not closed completely in a compressor with a small supply amount (less than 0.75 kW) and the air will ceaselessly blow out.



# AF10-A to AF60-A Series

### Construction



### **Component Parts**

No.	Description	Material	Model	Colour
1	Body	Zinc die-cast	AF10-A	White
'	воау	Aluminium die-cast	AF20-A to AF60-A	vvnite
6	Housing	Aluminium die-cast	AF50-A/AF60-A	White

#### **Replacement Parts**

No.	Description	Material		Part no.									
INO.	Description	Material	AF10-A	AF20-A	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A				
2	Filter element	Non-woven fabric	AF10P-060S	AF20P-060S	AF30P-060S	AF40F	2-060S	AF50P-060S	AF60P-060S				
3	Baffle	PBT	AF10P-040S *2	AF22P-040S	AF32P-040S	AF42F	P-040S	AF50P-040S	AF60P-040S				
4	Bowl seal	NBR	C1SFP-260S	C2SFP-260S	C32FP-260S	C42FP-260S							
5	Bowl assembly *1	Polycarbonate	C1SF-A	C2SF-A	C3SF-A	C4SF-A							

\*1 Bowl seal is included for the AF20-A to AF60-A. Please contact SMC regarding the supply of bowl assembly with psi and °F unit specifications.

\*2 The baffle material for the AF10-A (AF10P-040S) only is polyacetal.

## Air Filter AF10-A to AF60-A Series



AF50-A

AF60-A

3/4.1

90 220.1 24

95 234.1 24

45


47.5

30 45

30 47.5

70 66 35 11 13 90 3.2 47 259.9

70 66 35



13 90

3.2 47

273.9

228.6

242.6

226.9

240.9

222.6

236.6

227.1

241.1

242.6

256.6

247.1

261.1

# AF10-A to AF60-A Air Filter Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### 1 Long Bowl Drain capacity is greater than that of standard models. Applicable Model/Drain Capacity AF40-A AF10-A AF20-A Model AF30-A AF40-06-A AF50-A AF60-A Port size 1/4, 3/8 1/4, 3/8, 1/2 M5 1/8, 1/4 3/43/4, 1 1 Drain capacity [cm<sup>3</sup>] 9 19 43 88 B dimension [mm] 81.6 108.6 137.1 167.2 169.2 240.2 254.2 \*1 For polycarbonate bowls. Please contact SMC for other bowl materials AF20-A AF30 to 40-06-A AF 30 03 A-X64 B m 4 Long bowl 虿 • Semi-standard: Select one each for a to d. • Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AF30-03B-2R-A-X64 0 Symbol Description Body size 10 20 30 40 50 60 Metric thread (M5) Rc • 2 Pipe thread type **N**\*1 NPT \_ **F**\*2 G • + M5 M5 01 1/802 1/4 03 3 3/8 Port size 04 1/2 06 3/4 • 10 1 + Without mounting option 4 Option (Mounting) **B**\*3 With bracket + Polycarbonate bowl 2 Metal bowl Bowl \*4 6 Nylon bowl а C With bowl guard \_\_\*6 \_\_\_\*6 6C \_\_\_\*6 With bowl guard (Nylon bowl) +Semi-standard With drain cock Drain guide 1/8 **J**\*7 6 b Drain port Drain guide 1/4 **W**\*8 Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube) +Flow direction: Left to right Flow direction С R Flow direction: Right to left +Name plate and caution plate for bowl in SI units: MPa d Pressure unit **Z**\*9 Name plate and caution plate for bowl in imperial units: psi, °F $\bigcirc^{*1}$

\*1 Drain guide is NPT 1/8 (applicable to the AF20-A) and NPT 1/4 (applicable to the AF30-A to AF60-A).
 The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the

\*2 Drain guide is G 1/8 (applicable to the AF20-A) and G 1/4 (applicable to the

\*4 Refer to chemical data on page 46 for chemical resistance of the bowl.

\*5 A bowl guard is provided as standard equipment (polycarbonate).

\*6 A bowl guard is provided as standard equipment (nylon).
 \*7 Without a valve function

\*8 The combination of metal bowl: 2 is not available.

\*9 For pipe thread type: NPT. \*10 O: For pipe thread type: NPT only

AF30-A to AF60-A).\*3 Option B is not assembled and supplied loose at the time of shipment. Assembly of a bracket and 2 mounting screws.

**SMC** 

AF30-A to AF60-A).

#### AF20-A to AF60-A Air Filter Made to Order Please contact SMC for detailed dimensions, specifications and lead times. AC (2) With Element Service Indicator Clogging status of elements can be checked visually. AF+AR+AL Applicable Model AF60-A AF40-06-A AF50-A Model AF20-A AF30-A AF40-A Port size 1/8. 1/4 1/4.3/8 1/4. 3/8. 1/2 3/4, 1 3/4• Option/Semi-standard: Select one each for a to f. A-X2141 AF 30 03 · Option/Semi-standard symbol: When more than one specification is AW+AL required, indicate in alphanumeric order. Example) AF30-03BD-2R-A-X2141 With element service indicator AF+AR A special body type is required to mount the element service indicator. It cannot be mounted on a standard body. 0 Symbol Description Body size 20 30 40 50 60 AF+AFM+AR Rc 2 N\*1 NPT Pipe thread type **F**\*2 G + 01 1/8 1/402 \_ 03 3/8 AW+AFM 3 Port size 04 1/2 06 3/4 10 1 + Attachment Without mounting option а Mountina **B**\*3 With bracket Option + 4 Without auto drain Float type C N.C. (Normally closed) Drain port is closed when pressure is not applied. • b auto drain **D**\*5 N.O. (Normally open) Drain port is open when pressure is not applied. • +Polycarbonate bowl 2 Metal bowl Bowl \*6 С Nylon bowl 6 ЧF 8 Metal bowl with level gauge + With drain cock Semi-standard **AFM / AFD** Drain guide 1/8 J\*8 d Drain port \*7 6 Drain guide 1/4 • **W**\*9 Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube) + Flow direction: Left to right е Flow direction Flow direction: Right to left R AR + Name plate and caution plate for bowl in SI units: MPa Pressure unit

Drain guide is NPT 1/8 (applicable to the AF20-A) and NPT 1/4 (applicable to the AF30-A to AF60-A). \*1

The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AF30-A to AF60-A). \*2 Drain guide is G 1/8 (applicable to the AF20-A) and G 1/4 (applicable to the AF30-A to AF60-A).

\*3 Option B is not assembled and supplied loose at the time of shipment. Assembly of a bracket and 2 mounting screws.

\*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

\*5 If the compressor is small (0.75 kW, discharge flow is less than 100 I/min [ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended

Z<sup>\*10</sup> Name plate and caution plate for bowl in imperial units: psi, °F

\*6 Refer to chemical data on page 46 for chemical resistance of the bowl.

The combination of float type auto drain: C and D is not available. \*7

\*8 Without a valve function

\*9 The combination of metal bowl: 2 and 8 is not available.

\*10 For pipe thread type: NPT

\*11 O: For pipe thread type: NPT only



0\*11

Ł

AV

0\*11

O\*11

○\*11

○\*11

# AF20-A to AF60-A Air Filter Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



### **③** Special Temperature Environment

Special materials are used in the manufacturing of seals and resin parts to allow them to withstand various temperature conditions in cold or tropical (hot) climates.

#### Specifications

Made-to	-order part no.	-X430	-X440
Environment		Low temperature	High temperature
Ambient t	emperature [°C]	-30 to 60	-5 to 80
Fluid tem	perature [°C]	-5 to 60 (with	no freezing)
Material	Rubber parts	Special NBR	FKM
wateriai	Main parts	Metal (Aluminiu	m die-cast. etc.)

### **Applicable Model**

		-			
Model	AF30-A	AF40-A	AF40-06-A	AF50-A	AF60-A
Port size	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1

A	F	3	0 - [	2	03 B - 2 8 4 5				30
• 5	Semi	-sta	ndard sy	mbol: V	he each for <b>a</b> to <b>c</b> . When more than one			high/ perat	
0	ordei		tion is re AF30-03		indicate in alphabetic -X430	X430 X440		tempe tempe	
				Symbol	Description	30	Body 40	) / size 50	60
				<u> </u>	Rc				
2	P	•	thread	<b>N</b> *1	NPT				
-		ty	rpe	<b>F</b> *2	G				
				+		L			
				02	1/4			—	—
				03	3/8			—	—
3		Por	t size	04	1/2	_		-	_
				06	3/4	_			—
				10	1				
				+					
		Op	otion	_	Without mounting option				
4	(		inting)	<b>B</b> *3	With bracket				
				+	I	L			
6		Bo	wl*4	2	Metal bowl				
				+					
		a	Drain		With drain cock				
		a	port	<b>J</b> *5	Drain guide 1/4				
	σ			+					
	dar	b	Flow		Flow direction: Left to right				
6	tan		direction	R	Flow direction: Right to left				
	ni-s			+					
	Semi-standard	с	Pressure	_	Name plate and caution plate for bowl in SI units: MPa	•	•	•	•
		Ū	unit	<b>Z</b> *6	Name plate and caution plate for bowl in imperial units: psi, °F	0*7	0*7	0*7	0*7

## \*1 Drain guide is NPT 1/4.\*2 Drain guide is G 1/4.

\*3 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

\*4 Only metal bowl 2 is available.

\*5 Without a valve function

\*6 For pipe thread type: NPT.
\*7 O: For pipe thread type: NPT only


### 4 High Pressure

Strong materials are used in the manufacturing of air filters intended for high pressure operation.

#### Specifications

Made-to-order part no.	-X425		
Proof pressure [MPa]	3.0		
Maximum operating pressure [MPa]	2.0		
Ambient and fluid temperature [°C]	-5 to 60 (with no freezing)		

#### **Applicable Model**



For high pressure

• Semi-standard: Select one each for a to c.

Semi-standard symbol: When more than one specification is required,

indicate in alphabetic order.

	amp		AF30-03		-//=20					
								0		
				Symbol	Description		Bo	ody si	ze	
			$\sim$			20	30	40	50	60
					Rc					
2	P		thread	<b>N</b> *1	NPT					
		ty	pe	<b>F</b> *2	G					
				+						
				01	1/8		—	—	_	—
				02	1/4		٠		—	—
6		Dord	t size	03	3/8	—	٠		—	—
8		POI	size	04	1/2	—	—		—	—
				06	3/4	—	—			—
				10	1	—	—	-		
				+						
			otion	—	Without mounting option					
4	(	Mou	inting)	<b>B</b> *3	With bracket					
				+						
6		Bo	wl*4	2	Metal bowl					
9		DU	VVI	8	Metal bowl with level gauge	—				
		_	-	+						
			Drain		With drain cock					
		а	port	<b>J</b> *5	Drain guide 1/8		_			—
			P		Drain guide 1/4	_				
	ard	_		+						
	nd	b	Flow		Flow direction: Left to right					
6	-sta		direction	R	Flow direction: Right to left					
	Semi-standard	_		+					I	
	Š	с	Pressure	_	Name plate and caution plate for bowl in SI units: MPa	•	•	•	•	•
		G	unit	<b>Z</b> *6	Name plate and caution plate for bowl in imperial units: psi, °F	0*7	0*7	0*7	0*7	0*7

\*1 Drain guide is NPT 1/8 (applicable to the AF20-A) and NPT 1/4 (applicable to the AF30-A to AF60-A).

 $\ast 2$  Drain guide is G 1/8 (applicable to the AF20-A) and G 1/4 (applicable to the AF30-A to AF60-A).

\*3 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

\*4 Only metal bowl 2 and 8 are available.\*5 Without a valve function

\*6 For pipe thread type: NPT.

\*7 O: For pipe thread type: NPT only

**SMC** 

# AF20-A to AF60-A Air Filter Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.

### **5** Clean Series

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.



### Standard model no.

Please contact SMC if a product with pressure gauge is desired.

Clean series


### 6 Copper, Fluorine and Silicone-free + Low Particle Generation

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.



Copper, fluorine and silicone-free + Low particle generation

⑦ Non-standard filtration rating



AC AF + AR + AL AW+AL AF+AR AF+AFM+AR Attachment AW+AFM AF **AFM / AFD** AR

AL

AV

		AF Micro AF				2004	
				filtration rating: 0.3 μm ΄΄΄ iltration rating: 0.01 μm <u>How to Order</u>		AFM20-A	AFD40-A
		30 - [ 30 - [		Option/Sem specificatio	ni-standard sym n is required, in <sup>-</sup> M30-03BD- <u>R</u> -A		n one
	_					0	
			Symbol	Description		Body size	
					20	30	40
				Rc			
2	Pine	e thread type	N*1	NPT			
9	Tipe	e inteau type	F*2	G			
			+	9	•		•
			01	1/8			
			02	1/4		•	
		Port size	02	3/8		•	
8		Fort Size		[ ]		•	
			04	1/2			•
			06	3/4		—	•
			- T	Without mounting option			
	a	Mounting	<b>B</b> *3	Without mounting option With bracket			
5			+	With Dracket			
Option			- T	Without auto drain	•		•
C		Float type					
		i ioai type	<b>C</b> *4	N.C. (Normally closed) Drain part is closed when pressure is not applied			
	b	auto drain	C*4	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•
	b	auto drain	<b>D</b> *5	N.C. (Normally closed) Drain port is closed when pressure is not applied. N.O. (Normally open) Drain port is open when pressure is not applied.	•	•	•
	d   b	auto drain		N.O. (Normally open) Drain port is open when pressure is not applied.	- -	•	•
	b	auto drain	D*5 +	N.O. (Normally open) Drain port is open when pressure is not applied. Polycarbonate bowl	٠	•	•
	b	auto drain	D*5 + 2	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl	•	•	•
	c	Bowl *6	D*5 + 2 6	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl	٠	•	•
		auto drain	D*5 + 2 6 8	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl with level gauge	•	• • •	•
		auto drain	D*5 + 2 6 8 C	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl with level gauge         With bowl guard	• • • 	•     •	• • *7
	c	auto drain	D*5 + 2 6 8 C 6C	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl with level gauge	•	• • •	•
dard	c	auto drain	D*5 + 2 6 8 C	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl with level gauge         With bowl guard         With bowl guard (Nylon bowl)	• • • •	•     •	• • • *7 *8
tandard	c	auto drain Bowl *6	D*5 + 2 6 8 C 6C	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock	• • • •		• • *7
<b>1</b> i-standard	c	auto drain	D*5 + 2 6 8 C 6C	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8	• • • • •		• • • *7 • *8
temi-standard	c	auto drain Bowl *6	D*5 + 2 6 8 C 6C + - J*9	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain guide 1/4	• • • •		• • • *8 • •
Semi-standard	c	auto drain Bowl *6	D*5 + 2 6 8 C 6C + J*9 U* <sup>13</sup>	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8	• • • • •		• • • *7 • *8
Semi-standard	c	auto drain Bowl *6	D*5 + 2 6 8 C 6C + - J*9	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)			• • • *8 • •
Semi-standard	c	auto drain Bowl *6	D*5 + 2 6 8 C 6C + J*9 W*13 +	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)         Flow direction: Left to right			• *7 *8 • • •
Semi-standard	c d	auto drain Bowl *6 Drain port *12	D*5 + 2 6 8 C 6C + J*9 W*13 + R	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)			• • • *8 • •
Semi-standard	c d	auto drain Bowl *6 Drain port *12	D*5 + 2 6 8 C 6C + J*9 W*13 +	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain guide 1/4         Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)         Flow direction: Left to right         Flow direction: Right to left			• • • *7 *8 • • • • • • • • • • • • •
Semi-standard	c d	auto drain Bowl *6 Drain port *12	D*5 + 2 6 8 C 6C + J*9 W*13 + R	N.O. (Normally open) Drain port is open when pressure is not applied.         Polycarbonate bowl         Metal bowl         Nylon bowl         Metal bowl guard         With bowl guard         With bowl guard (Nylon bowl)         With drain cock         Drain guide 1/8         Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)         Flow direction: Left to right			• *7 *8 • • • •

The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AFM30-A/40-A, AFD30-A/40-A). \*2 Drain guide is G 1/8 (applicable to the AFM20-A, AFD20-A) and G 1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A).

\*3 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

\*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

\*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min [ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended. \*6 Refer to chemical data on page 58 for chemical resistance of the bowl.

\*7 A bowl guard is provided as standard equipment (polycarbonate).

\*8 A bowl guard is provided as standard equipment (nylon).
\*9 Without a valve function

\*10 For pipe thread type: NPT.

\*11  $\bigcirc$ : For pipe thread type: NPT only

\*12 The combination of float type auto drain: C and D is not available.

 $\ast 13\,$  The combination of metal bowl: 2 and 8 is not available.

55



# Mist Separator AFM20-A to AFM40-A Series Micro Mist Separator AFD20-A to AFD40-A Series

### **Standard Specifications**

						- 11	
Model		AFM20-A	AFM30-A	AFM40-A	AFM40-06-A		
		AFD20-A	AFD30-A	AFD40-A	AFD40-06-A		
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4		
Fluid			A	ir		Г	
Ambient and fluid temperature	е		-5 to 60 °C (wi	th no freezing)			
Proof pressure		1.5 MPa					
Maximum operating pressure	)	1.0 MPa					
Minimum operating pressure		0.05 MPa					
	AFM20-A to AFM40-06-A		0.3 μm (99.9 % fil	tered particle size)			
Nominal filtration rating	AFD20-A to AFD40-06-A	0.01 μm (99.9 % filtered particle size)					
Outlet side oil mist	AFM20-A to AFM40-06-A	Max. 1.0 mg/m³ (ANR) (≈ 0.8 ppm) *2 *3					
concentration	AFD20-A to AFD40-06-A	Max. 0.1 mg/m <sup>3</sup> (ANR)	(Before saturated with o	aturated with oil 0.01 mg/m <sup>3</sup> (ANR) or less $\approx$ 0.008 ppm) *2 *3			
Data d flaur [/min (AND)] *1	AFM20-A to AFM40-06-A	200	450	11	00		
Rated flow [I/min (ANR)] *1	AFD20-A to AFD40-06-A	120	240	6	00		
Drain capacity [cm <sup>3</sup> ]		8	25	4	5		
Bowl material			Polycarbonate				
Bowl guard		Semi-standard (Steel) Standard (Polycarbonate)					
Weight [kg]		0.09	0.19	0.38	0.43		
1 Conditions: Inlet pressure: 0.7 MP	a. The rated flow varies deper	nding on the inlet pressure	e				

\*1 Conditions: Inlet pressure: 0.7 MPa; The rated flow varies depending on the inlet pressure.

Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.

\*2 When the compressor oil mist discharge concentration is 30 mg/m3 (ANR).

\*3 Bowl seal and other O-rings are slightly lubricated.

### **Options/Part No.**

		Model						
Optional specifications	AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A				
Bracket assembly *1	Bracket assembly *1			AF42P-050AS	AF42P-070AS			
Float type auto drain *2 *3	N.C.	AD27-A	AD37-A	AD47-A				
Float type auto draill	N.O.	—	AD38-A	AD4	-8-A			

\*1 Assembly of a bracket and 2 mounting screws

\*2 Minimum operating pressure: N.O. type-0.1 MPa; N.C. type-0.1 MPa (AD27-A) and 0.15 MPa (AD37-A/AD47-A).

Please consult with SMC separately for psi and °F unit display specifications. \*3 Please consult with SMC for details on drain piping to fit NPT or G port sizes.

### **Bowl Assembly/Part No.**

Bowl	Drain				Moo	del		
material	discharge mechanism	Drain port	Other	AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A	
		With drain cock	—	C2SF-A	—			
		With drain COCK	With bowl guard	C2SF-C-A	C3SF-A	C4	SF-A	
	Manual	Drain cock with barb fitting	With bowl guard		C3SF-W-A	C4S	F-W-A	
Delveerbenete		With drain guide	_	C2SF□-J-A	—			
Polycarbonate		(without valve function)	With bowl guard	C2SF□-CJ-A	C3SF□-J-A	C4SF	-⊡-J-A	
	Automatia *1	Normally closed (N.C.)	_	AD27-A	—			
	Automatic *1 (Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-C-A	AD37□-A	AD4	7 <b>□</b> -A	
		Normally open (N.O.)	With bowl guard	_	AD38□-A	AD48□-A		
		With drain cock	—	C2SF-6-A	—			
		With drain COCK	With bowl guard	C2SF-6C-A	C3SF-6-A	C4S	F-6-A	
	Manual	Drain cock with barb fitting	With bowl guard		C3SF-6W-A	C4SF	-6W-A	
Nylon		With drain guide	—	C2SF□-6J-A	—	—		
NyIOT		(without valve function)	With bowl guard	C2SF□-6CJ-A	C3SF□-6J-A	C4SF□-6J-A		
	Automotio *1	Normally closed (N.C.)	—	AD27-6-A	—			
	Automatic *1 (Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-6C-A	AD37□-6-A	AD47	′□-6-A	
		Normally open (N.O.)	With bowl guard	_	AD38□-6-A	AD48	3□-6-A	
		With drain cock	—	C2SF-2-A	C3SF-2-A	C4S	F-2-A	
	Manual	With drain cock	With level gauge	—	C3LF-8-A	C4L	F-8-A	
	Ivianuai	With drain guide	—	C2SF□-2J-A	C3SF□-2J-A	C4SF	□-2J-A	
Metal		(without valve function)	With level gauge	_	C3LF□-8J-A	C4LF	□-8J-A	
IVIELAI		Normally closed (N.C.)	_	AD27-2-A	AD37□-2-A	AD47	′□-2-A	
	Automatic *1	Normally closed (N.C.)	With level gauge	_	AD37□-8-A	AD47	′□-8-A	
	(Auto drain)		—	_	AD38□-2-A	AD48	3 <b>□-2-</b> A	
		Normally open (N.O.)	With level gauge	_	AD38□-8-A	AD48	3□-8-A	

\*1 Minimum operating pressure: N.O. type-0.1 MPa (AD38-A, AD48-A); N.C. type-0.1 MPa (AD17-A, AD27-A) and 0.15 MPa (AD37-A, AD47-A). Bowl assembly for the AFM20-A to AFM40-06-A, AFD20-A to AFD40-06-A models comes with a bowl seal.

in bowl assembly part numbers indicates a pipe thread type (applicable tubing for auto drain). No indication is necessary for Rc thread; however, indicate N for

AF+AFM+AR

Attachment | AW+AFM

AF

AFM / AFD


AR

A


AV

# AFM20-A to AFM40-A Series AFD20-A to AFD40-A Series


### Flow Rate Characteristics (Representative values)
























# Mist Separator AFM20-A to AFM40-A Series Micro Mist Separator AFD20-A to AFD40-A Series

/!\ Caution

\land Warning

to the element.

## A Specific Product Precautions

I Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

### **Design/Selection**

## **M**Warning

1. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

			Mat	erial
Туре	Chemical name	Application examples	Polycar- bonate	Nylon
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0
Inorganic salts	Sodium sulfide Potassium nitrate Sulfate of soda	—	×	Δ
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×
Oil	Gasoline Kerosene	_	×	0
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ
O: Essential	ly safe △: Some effect	cts may occur. X: Effe	cts will o	ccur.

When the above factors are present, or there is some doubt, use a metal bowl for safety

## Air Supply

the mist separator to prevent premature clogging.

premature clogging of the element.

AF + AR + AL 1. Install an air filter (AF series) as a pre-filter on the inlet side of AW+AL 2. Install a mist separator (AFM series) as a pre-filter on the inlet side of the micro mist separator to prevent premature clogging. 3. Do not install on the inlet side of the dryer as this can cause AF+AR AF+AFM+AR 1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage Attachment AW+AFM

AF

AFM / AFD

AR

A

AV

AC

Mounting/Adjustment Caution
 Caution

Maintenance

1. When the bowl is installed on the mist separator (AFM30-A/AFM40-A), or micro mist separator (AFD30-A/AFD40-A), install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.





# A Caution

1. Design the system so that the mist separator is installed in a pulsation-free location. The difference between internal and external pressure inside the element should be kept within 0.1 MPa, as exceeding this value could cause damage.

### Selection

### A Caution


SMC

- 1. Do not allow air flow that exceeds the rated flow. If the air flow is allowed outside the range of the rated flow even momentarily, drainage and lubricant may splash at the outlet side or cause damage to the component.
- 2. Do not use in a low pressure application (such as a blower). An F.R.L. unit has its own minimum operating pressure depending on the equipment and is designed specifically to function with compressed air. If used below the minimum operating pressure, a loss of performance and malfunction can occur. Please contact SMC if an application under such conditions cannot be avoided.


# AFM20-A to AFM40-A Series AFD20-A to AFD40-A Series

### Construction

### AFM20-A AFD20-A



### AFM30-A to AFM40-06-A AFD30-A to AFD40-06-A



### **Component Parts**


No.	Description	Material	Model	Colour
1	Body	Aluminium die-cast	AFM20-A to AFM40-06-A AFD20-A to AFD40-06-A	White

#### **Replacement Parts**

	No. Description			Part no.					
No.			Material	AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A		
2	Element assembly	AFM20 to 40	—	AFM20P-060AS	AFM30P-060AS	AFM40P-060AS			
2	Element assembly	AFD20 to 40	—	AFD20P-060AS	AFD30P-060AS	AFD40F	P-060AS		
3	3 Bowl seal		NBR	C2SFP-260S	C32FP-260S	C42FP-260S			
4	4 Bowl assembly *1		Polycarbonate	C2SF-A	C3SF-A	C45	SF-A		

\*1 Bowl seal is included. Please contact SMC regarding the supply of bowl assembly with psi and °F unit display specifications.

# Mist Separator AFM20-A to AFM40-A Series Micro Mist Separator AFD20-A to AFD40-A Series



Applicable model		AFM30-A to AFM40-06-A/AFD30-A to AFD40-06-A										
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with drain guide Metal bowl with level gauge with drain guide		With drain guide	Drain cock with barb fitting						
Dimensions		Width across flats 17	e e e e e e e e e e e e e e e e e e e	Width across flats 17	Width across flats 17	Barb fitting applicable tubing: T0604						

			Standa	rd spoo	ification	c						Optic	onal spe	cificatio	ns		
Model Standard specifications				5			Bracket mount					With auto drain					
	Р	Α	В	С	D	E	G	J	Μ	Ν	Q	R	S	Т	U	V	В
AFM20-A/AFD20-A	1/8, 1/4	40	87.6	9.8	20	—	40	20	30	27	22	5.4	8.4	40	2.3	28	104.9
AFM30-A/AFD30-A	1/4, 3/8	53	115.1	14	26.7	30	50	26.7	41	35	23	6.5	13	53	2.3	30	156.8
AFM40-A/AFD40-A	1/4, 3/8, 1/2	70	147.1	18	35.5	38.4	75	35.5	50	52	26	8.5	12.5	70	2.3	35	186.9
AFM40-06-A/AFD40-06-A	3/4	75	149.1	20	35.5	38.4	75	35.5	50	52	25	8.5	12.5	70	2.3	34	188.9

Semi-standard specifications									
With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide				
В	В	В	В	В	В				
_	91.4	87.4	93.9	—	—				
123.6	121.9	117.6	122.1	137.6	142.1				
155.6	153.9	149.6	154.1	169.6	174.1				
157.6	155.9	151.6	156.1	171.6	176.1				
	<b>B</b> — 123.6 155.6	B         B            91.4           123.6         121.9           155.6         153.9	B         B         B            91.4         87.4           123.6         121.9         117.6           155.6         153.9         149.6	With barb fitting         With drain guide         Metal bowl         Metal bowl with drain guide           B         B         B         B            91.4         87.4         93.9           123.6         121.9         117.6         122.1           155.6         153.9         149.6         154.1	With barb fitting         With drain guide         Metal bowl         Metal bowl with drain guide         Metal bowl with level gauge           B         B         B         B         B         B            91.4         87.4         93.9            123.6         121.9         117.6         122.1         137.6           155.6         153.9         149.6         154.1         169.6				

**SMC** 

60

AF

AFM / AFD

AR

AL

AV

# AFM20-A to AFM40-06-A Mist Separator AFD20-A to AFD40-06-A Micro Mist Separator Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.




### 1 Long Bowl

Drain capacity is greater than that of standard models.

### **Applicable Model/Drain Capacity**

Model	AFM20-A, AFD20-A	AFM30-A, AFD30-A	AFM40-A, AFD40-A	AFM40-06-A, AFD40-06-A	
Port size	1/8, 1/4	/8, 1/4 1/4, 3/8 1/4, 3/8, 1/2			
Drain capacity [cm <sup>3</sup> ]	19	43		88	
B dimension [mm]*1	108.6	137.1	167.2	169.2	

\*1 For polycarbonate bowls. Please contact SMC for other bowl materials.



AFM20-A AFD20-A

#### AFM30 to 40-06-A AFD30 to 40-06-A





· Semi-standard: Select one each for a to d.

• Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AFM30-03B-2R-A-X64

	<u> </u>	_					0	
				Symbol	Description		Body size	
						20	30	40
				—	Rc		•	
2		Pipe	e thread type	<b>N</b> *1	NPT			•
				<b>F</b> *2	G			•
				+				
				01	1/8		—	—
				02	1/4			•
8			Port size	03	3/8	_		•
				04	1/2		_	
				06	3/4	_	_	•
				+				
4		Ontid	on (Mounting)	—	Without mounting option			•
4		Opii	on (wounting)	<b>B</b> *3	With bracket			•
				+				
				—	Polycarbonate bowl			•
				2	Metal bowl			•
		а	Bowl *4	6	Nylon bowl			٠
				С	With bowl guard		*5	*5
				6C	With bowl guard (Nylon bowl)		*6	*6
	0			+				
	dan			—	With drain cock	•	•	•
6	tan	b	Drain port	<b>J</b> *7	Drain guide 1/8			_
	i-s-ic	~	Drain port		Drain guide 1/4	_	•	•
	Semi-standard			<b>W</b> *8	Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube)	_	•	•
				+				
		с	Flow direction	—	Flow direction: Left to right	•	•	•
		Ŭ		R	Flow direction: Right to left	•	•	•
			1	+				
		d	Pressure unit	—	Name plate and caution plate for bowl in SI units: MPa	•	•	•
		ŭ		<b>Z</b> *9	Name plate and caution plate for bowl in imperial units: psi, °F	○*10	○*10	○*10

\*1 Drain guide is NPT 1/8 (applicable to the AFM20-A, AFD20-A) and NPT 1/4 (applicable to the AFM30-A to AFM40-06-A, AFD30-A to AFD40-06-A).

\*2 Drain guide is G 1/8 (applicable to the AFM20-A, AFD20-A) and G 1/4 (applicable to the AFM30-A to AFM40-06-A, AFD30-A to AFD40-06-A).

\*3 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

\*4 Refer to chemical data on page 58 for chemical resistance of the bowl.

\*7 Without a valve function \*8 The combination of metal bowl: 2 is not available.

\*5 A bowl guard is provided as standard equipment (polycarbonate).

\*6 A bowl guard is provided as standard equipment (nylon).

\*9 For pipe thread type: NPT

\*10 O: For pipe thread type: NPT only



# AFM20-A to AFM40-06-A Mist Separator AFD20-A to AFD40-06-A Micro Mist Separator Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### AC 2 With Element Service Indicator Clogging status of elements can be checked visually. AF+AR+AL **Applicable Model** Model AFM20-A, AFD20-A AFM30-A, AFD30-A AFM40-A, AFD40-A AFM40-06-A, AFD40-06-A Port size 1/8. 1/4 1/4.3/8 1/4, 3/8, 1/2 3/4 AFM 30 • Option/Semi-standard: Select one each for a to f. 03 A-X2141 · Option/Semi-standard symbol: When more than one specification is AW+AL required, indicate in alphanumeric order. Example) AFM30-03BD-2R-A-X2141 30 03 A-X2141 AF+AR 1 With element service indicator A special body type is required to mount the element service indicator. It cannot be mounted on a standard body. 0 AF+AFM+AR Symbol Description Body size 20 40 30 Rc N\*1 2 Pipe thread type NPT **F**\*2 G + Attachment AW+AFM 01 1/8 02 1/4 3 Port size 03 3/8 04 1/206 3/4+Without mounting option а Mounting **B**\*3 With bracket Option + 4 Without auto drain Float type b **C**\*4 N.C. (Normally closed) Drain port is closed when pressure is not applied. auto drain **D**\*5 N.O. (Normally open) Drain port is open when pressure is not applied. + Polycarbonate bowl 2 Metal bowl AF 6 • Nvlon bowl Bowl \*6 С 8 Metal bowl with level gauge • With bowl guard С \_\_\_\*8 \*8 6C With bowl guard (Nylon bowl) Semi-standard AFM / AFD + With drain cock 6 **J**\*9 d Drain port \*12 Drain guide 1/4 **W**\*13 Drain cock with barb fitting (for Ø 6 x Ø 4 nylon tube) +Flow direction: Left to right Flow direction е AR R Flow direction: Right to left + Name plate and caution plate for bowl in SI units: MPa f Pressure unit O\*11 0\*11 **Z**\*10 Name plate and caution plate for bowl in imperial units: psi, °F \*1 Drain guide is NPT 1/8 (applicable to the AFM20-A, AFD20-A) and NPT 1/4 \*5 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min (applicable to the AFM30-A/40-A, AFD30-A/40-A). A

The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AFM30-A/40-A, AFD30-A/40-A).

\*2 Drain guide is G 1/8 (applicable to the AFM20-A, AFD20-A) and G 1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A).

\*3 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

\*4 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.

[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.

\*6 Refer to chemical data on page 58 for chemical resistance of the bowl.

\*7 A bowl guard is provided as standard equipment (polycarbonate).

\*8 A bowl guard is provided as standard equipment (nylon).

\*9 Without a valve function

\*10 For pipe thread type: NPT


\*11 O: For pipe thread type: NPT only

\*12 The combination of float type auto drain: C and D is not available.

\*13 The combination of metal bowl: 2 and 8 is not available.



AV



Please contact SMC for detailed dimensions, specifications and lead times.



### **③** Clean Series

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.



### Standard model no.

Please contact SMC if a product with pressure gauge is desired.

Clean series

### **④** Copper, Fluorine and Silicone-free + Low Particle Generation

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.

#### Standard model no. 21

• Copper, fluorine and silicone-free + Low particle generation

# Modular Type Regulator **AR Series**

Regulator AR Series	Model	Port size	Set pressure	Options
	AR10-A	M5 x 0.8	0.05 to 0.7 MPa 0.02 to 0.2 MPa	Bracket Round type pressure gauge Set nut (for panel mount) *1
Star	AR20(K)-B	1/8, 1/4		Bracket
	AR25(K)-B	4/4 2/2		Set nut (for panel mount) *1
	AR30(K)-B	1/4, 3/8		Square embedded type pressure gauge
	AR40(K)-B	1/4, 3/8, 1/2	0.05 to 0.85 MPa 0.02 to 0.2 MPa	Digital pressure switch
	AR40(K)-06-B	3/4		Round type pressure gauge
	AR50(K)-B	3/4, 1		Bracket Square embedded type pressure gauge
Pages 65 to 80	AR60(K)-B	1		Digital pressure switch Round type pressure gauge

AC



Symbol





### How to Order

#### Refer to page 67 for size 20 to 60.



Option/Semi-standard: Select one each for a to g.
Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AR10-<u>M5BG</u>-<u>1NR</u>-A

	<u> </u>			Symbol	Description		
				—	Without mounting option		
	-	а	Mounting	<b>B</b> *2	With bracket		
•	Option *1			Н	With set nut (for panel mount)		
	Opti		·	+			
	-	b	Pressure gauge	—	Without pressure gauge		
				<b>G</b> *3	Round type pressure gauge (without limit indicator)		
				+			
		с	Set pressure *4	—	0.05 to 0.7 MPa setting		
				1	0.02 to 0.2 MPa setting		
				+			
		d	Exhaust mechanism	—	Relieving type		
		ŭ	Exhaust meenamism	Ν	Non-relieving type		
	Semi-standard			+			
2		е	Flow direction	—	Flow direction: Left to right		
9				R	Flow direction: Right to left		
				+			
		f	Knob	—	Downward		
					Upward		
				+			
		g	Pressure unit	—	Name plate and pressure gauge in SI units: MPa		
				Ζ	Name plate and pressure gauge in imperial units: psi		

\*1 Options are not assembled and supplied loose at the time of shipment.

\*2 Assembly of a bracket and set nuts

\*3 A 1.0 MPa pressure gauge will be fitted. It is not assembled and supplied loose at the time of shipment.

\*4 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

# Regulator AR10-A Series

### **Standard Specifications**

•					
Port size	M5 x 0.8				
Pressure gauge port size *1	1/16				
Fluid	Air				
Ambient and fluid temperature	-5 to 60 °C (with no freezing)				
Proof pressure	1.5 MPa				
Maximum operating pressure	1.0 MPa				
Set pressure range	0.05 to 0.7 MPa				
Construction	Relieving type				
Weight [kg]	0.06				

\*1 Use a bushing (part no.: 131368) when connecting the R 1/8 pressure gauge to the Rc 1/16.

### **Options/Part No.**

Bracket assembly *1	AR12P-270AS				
Set nut	AR12P-260S				
Round type pressure gauge *2	G27-10-R1				

\*1 Assembly of a bracket and set nuts

\*2 1.0 MPa pressure gauge

## ▲ Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

### Selection

# **A Warning**

1. Although exhaust of the residual pressure to the inlet side is possible when eliminating the inlet pressure, exhaust is not possible when the set pressure is 0.15 MPa or less.

### Maintenance

## **M** Warning

 When using the regulator between a solenoid valve and an actuator, check the pressure gauge periodically. Sudden pressure fluctuations may shorten the durability of the pressure gauge. A digital pressure gauge is recommended for such situation or as deemed necessary.

### Mounting/Adjustment

## 🕂 Warning

- Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- **2**. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

# **A** Caution

- Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).
- 2. Pulsation will be generated when the difference between the inlet and the outlet pressure is large. In this case, reduce the pressure difference between the inlet and the outlet. Please consult with SMC if the pulsation problem is not resolved.


AFM / AFD

AF

**SMC** 



• With the backflow function, it incorporates a mechanism to exhaust the air pressure in the outlet side reliably and quickly.



# Regulator AR20-B to AR60-B Series Regulator with Backflow Function AR20K-B to AR60K-B Series



AR20-B, AR20K-B AR40-B, AR40K-B

Symbol			Svmbol	Description	Body size						
					20	25	<b>30</b>	<b>40</b>	50	60	
	1	Set	—	0.05 to 0.85 MPa setting						•	
	c			0.02 to 0.2 MPa setting			•	•	•		
	<u> </u>	•	+					•			
	d	Exhaust	—	Relieving type				•			
	la	mechanism	N	Non-relieving type				•			
Ird	<u> </u>	•	+								
Semi-standard		Flow direction	—	Flow direction: Left to right							
stal 0	e	R		Flow direction: Right to left				•	•		
ц.	I —		+								
Se	ء	Knob	—	Downward				•			
	1		Y	Upward							
			+								
			—	Name plate and pressure gauge in SI units: MPa				•			
	g	Pressure unit	<b>Z</b> *7	Name plate and pressure gauge in imperial units: psi	0*9	0*9	0*9	0*9	0*9	0*9	
			<b>ZA</b> *8	Digital pressure switch: With unit selection function	*1	0 △*10	$\triangle^{*10}$	$\triangle^{*10}$	$\triangle^{*10}$	$\triangle^{*10}$	

\*1 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

\*2 Options B, G, H, M are not assembled and supplied loose at the time of shipment.

\*3 Assembly of a bracket and set nuts (applicable to the AR20(K)-B to AR40(K)-B). Including 2 mounting screws for the AR50(K)-B and AR60(K)-B \*4 When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for

standard (0.85 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type. \*5 When choosing with H (panel mount), the installation space for lead wires will not

be secured. In this case, select "wiring top entry" for the electrical entry. (Select "wiring bottom entry" when the semi-standard Y is chosen simultaneously.)

\*6 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

\*7 For pipe thread type: NPT

Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special.

The digital pressure switch will be equipped with the unit selection function, setting to psi initially.

\*8 For options: E1, E2, E3, E4.

- \*9 O: For pipe thread type: NPT only
- \*10  $\triangle$ : Select with options: E1, E2, E3, E4.

∢

₹

AC

AF + AR + AL

AW+AL

AF+AR

AF+AFM+AR

Attachment AW+AFM

### **Standard Specifications**

Model	AR20-B	AR25-B	AR30-B	AR40-B	AR40-06-B	AR50-B	AR60-B			
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1			
Pressure gauge port size *1		1/8								
Fluid		Air								
Ambient and fluid temperature *2	-5 to 60 °C (with no freezing)									
Proof pressure	1.5 MPa									
Maximum operating pressure	1.0 MPa									
Set pressure range	0.05 to 0.85 MPa									
Construction	Relieving type									
Weight [kg]	0.16	0.21	0.29	0.44	0.47	1.17	1.22			

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch. \*2 -5 to 50 °C for the products with the digital pressure switch.



# AR20-B to AR60-B Series AR20K-B to AR60K-B Series

### **Options/Part No.**

Option		Model	AR20(K)-B	AR25(K)-B	AR30(K)-B	AR40(K)-B	AR40(K)-06-B	AR50(K)-B	AR60(K)-B	
Brack	et assem	ibly *1	AR23P-270AS	AR28P-270AS	AR33P-270AS	AR43P	-270AS	AR52P-270AS		
Set nut			AR23P-260S	AR28P-260S	AR33P-260S	AR43F	P-260S	* <sup>2</sup>		
	Round	Standard		G36-10-□01		G46-10-□01				
	type *3	0.02 to 0.2 MPa setting		G36-4-□01		G46-4-🗆01				
	Round type *3			G36-10-□01-L		G46-10-□01-L				
gauge	(with colour zone	0.02 to 0.2 MPa setting		G36-4-□01-L		G46-4-⊡01-L				
	Square *4 embedded type	Standard	GC3-10AS [GC3P-010AS (Pressure gauge cover only)]							
		0.02 to 0.2 MPa setting	GC3-4AS [GC3P-010AS (Pressure gauge cover only)]							
Digita		NPN output, Wiring bottom entry	ISE35-N-25-MLA [ISE35-N-25-M (Switch body only)]							
		NPN output, Wiring top entry	ISE35-R-25-MLA [ISE35-R-25-M (Switch body only)]							
press switch		PNP output, Wiring bottom entry	ISE35-N-65-MLA [ISE35-N-65-M (Switch body only)]							
SWITCH	1	PNP output, Wiring top entry		ISI	E35-R-65-MLA [	[ISE35-R-65-M (Switch body only)]				

\*1 Assembly of a bracket and set nuts. Including 2 mounting screws for the AR50(K)-B and AR60(K)-B

\*2 Please consult with SMC regarding the set nuts for the AR50(K)-B and AR60(K)-B.

□ in part numbers for a round pressure gauge indicates a pipe thread type. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the pressure gauge supply for psi unit specifications. \*3

\*4 Including one O-ring and 2 mounting screws. []: Pressure gauge cover only

\*5 In addition to the pressure switch body, lead wire with connector (2 m), adapter, lock pin, O-ring (1 pc.), mounting screw (2 pcs.) are attached. []: Switch body only. (Regarding how to order the digital pressure switch, refer to the Web Catalogue.)

## Specific Product Precautions

I Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### Selection

## 🗥 Warning

1. Residual pressure disposal (outlet pressure removal) is not possible for the AR20-B to AR60-B even though the inlet pressure is exhausted. When the residual pressure disposal is performed, use the regulator with a backflow function (AR20K-B to AR60K-B).

#### Maintenance

## 🗥 Warning

1. When using the regulator with backflow function between a solenoid valve and an actuator, check the pressure gauge periodically. Sudden pressure fluctuations may shorten the durability of the pressure gauge. A digital pressure gauge is recommended for such situation or as deemed necessary.

### Mounting/Adjustment

## A Warning

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

## Caution

- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).





2. A knob cover is available to prevent careless operation of the knob. Refer to page 112 for details.




## Regulator **AR10-A** Series Regulator AR20-B to AR60-B Series Regulator with Backflow Function AR20K-B to AR60K-B Series











500


Condition: Inlet pressure of 0.7 MPa


1000


1500














AC

AF+AR+AL


AV


AF


# AR10-A Series AR20-B to AR60-B Series AR20K-B to AR60K-B Series


Pressure Characteristics (Representative values)


Conditions: Inlet pressure of 0.7 MPa, Outlet pressure of 0.2 MPa, Flow rate 20 l/min (ANR)
























71




# Regulator With Backflow Function AR20K-B to AR60K-B Series

#### Construction

AR10-A



#### AR30(K)-B/AR40(K)-B



#### **Component Parts**

No.	Description	Material	Model	Colour		
		Zinc die-cast	AR10-A			
1	Body	Aluminium die-cast	AR20(K)-B to AR60(K)-B	White		
			AR10-A			
2	Bonnet	Polyacetal	AR20(K)-B to AR40(K)-B	White		
		Aluminium die-cast	AR50(K)-B/ AR60(K)-B			

#### Replacement Parts


	[AR10-A]											
	No.	Description	Material	Part no.								
	3	Valve	HNBR	AR10P-090S								
	4	Piston assembly	Polyacetal	AR10P-150AS								
5		Valve guide assembly	Polyacetal	131329								

#### [AR20(K)-B to AR60(K)-B]


No.	Description	Material		Part no.											
INO.	Description		AR20(K)-B	AR25(K)-B	AR30(K)-B	AR40(K)-B	AR40(K)-06-B	AR50(K)-B	AR60(K)-B						
3	Valve	Brass, HNBR	AR20P-410S	AR25P-410S	AR30P-410S	AR40P-410S		AR50P-410S	AR60P-410S						
4	Diaphragm assembly	Weatherable NBR	AR20P-150AS	AR25P-150AS	AR30P-150AS	AR40P	AR40P-150AS		AR50P-150AS						
5	Valve guide assembly	Polyacetal	AR20P-050AS	AR25P-050AS	AR30P-050AS	AR40P	AR40P-050AS		AR40P-050AS		AR40P-050AS		AR40P-050AS AF		AR60P-050AS
6	Check valve assembly *1	—			A	AR23KP-020AS									

**SMC** 


\*1 Check valve assembly is applicable for a regulator with backflow function (AR20K-B to AR60K-B) only. Assembly of a check valve cover, check valve body assembly and 2 mounting screws



#### AR50(K)-B/AR60(K)-B



#### AR20K-B to AR60K-B (Regulator with Backflow Function)



AW

AL AR

AC

AF + AR + AL

AW+AL

AF+AR

Attachment AW+AFM AF+AFM+AR

AF


**AFM / AFD** 

### AR10-A Series AR20K-B to AR60K-B Series

#### Working Principle (Regulator with Backflow Function)



When the inlet pressure is higher than the regulating pressure, the check valve operates as a normal regulator (Figure 1). When the inlet pressure is shut off and exhausted, any inlet pressure applied to the valve ① will be lost. The force for seating the valve ① is the valve spring force ② only. When the valve ① is opened using the outlet force, the outlet pressure will be exhausted at the inlet side (Figure 2). When the set pressure is 0.15 MPa or less, the valve ① may not open due to the valve spring ② force.



When the inlet pressure is higher than the regulating pressure, the check valve (2) closes and operates as a normal regulator (Figure 1). When the inlet pressure is shut off and released, the check valve (2) opens and the pressure in the diaphragm chamber (1) is released into the inlet side (Figure 2). This lowers the pressure in the diaphragm chamber (1) and the force generated by the spring (3) lifts the diaphragm. The valve (4) opens through the stem, and the outlet pressure is released to the inlet side (Figure 2).


#### 73

AC
AF + AR + AL
AW+AL
AF+AR
AF+AFM+AR
AW+AFM
Attachment
AF
AFM / AFD
AR
AL
AW

### AR10-A Series AR20-B to AR60-B Series AR20K-B to AR60K-B Series

#### Dimensions

#### AR10-A




P2 A (Pressure gauge port size) Panel mounting dimensions





Plate thickness AR10-A: Max. 3.5

AR20(K)-B to AR40(K)-06-B



#### AR50(K)-B/AR60(K)-B





Panel mounting dimensions






Plate thickness AR20(K)-B to AR30(K)-B: Max. 3.5 AR40(K)-B : Max. 5

P2 (Pressure gauge port size)



### Regulator **AR10-A** Series Regulator AR20-B to AR60-B Series Regulator with Backflow Function **AR20K-B to AR60K-B Series**



											Optional specifications							
Model		Standard specifications								Square embedded type Digital pressu					Round type pressure gauge			
	pressure gauge					e gauge	swi	itch	pressur	pressure gauge		(with colour zone)						
	<b>P</b> 1	<b>P</b> 2	Α	<b>B</b> *1	С	D	F	J	ĸ	Н	J	Н	J	H	J	H	J	
AR10-A	M5 x 0.8	1/16	25	47.4	11	12.5	M18 x 1	12.5	—	—	—	—	—	Ø 26	26	-	-	
AR20(K)-B	1/8, 1/4	1/8	40	67.4	26.5	28.5	M28 x 1	28.5	2 *2	□28	29.5	□27.8	40	Ø 37.5	65	Ø 37.5	66	
AR25(K)-B	1/4, 3/8	1/8	53	71.9	28	27.5	M32 x 1.5	27.5	0	□28	28.5	□27.8	39	Ø 37.5	64	Ø 37.5	65	
AR30(K)-B	1/4, 3/8	1/8	53	85.6	30.7	29.4	M38 x 1.5	29.4	3.5	□28	30.4	□27.8	40.9	Ø 37.5	65.9	Ø 37.5	66.9	
AR40(K)-B	1/4, 3/8, 1/2	1/8	70	91.7	35.8	33.8	M42 x 1.5	33.8	3.5	□28	34.8	□27.8	45.3	Ø 42.5	71.3	Ø 42.5	71.3	
AR40(K)-06-B	3/4	1/8	75	93.2	35.8	33.8	M42 x 1.5	33.8	3	□28	34.8	□27.8	45.3	Ø 42.5	71.3	Ø 42.5	71.3	
AR50(K)-B	3/4, 1	1/8	90	125.2	43	43.3	M62 x 1.5	43.3	3.2	□28	44.3	□27.8	54.8	Ø 42.5	80.8	Ø 42.5	80.8	
AR60(K)-B	1	1/8	95	129.6	46	43.3	M62 x 1.5	43.3	3.2	□28	44.3	□27.8	54.8	Ø 42.5	80.8	Ø 42.5	80.8	

	Optional specifications												
Model			Br	Panel mount									
	М	N	Q	R	S	Т	U	V	W	Y	Z		
AR10-A	25	28	30	4.5	6.5	40	2	18	18.5	—	_		
AR20(K)-B	30	34	43.9	5.4	15.4	55	2.3	24.7	28.5	14	6		
AR25(K)-B	30	34	43.9	5.4	15.4	55	2.3	25.7	32.5	16	6		
AR30(K)-B	41	40	45.8	6.5	8	53	2.3	31.1	38.5	19	7		
AR40(K)-B	50	54	54	8.5	10.5	70	2.3	35.5	42.5	21	7		
AR40(K)-06-B	50	54	55.5	8.5	10.5	70	2.3	37	42.5	21	7		
AR50(K)-B	70	66	65.8	11	13	90	3.2	—	—	—	_		
AR60(K)-B	70	66	65.8	11	13	90	3.2	—	_	_	_		

\*1 The dimension of B is the length when the filter regulator knob is unlocked.
\*2 For the AR20(K)-B only, the position of the pressure gauge is above the centre of the piping.

AW

**SMC** 

### AR20-B to AR60-B Regulator Made to Order Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### **(1)** Special Temperature Environment

Special materials are used in the manufacturing of seals and resin parts to allow them to withstand various temperature conditions in cold or tropical (hot) climates.

#### Specifications

Made-to-	-order part no.	-X430	-X440			
Environn	nent	Low temperature	High temperature			
Ambient t	emperature [°C]	-30 to 60	-5 to 80			
Fluid terr	perature [°C]	-5 to 60 (with no freezing)				
Material	Rubber parts	Special NBR	FKM			
waterial	Main parts	Metal (Aluminium die-cast, etc.)				

#### Applicable Model

Mod			-	AR30-B	AR40-B	AR	40-06-B	AR	50-B	AR	0-F
Ports	-	1/4, 3	_	1/4, 3/8	1/4, 3/8, 1/2	-	3/4		4, 1		1
FOILS	126	1/4, 3	<i>"</i> 0	1/4, 3/0	1/4, 3/0, 1/2	·	3/4	3/4	т, I		
٩R	30	)-[	2	03 6	BG -	6		B	- X	43	80
<ul> <li>Option</li> <li>than</li> <li>alpha</li> </ul>	on/Se one s anume	mi-stan pecifica eric ord	dard ation er.	symbol: \	e each for <b>a</b> to When more d, indicate in 30		X43 X44	te 0 Lo	or hi empe ow ter igh te	eratu npera	<b>ire</b> iture
			Symb	ool l	Description		25	Во <b>30</b>	0 ody siz	ze 50	60
-					Rc		20	•	•	•	
2 Pipe	e thre	ad type			NPT				•		•
	o une	aa type	F		G	_					
			+		0		•	•	•		-
			02		1/4					_	_
			03		3/8			•	•	_	—
3	Port s	size	04		1/2		_	_	•	_	_
			06		3/4		—	—	٠	٠	_
			10	1	1		_	_	_	٠	٠
			+								
			_		it mounting op	tion					
	a	lounting	B								
Option *1	a	Mounting	н	With second with second with second with the second	et nut nel mount)			•		_	_
Dpti			+	(	,						
	b	Pressure gauge	G		ype pressure ga ut limit indicat		•	٠	•	•	•
			+						•		
		Set			0.85 MPa set					٠	
	c b	oressure	1*	<sup>*4</sup> 0.02 to	0.2 MPa setti	ng				٠	٠
			+								
	d	Exhaust	_		ing type						
	۳ n	nechanism	N	Non-re	elieving type						
P			+								
Ida	е	Flow	_		rection: Left to r			٠	٠	•	٠
stan	C	lirection	R	Flow di	rection: Right to	left					
ni-o			+							-	-
Semi-standard	f	Knob	— 	Downy				•	•	-	
0,			Y	Upwar	a					•	
			+								
	F	Pressure	—		plate and press in SI units: MP			٠	•	٠	•
	g	unit	<b>Z</b> *5	gauge	plate and press in imperial	sure	○*6	○*6	○*6	○*6	0*(
				units: p	ISI						

Options B. G. H are not assembled and supplied loose at the time of shipment. \*1 \*2 Assembly of a bracket and set nuts (AR25-B to AR40-B)

Including 2 mounting screws for the AR50-B and AR60-B \*3 Mounting thread for pressure gauge: 1/8, Pressure gauge type: G43 \*4 The only difference from the standard specifications is the spring for the regulator. It does not restrict the setting of 0.2 MPa or more. When the pressure gauge is attached, a 0.4 MPa pressure gauge will be fitted.

\*5 For pipe thread type: NPT

\*6 O: For pipe thread type: NPT only

#### AR30-03-B-X430/440/425

#### 2 High Pressure

Strong materials are used in the manufacturing of regulators intended for high pressure operation. Also, construction modification allows a wider set pressure range.

#### **Specifications**

Made-to-order part no.	-X425				
Proof pressure [MPa]	3.0				
Maximum operating pressure [MPa]	2.0				
Set pressure range [MPa]	0.1 to 1.7				
Ambient and fluid temperature [°C]	-5 to 60 (with no freezing)				

#### Applicable Model

AR20-B AR25-B AR30-B AR40-B AR40-06-B AR50-B AR60-B Model 1/8, 1/4 1/4, 3/8 1/4, 3/8 1/4, 3/8, 1/2 Port size 3/4 3/4, 1

#### 30 03 BG AR X425 5 For high pressure

• Option/Semi-standard: Select one each for a to f.

· Option/Semi-standard symbol: When more than one specification is

required, indicate in alphabetic order.

Example) AR30-03BG-NR-B-X425

				Symbol	Description	20	25	Body 30	size	50	60
	_										
				—	Rc		٠				
2	Pip	e thi	read type		NPT						
_				F	G						
				+							
				01	1/8		—	—	—	—	—
	3 Port size			02	1/4		٠			—	—
6				03	3/8	—	٠	٠	٠	—	—
3				04	1/2	—	—	—		—	—
				06	3/4	—	—	—	٠		—
					1	_	—	—	—		•
				+							
				_	Without mounting option						
				<b>B</b> *2	With bracket		•		•	•	•
	¥	а	Mounting		With set nut	-	-	-	-	-	
4	Option *1			н	(for panel mount)					—	—
	pti			+	( )						
	0	L.	Pressure		Round type pressure switch						
		b	gauge	<b>G</b> *3	(with limit indicator)						•
			gaago	+	(mar maloator)						
			Exhaust		Relieving type						
		с	mechanism	N	Non-relieving type						
			moonamon	+	Non-relieving type						
			Flow	т	Flow direction: Left to right						
	σ	d	direction	 R	Flow direction: Right to left						
	dar		uncellon	+	FIOW UNECTION. RIGHT TO TELL						
B	an			7	Downward						
6	Semi-standard	е	Knob	Y							
	em			+	Upward						
	õ			+	I		-	-			
		f	Pressure	—	Name plate and pressure gauge in SI units: MPa	•	•	•	•	•	•
			unit	<b>Z</b> *4	Name plate and pressure gauge in imperial units: psi	○*5	○*5	○*5	○*5	○*5	○*5
		f		<b>–</b> <b>Z</b> *4	Name plate and pressure gauge in imperial	● ○* <sup>5</sup>	• 0*5	• 0*5	● ○* <sup>5</sup>	• 0*5	0

\*1 Options B, G, H are not assembled and supplied loose at the time of shipment.
 \*2 Assembly of a bracket and set nuts (AR20-B to AR40-B)

Including 2 mounting screws for the AR50-B and AR60-B

\*3 Mounting thread for pressure gauge: 1/8, Pressure gauge type: G46-20-□
\*4 For pipe thread type: NPT.
\*5 ○: For pipe thread type: NPT only





Please contact SMC for detailed dimensions, specifications and lead times.



#### 3 0.4 MPa Setting


The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.4 MPa.

#### **Specifications**

Made-to-order part no.	-X406				
Proof pressure [MPa]	1.5				
Maximum operating pressure [MPa]	1.0				
Set pressure range [MPa]	0.05 to 0.4				

#### **Applicable Model**

Model **AR10** Port size M5



0.4 MPa setting

#### • Option/Semi-standard: Select one each for a to f. • Option/Semi-standard symbol: When more than one specification is required, indicate in alphabetic order. Example) AR10-M5BG-NR-A-X406

				Symbol	Description	Body size
	n *1	a	Mounting	— B*2 H	Without mounting option With bracket With set nut (for panel mount)	
U	Option	b	Pressure gauge *3	+ — G	Without pressure gauge Round type pressure gauge (without limit indicator)	•
		c	Exhaust mechanism	+ — N	Relieving type Non-relieving type	•
	andard	d	Flow direction	+ 	Flow direction: Left to right Flow direction: Right to left	•
2	Semi-standard	е	+ Knob <u>-</u> Y		Downward Upward	•
		f	Pressure unit	+  Z	Name plate and pressure gauge in SI units: MPa Name plate and pressure gauge in imperial units: psi	•

\*1 Options B, G, H are not assembled and supplied loose at the time of shipment.

\*2 Assembly of a bracket and set nuts.\*3 A 1.0 MPa pressure gauge will be fitted.

**≜**Caution • The AR10 comes with a backflow function as a standard feature. When using the AR10 as with backflow function, backflow may not occur with the set pressure of 0.15 MPa or less.

AR

A

AV



Please contact SMC for detailed dimensions, specifications and lead times.



#### 3 0.4 MPa Setting

The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.4 MPa.

#### Specifications

Made-to-order part no.	-X406
Proof pressure [MPa]	1.5
Maximum operating pressure [MPa]	1.0
Set pressure range [MPa]	0.05 to 0.4

#### **Applicable Model**

Mc	odel	AR20(K)-B AR2	5(K)-B A	R30(K)-B AR40(K)-B AR40(K)-06-B AR50(K)-B AR60(K)-B						
Port	size	1/8, 1/4 1/4	1, 3/8	1/4, 3/8 1/4, 3/8, 1/2 3/4 3/4, 1 1						
AF	23		03	B - B - X406 • 0.4 MPa setting						
• Opti	on/Ser	ni-standard: Select ni-standard symbol R30K-03BE-NR-B->	When mo	for <b>a</b> to <b>f</b> . ore than one specification is required, indicate in alphabetic order.			(			
			Symbol	Description	20	25	Body	size	50	60
					20	25	30	40	50	60
2	With	backflow function	— K*1	Without backflow function With backflow function	•	•	•	•	•	•
			+							
6	D:		—	Rc NPT	•	•	•	•	•	•
8	PI	be thread type	N F	G	•	•	•	•	•	•
			<u> </u>	6			•			•
			01	1/8		_	_	_	_	_
			02 1/4			•	•		-	_
		Dest size	03	3/8	_	•			_	_
4		Port size	04	1/2	—	—	—		—	—
			06	3/4	—	—	—			—
			10	1	—	—	—	—		•
			+			_	•			-
		Manuationa	— B*3	Without mounting option With bracket	•	•	•	•	•	•
	а	Mounting	H	With set nut (for panel mount)	•	•	•	•	-	_
			+	with set hut (ior panel mount)						
			· - 1	Without pressure gauge						•
	=		E	Square embedded type pressure gauge (with limit indicator)	•	•	•	•	•	•
<b>6</b>		Pressure gauge*4	G	Round type pressure gauge (with limit indicator)		•			•	•
	b		М	Round type pressure gauge (with colour zone)		•				
	0		E1*5	Output: NPN output, Electrical entry: Wiring bottom entry		•	٠			٠
		Digital pressure	E2*5	Output: NPN output, Electrical entry: Wiring top entry	•	•	•	•	•	•
		switch	E3*5	Output: PNP output, Electrical entry: Wiring bottom entry	•	•	•	•	•	•
			E4*5 +	Output: PNP output, Electrical entry: Wiring top entry		•	•		•	•
		Exhaust		Relieving type		•				•
	С	mechanism		Non-relieving type	•	•	•	•	•	•
	d Flow direction		+			•	•	•	-	-
-			—	Flow direction: Left to right						•
			R	Flow direction: Right to left		•				
6			+							
	2 e	Knob	_	Downward		•	•		•	•
			Y	Upward		•	•			•
			+	Name plate and pressure gauge in SI units: MPa		•			•	•
	f	Pressure unit	 Z*6	Name plate and pressure gauge in SI units: MPa Name plate and pressure gauge in imperial units: psi	● ○*8	● ○*8	 ⊖*8			 ⊖*8
		r ressure unit	ZA*7	Digital pressure switch: With unit selection function						
			24	Digital prossure switch. With unit selection function		$\Delta$	$\Delta$	$\Delta$		$\Delta$

 $\ast 1$  Please set the inlet pressure to at least 0.05 MPa higher than the set pressure.

\*2 Options B, G, H are not assembled and supplied loose at the time of shipment. \*3 Assembly of a bracket and set nuts. (AR20(K)-B to AR40(K)-B). Including 2

mounting screws for the AR50(K)-B and AR60(K)-B

 \*4 A 0.7 MPa pressure gauge will be fitted.
 \*5 When choosing with H (panel mount), the installation space for lead wires will not be secured. In this case, select "wiring top entry" for the electrical entry. (Select "wiring bottom entry" when the semi-standard Y is chosen simultaneously.)

\*6 For pipe thread type: NPT. The digital pressure switch will be equipped with the unit selection function, setting to psi initially.
\*7 For options: E1, E2, E3, E4.

\*8 O: For pipe thread type: NPT only
\*9 △: Select with options: E1, E2, E3, E4.





#### (4) Clean Series

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.



#### Standard model no.

Please contact SMC if a product with pressure gauge is desired.

Clean series

#### **(5)** Copper, Fluorine and Silicone-free + Low Particle Generation

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.

### 21 - Standard model no.

Copper, fluorine and silicone-free + Low particle generation

# Modular Type Lubricator **AL Series**

Lubricator AL Series			Model	Port size	Option
			AL10-A	M5 x 0.8	
			AL20-A	1/8, 1/4	
M	di.	E Maye	AL30-A	1/4, 3/8	
A REAL PROPERTY AND INCOME.			AL40-A	1/4, 3/8, 1/2	Bracket (Except AL10-A)
.485	Ģ	13	AL40-06-A	3/4	
			AL50-A	3/4, 1	
Pages 83 to	90		AL60-A	1	

AF Attachment AW+AFM AF+AFM+AR AF+AR AF+AR AW+AL AF+AR+AL

AC

AFM / AFD

AR

AL

# Lubricator AL10-A to AL60-A

Symbol



-



How to Order

			AL 30		03       B       -       -       A       • Option/Semirequired, ind         2       3       4       5       • Determinequired, ind	-standard sy licate in alph	mbol: Wł anumeric	en more		specificati	ion is	
	Symbo			Symbol	Description	Body size 10 20 30 40 50 60						
					Metric thread (M5)		_	_	_	_	_	
		<b>.</b> .		—	Rc							
0		Ріре	thread type	Ν	NPT		•	•	•			
				F	G							
				+								
				M5	M5 x 0.8		—	_	—	—	_	
				01	1/8			—	—	—	_	
_				02	1/4					—	—	
6		Port size 03 04			3/8		—	•		—	—	
					1/2		—	—		_		
				06	3/4		—	—	•	•		
				10	1		—	—	—			
				+					- 1	- 1		
4	C	Optic	on (Mounting)		Without mounting option		•	•	•	•	•	
		'	· · · · · · · · · · · · · · · · · · ·	<b>B</b> *1	With bracket						•	
_				+			-	-	•	-		
				_	Polycarbonate bowl		•	•	•	•	-	
				2	Metal bowl		•	•	•	•	•	
		а	Bowl *2 *3	6	Nylon bowl		•	•	•	•	•	
				8	Metal bowl with level gauge		_	• *4	• *4	• *4	*4	
				C	With bowl guard		•	*5	*5	*5	*5	
•	g			6C +	With bowl guard (Nylon bowl)		•					
•	nda			T	Without drain cock					•		
6	stal	b	Lubricant	3	With drain cock		•	•	•		_	
	Semi-standard	b	exhaust port	3 3₩*6	Drain cock with barb fitting		•	•	•	•		
	se			+							-	
				т 	Flow direction: Left to right						•	
		С	Flow direction	R	Flow direction: Right to left		•	•	•	•		
				к +			•	•	•	•	•	
				_	Name plate and caution plate: MPa					•	•	
		d	Pressure unit	<b>–</b> <b>Z</b> *7	Name plate and caution plate: psi, °F	0*8	0*8	0*8	0*8	0*8	0*8	
				2	Name plate and caution plate. pol, 1		$\cup$	$\cup$	$\cup$	$\cup$	$\cup$	

\*1 Option is not assembled and supplied loose at the time of shipment. \*2 Refer to chemical data on page 86 for chemical resistance of the bowl.

\*3 Refer to page 89 for 1000 cm<sup>3</sup> tanks.

\*4 A bowl guard is provided as standard equipment (polycarbonate).

\*5 A bowl guard is provided as standard equipment (nylon).

\*6 The combination of metal bowl: 2 and 8 is not available.

\*7 For pipe thread type: M5, NPT

\*8 O: For pipe thread type: M5, NPT only

### Lubricator AL10-A to AL60-A Series

#### **Standard Specifications**

Model	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A			
Port size	M5 x 0.8	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1			
Fluid				Air						
Ambient and fluid temperature		·	-5 to 60 °C (with no freezing)							
Proof pressure				1.5 MPa						
Maximum operating pressure				1.0 MPa						
Minimum dripping flow rate [I/min (ANR)] *1	4	15	1/4: 30 3/8: 40	1/4: 30 3/8: 40 1/2: 50	50	190	220			
Oil capacity [cm <sup>3</sup> ]	7	25	55		13	5				
Recommended lubricant			Class	I turbine oil (ISO	VG32)					
Bowl material				Polycarbonate						
Bowl guard	—	Semi-standard (Steel)		Stan	dard (Polycarbor	nate)				
Weight [kg]	0.07	0.10	0.20	0.38 0.43 0.94 1.09						

• The flow rate is 5 drops or greater/min under the following conditions: Inlet pressure of 0.5 MPa; Class 1 turbine oil (ISO VG32); Temperature at 20 °C; Oil adjustment valve fully open.

• For a circuit that repeatedly turns ON and OFF on the outlet side, make the adjustment so that the average air consumption per minute becomes the minimum dripping flow rate or more.

#### **Option/Part No.**

Optional specifications	Model									
Optional specifications	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A			
Bracket assembly *1	—	AF22P-050AS	AF32P-050AS	AF42P-050AS	AF42P-070AS	AF52P-050AS				
1 Assembly of a bracket and 2 mounting earous										

\*1 Assembly of a bracket and 2 mounting screws

#### **Bowl Assembly/Part No.**

Bowl	Lubricant					Model				
material	exhaust port	Other	AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A	
	Without drain cock	—	C1SL-A	C2SL-A	—					
		With bowl guard		C2SL-C-A	C3SL-A		C45	SL-A		
Polycarbonate	With drain cock	—	C1SL-3-A	C2SL-3-A	—		-	_		
		With bowl guard		C2SL-3C-A	C3SL-3-A	C4SL-3-A				
	Drain cock with barb fitting	With bowl guard			C3SL-3W-A	C4SL-3W-A				
	Without drain cock	—	C1SL-6-A	C2SL-6-A	—	-				
		With bowl guard		C2SL-6C-A	C3SL-6-A	C4SL-6-A				
Nylon	With drain cock	—	C1SL-36-A	C2SL-36-A	—	—				
		With bowl guard	—	C2SL-36C-A	C3SL-36-A	C4SL-36-A				
	Drain cock with barb fitting	With bowl guard		—	C3SL-36W-A		C4SL-	36W-A		
	Without drain cock	—	C1SL-2-A	C2SL-2-A	C3SL-2-A		C4SI	2-A		
Metal		With level gauge		_	C3LL-8-A		C4LL	8-A		
ivielal	With drain cock		C1SL-23-A	C2SL-23-A	C3SL-23-A		C4SL	-23-A		
		With level gauge			C3LL-38-A		C4LL	-38-A		

**SMC** 

\* · Bowl seal is included for the AL20-A to AL60-A.

 $\cdot$  Please consult with SMC separately for psi and °F unit display specifications.


AL

AW

### AL10-A to AL60-A Series

Rc 1/2

#### Flow Rate Characteristics (Representative values)



AL40-A

Pressure drop [MPa]

0.1

0.08

0.06


0.04


0.02


0


0

2000










Flow rate [l/min (ANR)] AL60-A Rc 1 0.0 0.00

4000

6000

8000

#### Working Principle: AL10



A portion of the air introduced from the IN side pressurises the lubricant inside the bowl. The remainder of the air passes through the needle (9), and flows to the OUT side. The differential pressure between the inside of the bowl and the inside of the sight dome (2), causes the lubricant inside the bowl into the oil passage (10). The lubricant drips from the dripping tube (11), and lubricates the OUT side. The amount of lubricant is adjusted by the needle (9) on the front face. Turning the needle clockwise increases the amount of the lubricant, and turning it counterclockwise until fully open shuts off the lubricant. The needle on the side that is not used should be left fully open.



### Lubricator AL10-A to AL60-A Series

### ▲ Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### Selection

### **∕∆Warning**

- 1. Do not introduce air from the outlet side as this can damage the bumper.
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

Туре	Chemical name	Application examples	Mate	erial
туре	Chemical hame	Application examples	Polycarbonate	Nylon
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0
Inorganic salts	Sodium sulfide Potassium nitrate Sulfate of soda	_	×	Δ
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×
Oil	Gasoline Kerosene	_	×	0
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ

When the above factors are present, or there is some doubt, use a metal bowl for safety.

#### Selection

- 1. Use a check valve (AKM series) to prevent back flow of the lubricant when redirecting the air flow before the lubricator.

#### Maintenance

### A Warning

- For the AL10-A/AL20-A, replenish the lubricant after releasing the inlet pressure. Lubrication cannot take place under a pressurised condition.
- 2. Adjustment of the oil regulating valve for models from the AL20-A to AL60-A should be carried out manually. Turning it counterclockwise increases the dripping amount, and turning it clockwise reduces the dripping amount. The use of tools etc. can result in damage to the unit. From the fully closed position, three rotations will bring it to the fully open position. Do not rotate it any further than this. Note that the numbered scale markings are guidelines for adjusting the position, and not indicators of the dripping amount.

#### Caution

1. Check the dripping amount once a day. Drip failure can cause damage to the components that need lubrication.

#### Mounting/Adjustment

#### Caution

1. When the bowl is installed on the AL30-A to AL60-A, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.




AF

₹ N


### AL10-A to AL60-A Series

#### Construction





AL20-A 2 1 (5) OUT 6 (4)  $\overline{(7)}$ 

IN



AL50-A/AL60-A





#### **Component Parts**

No.	Description	Material	Model	Colour
1 Body		Zinc die-cast		White
'	Бойу	Aluminium die-cast	AL20-A to AL60-A	vvnite
8	Housing	Aluminium die-cast	AL50-A/AL60-A	White


#### **Replacement Parts**

Description	Material		Part no.							
No. Description		AL10-A	AL20-A	AL30-A	AL40-A	AL40-06-A	AL50-A	AL60-A		
Sight dome assembly	Polycarbonate	AL10P-080AS		AL20P-080AS						
Lubrication plug assembly	_	—	AL22P-060AS	AL32P-060AS	AL42P-060AS					
Bumper retainer assembly	_	—	AL20P-030AS	AL30P-030AS	AL40P-030AS		AL50P-030AS	AL60P-030AS		
Bumper (assembly)	Synthetic resin	—	AL20P-040S	AL30P-040S	AL40F	P-040S	AL50P-040AS	AL60P-040AS		
Bowl seal	NBR	C1SFP-260S	C2SFP-260S	C32FP-260S	C42FP-260S					
Bowl assembly *1	Polycarbonate	C1SL-A	C2SL-A	C3SL-A	C4SL-A					
	Lubrication plug assembly Bumper retainer assembly Bumper (assembly) Bowl seal	Sight dome assemblyPolycarbonateLubrication plug assembly—Bumper retainer assembly—Bumper (assembly)Synthetic resinBowl sealNBR	Sight dome assemblyPolycarbonateAL10-ASight dome assemblyPolycarbonateAL10P-080ASLubrication plug assembly——Bumper retainer assembly——Bumper (assembly)Synthetic resin—Bowl sealNBRC1SFP-260S	Allo-AAllo-ASight dome assemblyPolycarbonateAL10P-080ASLubrication plug assembly——AL22P-060ASBumper retainer assembly——AL20P-030ASBumper (assembly)Synthetic resin—AL20P-040SBowl sealNBRC1SFP-260SC2SFP-260S	AllohaAllohaAllohaAllohaSight dome assemblyPolycarbonateAL10P-080ASLubrication plug assembly——AllohaAllohaBumper retainer assembly——AllohaAllohaBumper (assembly)Synthetic resin—AllohaAllohaBowl sealNBRC1SFP-260SC2SFP-260SC32FP-260S	Description         Material         AL10-A         AL20-A         AL30-A         AL40-A           Sight dome assembly         Polycarbonate         AL10P-080AS	Description         Material         AL10-A         AL20-A         AL30-A         AL40-A         AL40-A           Sight dome assembly         Polycarbonate         AL10P-080AS         -         -         AL22P-060AS         AL32P-060AS         -         -         AL40P-08AS           Lubrication plug assembly         -         -         AL20P-030AS         AL30P-030AS         -         -         AL40P-030AS           Bumper retainer assembly         -         -         AL20P-030AS         AL30P-030AS         AL40P-040S           Bumper (assembly)         Synthetic resin         -         AL20P-040S         AL30P-040S         AL40P-040S           Bowl seal         NBR         C1SFP-260S         C2SFP-260S         C32FP-260S         C42FP	DescriptionMaterialAL10-AAL20-AAL30-AAL40-AAL40-06-AAL50-ASight dome assemblyPolycarbonateAL10P-080ASAL22P-060ASAL32P-060ASAL42P-060AS		

\*1 • Bowl seal is included for the AL20-A to AL60-A. Please consult with SMC separately for psi and °F unit display specifications.
 • Bowl assembly for the AL30-A to AL60-A models comes with a bowl guard (Material: Polycarbonate).



### Lubricator AL10-A to AL60-A Series



## Semi-standard Specifications: 1000 cm<sup>3</sup> Tank Lubricator L30 to AL60

Available for previous models (AL30 to 60).

Symbol

How to Order

	AL 30		03 B - 1 6 4 6	Option/Semi-standard: Select one each for <b>a</b> to <b>c</b> .     Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.     Example) AL30-03B-1R					
		Symbol	Description		Body				
				30	40	50	60		
		_	Rc				•		
2	Pipe thread type	N	NPT						
		F	G				•		
		+							
		02	1/4			—	_		
		03	3/8			_			
3	Port size	04	1/2	—		—	_		
		06	3/4		•	•	—		
		10	1		_				
		+							
4	Option (Mounting)		Without mounting option				•		
	option (mounting)	<b>B</b> *1	With bracket				•		
		+	1						
	a Bowl *2	1	1000 cm <sup>3</sup> tank				•		
		+							
	<b>b</b> Flow direction		Flow direction: Left to right		•	•	•		
5		R	Flow direction: Right to left						
		+			-				
	c Pressure unit	-	Name plate in SI units: MPa		•	•	•		
		<b>Z</b> *3	Name plate in imperial units: psi	O*4	0*4	0*4	0*4		

\*1 Option B is not assembled and supplied loose at the time of shipment.

\*2 The standard bowl is a metal bowl with level gauge and lubricant discharge function. The material of the sight dome is polycarbonate resin. For chemical resistance, refer to the chemical data on page 463. \*3 For pipe thread type: M5, NPT. This product is for overseas use only according to the new Measurement Act. (The SI unit type is provided for use in Japan.)

\*4 O: For pipe thread type: M5, NPT only

#### Semi-standard/Bowl Assembly Part No.

Semi-standard	specifications		Model					
	With s	switch						
Bowl material	Lowest limit ON	Lowest limit OFF	AL30	AL30 AL40		AL50	AL60	
1000 cm <sup>3</sup> tank (Metal bowl with level gauge)	_	_			121538-1A			

· It is not possible to switch from a polycarbonate, nylon or metal bowl, or from a metal bowl with a level gauge to a 1000 cm<sup>3</sup> tank. Please order the product separately.


· When adding a float switch to the 1000 cm<sup>3</sup> tank, select IS400-1 or IS400-2.


· For other replacement parts, refer to the Operation Manual

Lubricator AL30 to AL60 Series

#### Dimensions

#### Semi-standard specifications: 1000 cm<sup>3</sup> tank





Model	Р	Α	в	С	Bracket mount		Float switch
Woder	F	~		C	Q	V	В
AL30	1/4, 3/8	53	324	38	25	—	374
AL40	1/4, 3/8, 1/2	70	333	40	18	—	383
AL40-06	3/4	75	333	38	16	—	383
AL50	3/4, 1	90	332	41	35	47	382
AL60	1	95	335	45	35	47	385

**SMC** 



AC

AF + AR + AL

AW+AL

AF+AR

AF+AFM+AR

Attachment AW+AFM

AF

AFM / AFD

AR

AL

AW


# Modular Type Filter Regulator **AV Series**

Filter Regulator AW Series	Model	Port size	Set pressure	Options
	<b>AW10-A</b> M5 x 0.8 0.05 to 0.7 MPa 0.02 to 0.2 MPa			Bracket Round type pressure gauge Set nut (for panel mount)*1
	AW20-B	1/8, 1/4		Bracket Set nut (for panel mount)*1
	AW30-B	1/4, 3/8		Float type auto drain
	AW40-B	1/4, 3/8, 1/2	0.05 to 0.85 MPa 0.02 to 0.2 MPa	Square embedded type pressure gauge Digital pressure switch
	AW40-06-B	3/4	0.02 to 0.2 init a	Round type pressure gauge
Pages 93 to 111	AW60-B	3/4, 1		Bracket Square embedded type pressure gauge Digital pressure switch Round type pressure gauge

AL

# **Filter Regulator** AW10-A

#### Symbol



• Integrated filter and regulator units save space and require less piping.

How	to	Order

Refer to page 95 for size 20 to 60.



• Option/Semi-standard: Select one each for a to h. • Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AW10-M5CG-12NR-A

Made to order

(Refer to page 108 for details.)

				Symbol	Description			
		а	a Mounting		Without mounting option With bracket			
		ŭ	linearning	B	With set nut (for panel mount)			
	*			+				
0	ion			_	Without auto drain			
	Option *1	b	Float type auto drain	<b>C</b> *2	N.C. (Normally closed) Drain port is closed when pressure is not applied.			
			I	+				
		с	Pressure gauge	—	Without pressure gauge			
			Flessule gauge	<b>G</b> *3	Round type pressure gauge (without limit indicator)			
				+				
		d	Set pressure *4		0.05 to 0.7 MPa setting			
				1	0.02 to 0.2 MPa setting			
				+				
					Polycarbonate bowl			
		е	Bowl *5	2	Metal bowl			
	Semi-standard			6	Nylon bowl			
	and			+				
2	-sta	f	Exhaust mechanism	<u> </u>	Relieving type			
	emi			N	Non-relieving type			
	Ň			+				
		g	Flow direction		Flow direction: Left to right			
		•		R	Flow direction: Right to left			
				+				
		h	Pressure unit		Name plate, caution plate, and pressure gauge in SI units: MPa			
				Z	Name plate, caution plate, and pressure gauge in imperial units: psi, °F			

\*1 Options B, G, H are not assembled and supplied loose at the time of shipment.

\*2 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

\*3 A 1.0 MPa pressure gauge will be fitted. It is not assembled and supplied loose at the time of shipment.
 \*4 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

\*5 Refer to chemical data on page 98 for chemical resistance of the bowl.

### Filter Regulator **AW10-A** Series

3

AW10-A

AL

#### **Standard Specifications**

	1
Port size	M5 x 0.8
Pressure gauge port size	1/16
Fluid	Air
Ambient and fluid temperature	-5 to 60 °C (with no freezing)
Proof pressure	1.5 MPa
Maximum operating pressure	1.0 MPa
Set pressure range	0.05 to 0.7 MPa
Nominal filtration rating	5 µm
Drain capacity [cm <sup>3</sup> ]	2.5
Bowl material	Polycarbonate
Construction	Relieving type
Weight [kg]	0.09

#### **Options/Part No.**

Bracket assembly *1	AR12P-270AS
Set nut	AR12P-260S
Round type pressure gauge *2	G27-10-R1

\*1 Assembly of a bracket and set nuts


\*2 1.0 MPa pressure gauge

#### **Bowl Assembly/Part No.**

Bowl material	Drain discharge mechanism	Drain port	Bowl part no.
Polycarbonate	Manual	With drain cock	C1SF-A
Polycarbonale	Automatic (Auto drain) *1	Normally closed (N.C.)	AD17-A
Nvlon	Manual	With drain cock	C1SF-6-A
NyIOIT	Automatic (Auto drain) *1	Normally closed (N.C.)	AD27-6-A
Metal	Manual	With drain cock	C1SF-2-A
IVIELAI	Automatic (Auto drain) *1	Normally closed (N.C.)	AD17-2-A

\*1 Minimum operating pressure: 0.1 MPa
 \* Please consult with SMC separately for psi and °F unit display specifications.






**SMC** 

### Filter Regulator AW20-B to AW60-B Series Filter Regulator with Backflow Function AW20K-B to AW60K-B Series



AW20-B, AW20K-B AW40-B, AW40K-B



\*1 Set the inlet pressure to at least 0.05 MPa higher than the set pressure.

- \*2 Drain guide is NPT 1/8 (applicable to the AW20(K)-B) and NPT 1/4 (applicable to the AW30(K)-B to AW60(K)-B). The auto drain port comes with Ø 3/8" One-touch fitting (applicable to the AW30(K)-B to AW60(K)-B).
- \*3 Drain guide is G 1/8 (applicable to the AW20(K)-B) and G 1/4 (applicable to the AW30(K)-B to AW60(K)-B).
- \*4 Options B, G, H, M are not assembled and supplied loose at the time of shipment.
- \*5 Assembly of a bracket and set nuts (applicable to the AW20(K)-B to AW40(K)-B). Including 2 mounting screws for the AW60(K)-B
- \*6 When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- \*7 If the compressor is small (0.75 kW, discharge flow is less than 100 l/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- \*8 When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.85 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- \*9 When choosing with H (panel mount), the installation space for lead wires will not be secured. In this case, select "wiring top entry" for the electrical entry.
- \*10 Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- \*11 Refer to chemical data on page 98 for chemical resistance of the bowl.
- \*12 A bowl guard is provided as standard equipment
- (polycarbonate). \*13 A bowl guard is provided as standard equipment (nvlon).

- \*14 The combination of float type auto drain: C and D is not available.
- \*15 Without a valve function
- \*16 The combination of metal bowl: 2 and 8 is not available.
- \*17 For pipe thread type: NPT. Cannot be used with M: Round type pressure gauge (with colour zone). Available by request for special. The digital pressure switch will be equipped with the unit selection function, setting to psi initially.
- \*18 For options: E1, E2, E3, E4.
- \*19 O: For pipe thread type: NPT only
- \*20  $\triangle$ : Select with options: E1, E2, E3, E4.

#### **Standard Specifications**

Model	AW20-B	AW30-B	AW40-B	AW40-06-B	AW60-B	
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	
Pressure gauge port size *1			1/8			
Fluid			Air			
Ambient and fluid temperature *2		-5 t	to 60 °C (with no free:	zing)		
Proof pressure			1.5 MPa			
Maximum operating pressure			1.0 MPa			
Set pressure range			0.05 to 0.85 MPa			
Nominal filtration rating			5 µm			
Drain capacity [cm <sup>3</sup> ]	8	25		45		
Bowl material			Polycarbonate			
Bowl guard	Semi-standard (Steel)		Standard (Pr	olycarbonate)		
Construction		Relieving type				
Weight [kg]	0.20	0.36	0.66	0.72	2.05	

**GSMC** 

\*1 Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge or with a digital pressure switch.

 $\ast 2\,$  -5 to 50 °C for the products with the digital pressure switch.

AC

AR

A

**A** 

### AW20-B to AW60-B Series AW20K-B to AW60K-B Series

#### **Options/Part No.**

	Optional spe	oificationa	Model					
	Optional spe	cincations	AW20(K)-B	AW30(K)-B	AW40(K)-B	AW40(K)-06-B	AW60(K)-B	
Bracke	t assembly *1		AW23P-270AS	AR33P-270AS	S AR43P-270AS AW62P-27			
Set nut			AR23P-260S	AR33P-260S	S AR43P-260S —			
	Round type *3	Standard	G36-1	0-□01	G46-10-□01			
	Round type	0.02 to 0.2 MPa setting	G36-4-□01		G46-4-□01			
Pressure	Round type *3	Standard	G36-10	-□01-L	G46-10-□01-L			
gauge	(with colour zone)	0.02 to 0.2 MPa setting	G36-4-🗆01-L G46-4-🗆01-L					
	Square embedded	Standard	GC3-10AS [GC3P-010AS (Pressure gauge cover only)]					
	type *4	0.02 to 0.2 MPa setting		GC3-4AS [GC3P-	010AS (Pressure g	gauge cover only)]		
		NPN output, Wiring bottom entry		ISE35-N-25-MLA	[ISE35-N-25-M (S	witch body only)]		
Digital	pressure	NPN output, Wiring top entry		ISE35-R-25-MLA	[ISE35-R-25-M (S	witch body only)]		
switch	*5	PNP output, Wiring bottom entry		ISE35-N-65-MLA	[ISE35-N-65-M (S	witch body only)]		
		PNP output, Wiring top entry		ISE35-R-65-MLA	(ISE35-R-65-M (S	witch body only)]		

\*1 Assembly of a bracket and set nuts. Including 2 mounting screws for the AW60(K)-B

\*2 Please consult with SMC regarding the set nuts for the AW60(K)-B.

\*3 
in part numbers for a round type pressure gauge indicates a pipe thread type.

No indication is necessary for R; however, indicate N for NPT.

Please contact SMC regarding the pressure gauge supply for psi unit specifications.

\*4 Including one O-ring and 2 mounting screws.

[]: Pressure gauge cover only

\*5 In addition to the pressure switch body, lead wire with connector (2 m), adapter, lock pin, O-ring (1 pc.), mounting screw (2 pcs.) are attached.

[]: Switch body only. (Regarding how to order the digital pressure switch, refer to the Web Catalogue.)

A pressure switch can be mounted on the AW60(K)-B, with a special mounting adapter (Pressure switch adapter assembly: AW63P-310AS) and mounting screws (M3 x 0.5 x 14) which are delivered with the mounting adapter.

#### **Bowl Assembly/Part No.**

David	Drain			Model					
Bowl material	discharge mechanism	Drain port	Other	AW20-B	AW30-B	AW40-B	AW40-06-B	AW60-B	
		With drain cock		C2SF-A	—		_		
			With bowl guard	C2SF-C-A	C3SF-A		C4SF-A		
	Manual	Drain cock with barb fitting	With bowl guard	—	C3SF-W-A		C4SF-W-A		
Polycarbonate		With drain guide	—	C2SF□-J-A	—		—		
Folycarbonate		(without valve function)	With bowl guard	C2SF□-CJ-A	C3SF□-J-A		C4SF□-J-A		
	Automatic *1	Normally closed (N.C.)	_	AD27-A	—		—		
	(Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-C-A	AD37□-A	AD47□-A			
	(Auto urain)	Normally open (N.O.)	With bowl guard	—	AD38D-A	AD48□-A			
	Manual	With drain cock	—	C2SF-6-A	—	—			
			With bowl guard	C2SF-6C-A	C3SF-6-A	C4SF-6-A			
		Drain cock with barb fitting	With bowl guard	—	C3SF-6W-A		C4SF-6W-A		
Nylon			With drain guide	—	C2SF□-6J-A	—	—		
TNYIOT		(without valve function)		C2SF□-6CJ-A	C3SF□-6J-A	C4SF⊡-6J-A			
	Automatic *1	natic *1 Normally closed (N.C.)	_	AD27-6-A	—	—			
	(Auto drain)	Normally closed (N.C.)	With bowl guard	AD27-6C-A	AD37□-6-A	AD47□-6-A			
		Normally open (N.O.)	With bowl guard	—	AD38□-6-A		AD48□-6-A		
		With drain cock	_	C2SF-2-A	C3SF-2-A	C4SF-2-A			
	Manual		With level gauge	—	C3LF-8-A		C4LF-8-A		
	Ivialiual	With drain guide	_	C2SF□-2J-A	C3SF□-2J-A		C4SF□-2J-A		
Metal		(without valve function)	With level gauge	—	C3LF□-8J-A		C4LF□-8J-A		
IVIELAI		Normally closed (N.C.)		AD27-2-A	AD37[]-2-A		AD47🗆-2-A		
	Automatic *1	Normally Closed (N.C.)	With level gauge	—	AD37□-8-A		AD47□-8-A		
	(Auto drain)	Normally open (N.O.)		—	AD38□-2-A		AD48□-2-A		
			With level gauge	—	AD38□-8-A		AD48□-8-A		

\*1 Minimum operating pressure: N.O. type-0.1 MPa (AD38-A, AD48-A); N.C. type-0.1 MPa (AD27-A) and 0.15 MPa (AD37-A, AD47-A).

Bowl assembly comes with a bowl seal.

in bowl assembly part numbers indicates a pipe thread type (applicable tubing for auto drain).

No indication is necessary for Rc thread; however, indicate N for NPT thread, and F for G thread. (For auto drain, —: Ø 10, N: Ø 3/8") Please consult with SMC separately for psi and °F unit display specifications.

### Filter Regulator AW20-B to AW60-B Series

### ▲ Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For F.R.L. units I precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual", http://www.smc.eu

#### **Design/Selection**

### \land Warning

- Residual pressure disposal (outlet pressure removal) is not possible for the AW20-B to AW60-B even though the inlet pressure is exhausted. When the residual pressure disposal is performed, use the filter regulator with backflow function (AW20K-B to AW60K-B).
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

			Material		
Туре	Chemical name	Application examples	Polycarbonate	Nylon	
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×	
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0	
Inorganic salts	Sodium sulfide Potassium nitrate Sulfate of soda	_	×	Δ	
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ	
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ	
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×	
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×	
Oil	Gasoline Kerosene	_	×	0	
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0	
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0	
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×	
Others Chread-lock fluid Seawater Leak tester		_	×	Δ	
O: Esse	ntially safe	effects may occur. X:	Effects will	occur.	

Maintenance

#### **M** Warning

 Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

#### Mounting/Adjustment

### **Marning**

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- **2.** Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

### **A** Caution

- Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).
- A knob cover is available to prevent careless operation of the knob. Refer to page 112 for details.
- When the bowl is installed on the AW30-B to AW60-B, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



Lock button

AR

AC

AF+AR+AL

AW+AL

AF+AR

AF+AFM+AR

Attachment AW+AFM

Ч

AFM / AFD


P


When the above factors are present, or there is some doubt, use a metal bowl for safety.




### AW10-A Series AW20-B to AW60-B Series AW20K-B to AW60K-B Series


Flow Rate Characteristics (Representative values)







Condition: Inlet pressure of 0.7 MPa












#### Pressure Characteristics (Representative values)






AW20(K)-B




**SMC** 


Conditions: Inlet pressure of 0.7 MPa, Outlet pressure of 0.2 MPa, Flow rate 20 I/min (ANR)




AW60(K)-B



#### Construction



#### Working Principle (Filter Regulator with Backflow Function)



When the inlet pressure is higher than the regulating pressure, the check valve operates as a normal regulator (Figure 1). When the inlet pressure is shut off and exhausted, any inlet pressure applied to the valve ① will be lost. The force for seating the valve ① is the valve spring force ② only. When the valve ① is opened using the outlet force, the outlet pressure will be exhausted at the inlet side (Figure 2). When the set pressure is 0.15 MPa or less, the valve ① may not open due to the valve spring ③ force.

AL

### AW20-B to AW60-B Series AW20K-B to AW60K-B Series

Construction AW20(K)-B AW30(K)-B/AW40(K)-B AW60(K)-B C  $\bigcirc$  $\bigcirc$ 2  $\bigcirc$ (6)  $\bigcirc$ 2  $\bigcirc$ (1) 6 6 (1) (1)OUT OUT OUT IN IN. IN 7 (7) (4) (4) (5) (5) (4) (8) (8) (3) (5) Drain AW20K-B to AW60K-B 7 (Filter Regulator with Backflow Function) Drain A-A 9 (8) Drain **Component Parts** No. Description Model Colour Material 1 Body Aluminium die-cast AW20-B to AW60-B White Polyacetal AW20-B to AW40-B White 2 Bonnet Aluminium die-cast AW60-B White 3 Housing Aluminium die-cast AW60-B White **Replacement Parts** 

No.	Description	Material	Part no.						
		Iviateriai	AW20(K)-B	AW30(K)-B	AW40(K)-B	AW40(K)-06-B	AW60(K)-B		
4	Valve assembly	Brass, HNBR	AW20P-340AS	AW30P-340AS	AW40P-340AS		AW60P-090AS		
5	Filter element	Non-woven fabric	AF20P-060S	AF30P-060S	AF40P-060S		AW60P-060S		
6	Diaphragm assembly	Weatherable NBR	AR20P-150AS	AR30P-150AS	AR40P-150AS		AR50P-150AS		
7	Bowl seal	NBR	C2SFP-260S	C32FP-260S	C42FP-260S				
8	Bowl assembly *1	Polycarbonate	C2SF-A	C3SF-A*2	C4SF-A*2				
9	Check valve assembly *3	—	AR23KP-020AS						

\*1 Bowl assembly includes the bowl O-ring.

Please consult with SMC separately for psi and °F unit display specifications.


\*2 Bowl assembly for the AW30(K)-B to AW60(K)-B models comes with a bowl guard (Material: Polycarbonate).
\*3 Check valve assembly is applicable for a filter regulator with backflow function (AW20(K)-B to AW60(K)-B) only.

Assembly of a check valve cover, check valve body assembly and 2 mounting screws

### Filter Regulator with Backflow Function AW20K-B to AW60K-B Series

#### Working Principle (Filter Regulator with Backflow Function)

#### AW20K-B to AW60K-B



When the inlet pressure is higher than the regulating pressure, the check valve 2 closes and operates as a normal regulator (Figure 1). When the inlet pressure is shut off and released, the check valve 2 opens and the pressure in the diaphragm chamber 1 is released into the inlet side (Figure 2). This lowers the pressure in the diaphragm chamber ① and the force generated by the spring ③ lifts the diaphragm. The valve ④ opens through the stem, and the outlet pressure is released to the inlet side (Figure 2).

AF

**AFM / AFD** 

### AW10-A Series AW20-B to AW60-B Series AW20K-B to AW60K-B Series

#### Dimensions

#### AW10-A







Plate thickness AW10-A: Max. 3.5

#### AW30(K)-B to AW40(K)-06-B



AW20(K)-B






Plate thickness AW20(K)-B: Max. 3.5

Ζ



103

### Filter Regulator **AW10-A** Series Filter Regulator **AW20-B** to **AW60-B** Series Filter Regulator with Backflow Function **AW20K-B** to **AW60K-B** Series



**GSMC** 

### AW30-B to AW60-B Filter Regulator Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### AC **(1)** Special Temperature Environment Special materials are used in the manufacturing of seals and resin parts to allow them to withstand various temperature conditions in cold or tropical (hot) climates. AF + AR + AL**Specifications** Made-to-order part no. -X430 -X440 Environment Low temperature High temperature Ambient temperature [°C] -30 to 60 -5 to 80 Fluid temperature [°C] -5 to 60 (with no freezing) AW+AL Rubber parts Special NBR FKM Material Main parts Metal (Aluminium die-cast, etc.) Applicable Model AW30-B AW40-B AW40-06-B AW60-B AF+AR Model AW30-03-2-B-X440 1/4, 3/8 Port size 1/4, 3/8, 1/2 3/4 3/4, 1 • Option/Semi-standard: Select one each for a to g. · Option/Semi-standard symbol: When more than one specification is AW 30 B-X430 03 BG 2 required, indicate in alphanumeric order. AF+AFM+AR Example) AW30-03BG-2N-B-X430 4 For high/low temperature X430 Low temperature X440 High temperature Attachment || AW+AFM 1 Symbol Description Body size 30 40 60 Rc 2 Pipe thread type N NPT F G • • + 02 1/4 . 03 3/8 3 Port size 04 1/2• 06 3/4 10 1 + Without mounting option B а Mounting With bracket . Option\* н With set nut (for panel mount) AF 4 + Without pressure gauge b Pressure gauge G Round type pressure gauge (without limit indicator) + 5 Bowl \* 2 Metal bowl **AFM / AFD** + 0.05 to 0.85 MPa setting • • с Set pressure 1\* 0.02 to 0.2 MPa setting + With drain cock . d Drain port **J**\*6 Drain guide 1/4 Semi-standard + AR Relieving type . 6 Exhaust mechanisn е N Non-relieving type . + Flow direction: Left to right . • Flow direction f R Flow direction: Right to left + Name plate, caution plate for bowl, and pressure gauge in SI units: $\ensuremath{\mathsf{MPa}}$ . P Pressure unit g **Z**\*7 Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F Options B. G. H are not assembled and supplied loose at the time of shipment. \*1

\*2 Assembly of a bracket and set nuts (AW30-B to AW40-B)

Including 2 mounting screws for the AW60-B

\*3 Mounting thread for pressure gauge: 1/8, Pressure gauge type: G43

\*4 Only metal bowl 2 is available.

\*5 The only difference from the standard specifications is the spring for the regulator. It does not restrict the setting of 0.2 MPa or more. When the pressure gauge is attached, a 0.4 MPa pressure gauge will be fitted.

\*6 Without a valve function\*7 For pipe thread type: NPT

\*8 ○: For pipe thread type: NPT only

AV

### AW20-B to AW60-B Filter Regulator **Made to Order**

Please contact SMC for detailed dimensions, specifications and lead times.

For high pressure



#### 2 High Pressure


Strong materials are used in the manufacturing of filter regulators intended for high pressure operation. Also, construction modification allows a wider set pressure range.

#### Specifications

Made-to-order part no.	-X425				
Proof pressure [MPa]	3.0				
Maximum operating pressure [MPa]	2.0				
Set pressure range [MPa]	0.1 to 1.7				
Ambient and fluid temperature [°C]	-5 to 60 °C (with no freezing)				

#### **Applicable Model**

Γ	Model	AW20-B	AW30-B	AW40-B	AW40-06-B	AW60-B	
	Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	





#### AW30-03-2-B-X425

• Option/Semi-standard: Select one each for a to f.

- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
- Example) AW30-03BG-2N-B-X425

			Quarter			1		
			Symbol	Description		Body		
					20	30	40	60
_			—	Rc	•	•	•	•
2	Pipe	thread type	N	NPT	•	•	•	•
			F	G	•	•	•	•
			+	· · · · · · · · · · · · · · · · · · ·				
			01	1/8	•	—	—	_
			02	1/4	•	•	•	_
		Dent elere	03	3/8	_	•	•	_
3		Port size	04	1/2	_	—	•	_
			06	3/4	_	_	•	•
			10	1	_	—	—	•
			+	· / [			1	
			—	Without mounting option				•
<del>、</del>	a	Mounting	<b>B</b> *2	With bracket	•			•
2		Ŭ	Н	With set nut (for panel mount)	•	•		_
Option			+					
ŏ		-	_	Without pressure gauge				•
	b	<b>b</b> Pressure gauge	G*3	Round type pressure gauge (with limit indicator)		•		•
			+		-		-	
			2	Metal bowl				•
5		Bowl *4		Metal bowl with level gauge	_	•		•
			8			-	-	-
			—	Relieving type				•
	С	Exhaust mechanism	N	Non-relieving type	•	•	•	•
			+			I	1	
-			—	With drain cock				•
larc	d	Drain port	1.5	Drain guide 1/8	•	_	_	_
			<b>J</b> *5	Drain guide 1/4	_	•		•
-sta			+			Ţ	-	
9 Semi-standard				Flow direction: Left to right				•
S	е	Flow direction	R	Flow direction: Right to left	•	•	•	•
		1	+		•	•	•	•
				Name plate, caution plate for bowl, and pressure gauge in SI units: MPa				•
	f	Pressure unit	<b>Z</b> *6	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O*7	0*7	0*7	0*7
				supplied loose at the time of shipment.	$\smile$	$\bigcirc$	0	0

\*1 Options B, G, H are not assembled and supplied loose at \*2 Assembly of a bracket and set nuts (AW20-B to AW40-B) at the time of shipment.

Including 2 mounting screws for the AW60-B

\*3 Mounting thread for pressure gauge: 1/8, Pressure gauge type: G46-20-□
 \*4 Only metal bowl 2 and 8 are available.

\*5 Without a valve function

\*6 For pipe thread type: NPT \*7 O: For pipe thread type: NPT only

### AW10 Filter Regulator Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.

#### Refer to page 109 and after for size 20 or more.

#### **③ 0.4 MPa Setting**

The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.4 MPa.

#### **Specifications**

Made-to-order part no.	-X406
Proof pressure [MPa]	1.5
Maximum operating pressure [MPa]	1.0
Set pressure range [MPa]	0.05 to 0.4

#### **Applicable Model**

Model	AW10
Port size	M5

**④** Long Bowl

Drain capacity is greater than that of standard models.

#### **Applicable Model/Drain Capacity**

 Model
 AW10

 Port size
 M5

 Drain capacity [cm³]
 9

 B dimension [mm] \*1
 81.6



\*1 For polycarbonate bowls. Please contact SMC for other bowl materials.

AC

AF + AR + AL

		0-M5	0	<b>A</b> - <b>X406</b> <b>2</b> <b>X406</b> 0.4 MPa setting <b>X64</b> Long bowl	ard feature. When using function, backflow may no	backflow function as a stand- the AW10 as with backflow of occur with the set pressure se set the inlet pressure to at n the set pressure.
Option     alpha	n/Se anum		mbol: Wh	each for <b>a</b> to <b>g</b> . en more than one specification is required, indicate in	0.4 MPa Setting	Long Bowl
	_		Symbol	Description	Body size	Body size 10
	a	Mounting	— B*2 H	Without mounting option       With bracket       With set nut (for panel mount)	•	•
Option *1	b	Float type auto drain	+  C	Without auto drain Float type auto drain (N.C.)	•	
	c	Pressure gauge *3	G	Without pressure gauge Round type pressure gauge (without limit indicator)	•	
	d	Bowl *4	+ 2 6	Polycarbonate bowl Metal bowl Nylon bowl	• •	• •
Semi-standard	e	Exhaust mechanism	+ — N	Relieving type Non-relieving type		
Semi-s	f	Flow direction	+  R +	Flow direction: Left to right Flow direction: Right to left	•	•
	g	Pressure unit	 Z	Name plate, caution plate for bowl, and pressure gauge in SI units: MPa Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	• •	•

How to Order

\*1 Options B, G, H are not assembled and supplied loose at the time of shipment.

\*2 Assembly of a bracket and set nuts.

\*3 A 1.0 MPa pressure gauge will be fitted.

\*4 Refer to chemical data on page 98 when selecting a bowl material.

AV

# AW20-B to AW60-B Filter Regulator AW20K-B to AW60K-B Filter Regulator with Backflow Function Made to Order

Please contact SMC for detailed dimensions, specifications and lead times.



#### **3 0.4 MPa Setting**

The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.4 MPa.

#### **Specifications**

Made-to-order part no.	-X406
Proof pressure [MPa]	1.5
Maximum operating pressure [MPa]	1.0
Set pressure range [MPa]	0.05 to 0.4

#### **Applicable Model**

Model	AW20(K)-B	AW30(K)-B	AW40(K)-B	AW40(K)-06-B	AW60(K)-B	
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	

#### 4 Long Bowl

Drain capacity is greater than that of standard models.

#### **Applicable Model/Drain Capacity**

Model	AW20(K)-B	AW30(K)-B	AW40(K)-B	AW40(K)-06-B	AW60(K)-B		
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1		
Drain capacity [cm <sup>3</sup> ]	19	43		88			
B dimension [mm]*1	108.6	137.1	167.2	169.2	254.2		

\*1 For polycarbonate bowls. Please contact SMC for other bowl materials.



be secured. In this case, select "wiring down entry" for the electrical entry.

•••	30		8	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0.4 MPa Long bo							
Dptio Ipha	n/Sem nume		nbol: Wh	each for <b>a</b> to <b>h</b> . en more than one specification is required, indicate in	0.4	4 MPa	I Setti	ng		Long	Bowl	
<u> </u>	_									(		
			Symbol	Description		Body	/ size			Body	/ size	
					20	30	40	60	20	30	40	60
1	14/:44	h a al flaur	_	Without backflow function								
		backflow Inction		With backflow function			•					
	10		+									
			<u> </u>	Rc								
	Pine t	hread type	<b>N</b> *1	NPT	•	•	•		•	•	•	•
	i ipe i		<b>F</b> *2	G		•						•
			+	5			•					
			01	1/8		_	_			_	_	_
		-	02	1/4	<b>O</b>				<b>O</b>			
	_		03	3/8	_	•	•	- 1	_	•	•	
	Po	ort size	04	1/2	_	_			_	_	•	
		-	06	3/4	_	_			_	_		
		Ī	10	1	_	—	_		_	_	_	
			+									
			—	Without mounting option								
	a	Mounting	<b>B</b> *4	With bracket								
			Н	With set nut (for panel mount)				—				
			+				1			1		
		Float type	_	Without auto drain						-	-	-
	b	auto drain	C	Float type auto drain (N.C.)		٠	•	•		-		
ლ *			D	Float type auto drain (N.O.)					_	-	-	-
ioi			+	14/21 - 1								
Option *3		D	 E	Without pressure gauge		•	•				•	•
Ŭ		Pressure *5	G	Square embedded type pressure gauge (with limit indicator) Round type pressure gauge (with limit indicator)		•	•			•	•	
		gauge	 M	Round type pressure gauge (with colour zone)		•	•			•	•	•
	c		E1*6	Output: NPN output, Electrical entry: Wiring bottom entry		•	•					
		Digital	E1*6	Output: NPN output, Electrical entry. Wring bottom entry Output: NPN output, Electrical entry: Wiring top entry		•	•			•	•	
		pressure	E3*6	Output: PNP output, Electrical entry: Wring top entry		•	•			•	•	
		switch -	E4*6	Output: PNP output, Electrical entry: Wiring bottom entry								•
_					embly of a	-	-	-	-	-		-

How to Order

AW30(K)-B to AW60(K)-B).

\*3 Options B, G, H, M are not assembled and supplied loose at the time of shipment.

### Filter Regulator AW20-B to AW60-B Series Filter Regulator with Backflow Function **AW20K-B** to **AW60K-B** Series

60

•

•

•

•

0\*14

∆\*15

A

AV

•

0\*14

∆\*15

		0.4		Setti	ng		Long	BOWI				
	Description	0					0					
	Decemption	00		/ size				y size	_			
		20	30	40	60	20	30	40				
	0.05 to 0.85 MPa setting		-	_	_							
	0.02 to 0.2 MPa setting	—	—	—	—							
	Polycarbonate bowl											
	Metal bowl											
	Nylon bowl											
	Metal bowl with level gauge	—				—	-	—				
	With bowl guard		_	-	—		-	_				
	With bowl guard (Nylon bowl)		—	—	—		—	—				
	With drain cock											
0	Drain guide 1/8		-	-	—		-	—				
-	Drain guide 1/4	—				_						
14												

•

∆\*15

⊃<sup>\*14</sup>

∆\*15

•

<u>)</u>\*14

∆\*15

•

\_\_\*14

∆\*15

•

>\*14

△\*15

•

O\*14

∆\*15

ZA\*13 Digital pressure switch: With unit selection function \*7 The only difference from the standard specifications is the adjusting spring for the regulator. It does not restrict the setting of 0.2 MPa or more. When the pressure gauge is attached, a 0.4 MPa pressure gauge will be fitted.

\*8 Refer to chemical Data on page 98 when selecting a bowl material.

\*9 Float type auto drain: The combination of C and D is not possible.

Symbol

1\*7

+

2

6

8 С

6C +

**J**\*10

W\*1'

+

Ν

+

R

+

Relieving type

Non-relieving type

Flow direction: Left to right

Flow direction: Right to left

Drain cock with barb fitting: For Ø 6 x Ø 4 nylon tube

Name plate, caution plate for bowl, and pressure gauge in SI units:  $\ensuremath{\mathsf{MPa}}$ 

Z\*12 Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F

\*10 Without a valve function

d

е

f

g

h

i

Semi-standard

6

Set pressure

Bowl \*8

Drain port

Exhaust

mechanism

Flow direction

Pressure unit

\*9

\*11 Metal bowl: The combination of 2 and 8 is not possible.

\*12 For pipe thread type: NPT. The digital pressure switch will be equipped with the

unit selection function, setting to psi initially.

\*13 For options: E1, E2, E3, E4.

\*14 ○: For pipe thread type: NPT only
\*15 △: Select with options: E1, E2, E3, E4.





#### **5** Clean Series

For details, refer to the Clean Series/Low Particle Generation section of the Web Catalogue.



#### - Standard model no.

Please contact SMC if a product with pressure gauge is desired.

Clean Series




#### 6 Copper, Fluorine and Silicone-free + Low Particle Generation

For details, refer to the Clean Series/Low Particle Generation section of the **Web Catalogue**.



Copper, fluorine and silicone-free + Low particle generation

⑦ Non-standard filtration rating





Prevents careless knob operation.





Lock (supplied by users)

Part no.	Applicable model
AR20P-580AS	AC20□-B, AR20(K)-B, AW20(K)-B
AR25P-580AS	AC25□-B, AR25(K)-B
AR30P-580AS	AC30□-B, AR30(K)-B, AW30(K)-B
AR40P-580AS	AC40□(-06)-B, AR40(K)(-06)-B, AW40(K)(-06)-B

**SMC** 

#### ▲ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

н

etc.

Caution indicates a hazard with a low level of risk ▲ Caution: which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of risk  $\triangle$  Warning: which, if not avoided, could result in death or serious injury.

Danger indicates a hazard with a high level of risk A Danger : Which, if not avoided, will result in death or serious injury. \_\_\_\_\_

#### 🗥 Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3.Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
  - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
  - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation

#### A Caution

1. The product is provided for use in manufacturing industries. The product herein described is basically provided for peaceful use in manufacturing industries

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary

If anything is unclear, contact your nearest sales branch.

\*1) ISO 4414: Pneumatic fluid power - General rules relating to systems. ISO 4413: Hydraulic fluid power - General rules relating to systems. IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements) ISO 10218-1: Manipulating industrial robots - Safety.

#### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" "Compliance Requirements". and Read and accept them before using the product.

#### Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years the product is delivered, wichever is first.\*2) after Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
  - \*2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

#### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed

#### ∧Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been gualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

#### ✓ Safety Instructions Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation	(Europe)
-----------------	----------

Austria	<b>2 +43 (0)2262622800</b>	www.smc.at	office@smc.at	Lithuania	🕿 +370 5 2308118	www.smclt.lt	info@smclt.lt
Belgium	🕿 +32 (0)33551464	www.smcpneumatics.be	info@smcpneumatics.be	Netherlands	🕿 +31 (0)205318888	www.smcpneumatics.nl	info@smcpneumatics.nl
Bulgaria	🕿 +359 (0)2807670	www.smc.bg	office@smc.bg	Norway	🕿 +47 67129020	www.smc-norge.no	post@smc-norge.no
Croatia	<b>2 +385 (0)13707288</b>	www.smc.hr	office@smc.hr	Poland	<b>222119600 222119600</b>	www.smc.pl	office@smc.pl
Czech Republic	<b>2 +420 541424611</b>	www.smc.cz	office@smc.cz	Portugal	🕿 +351 226166570	www.smc.eu	postpt@smc.smces.es
Denmark	🕿 +45 70252900	www.smcdk.com	smc@smcdk.com	Romania	🕿 +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
Estonia	<b>2 +</b> 372 6510370	www.smcpneumatics.ee	smc@smcpneumatics.ee	Russia	🕿 +7 8127185445	www.smc-pneumatik.ru	info@smc-pneumatik.ru
Finland	🕿 +358 207513513	www.smc.fi	smcfi@smc.fi	Slovakia	<b>2 +421 (0)413213212</b>	www.smc.sk	office@smc.sk
France	<b>2 +</b> 33 (0)164761000	www.smc-france.fr	info@smc-france.fr	Slovenia	<b>2</b> +386 (0)73885412	www.smc.si	office@smc.si
Germany	<b>2 +49 (0)61034020</b>	www.smc.de	info@smc.de	Spain	<b>2 +34 902184100</b>	www.smc.eu	post@smc.smces.es
Greece	🕿 +30 210 2717265	www.smchellas.gr	sales@smchellas.gr	Sweden	<b>2 +46 (0)86031200</b>	www.smc.nu	, post@smc.nu
Hungary	<b>2 + 36 235 13000</b>	www.smc.hu	office@smc.hu	Switzerland	<b>2</b> +41 (0)523963131	www.smc.ch	info@smc.ch
Ireland	<b>2 +353 (0)14039000</b>	www.smcpneumatics.ie	sales@smcpneumatics.ie	Turkey	🕿 +90 212 489 0 440	www.smcpnomatik.com.tr	info@smcpnomatik.com.tr
Italy	<b>2</b> +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	<b>2 +44 (0)845 121 5122</b>	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk
Latvia	🕿 +371 67817700	www.smclv.lv	info@smclv.lv				•

SMC CORPORATION Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362 1st printing VS printing VS 00 Printed in Spain Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.